Replacing the circuit breaker

(pns 48100014SP and 48100013SP)

Line voltage to each line of the sign is routed through a 30A single-pole 120v or double-pole 240v, single-throw circuit breaker. One circuit breaker is used for each line of the sign. These circuit breakers are used in the AlphaEclipse[™]Excite[™], AlphaEclipse[™] RoadStar[™], and AlphaEclipse[™] StreetSmart[™] signs.



Figure 1: 30A SPST circuit breaker

Before you begin

Tools needed

- 5/32-inch hex tool (pn 68117076)
- Screwdriver

Identifying the sign

Sign model labels are located inside the main section or cube and on the outside of each sign.



To replace the circuit breaker in an Excite sign go to page 2.

Figure 2: Sign labels for different types of signs

RoadStar sign model label

ADAPTIVE Adaptive Micro Systems LLC 7840 86th Street Micro Systems LLC 7840 86th Street 7840 85th Street 7840 85th Street 7840 85th Street 7840 85th Street 7840 85th

To replace the circuit breaker in a RoadStar sign, go to page 5.

StreetSmart sign model label



To replace the circuit breaker in a StreetSmart sign, go to page 8.



© Copyright 2008 Adaptive Micro Systems LLC. All rights reserved. Adaptive Micro Systems • 7840 North 86th Street • Milwaukee, WI 53224 USA • 414-357-2020 • 414-357-2029 (fax) • http://www.adaptivedisplays.com Adaptive is a registered trademark of Adaptive Micro Systems. AlphaEclipse, RoadStar, StreetSmart and Excite are trademarks of Adaptive Micro Systems. All other brand and product names are trademarks or registered trademarks of PN 97175010 REV. D

AlphaEclipse Excite sign installation instructions



Figure 3: Circuit breaker location in an AlphaEclipse Excite sign

WARNING! Hazardous voltage. Contact with high voltage may cause death or serious injury. Always disconnect power to unit prior to servicing.

Notice: Observe appropriate precautions to prevent electrostatic discharge (ESD) or "static" damage to the replacement part. For safe handling of ESD-sensitive parts, see TechMemo #00-0005.

⇒ To replace the circuit breaker

1. Disconnect all power to the sign at the power source.

Notice: If you are working on a back-to-back unit, disconnect power to the slave sign at the power source.

2. Locate the door locks in the section door.



Figure 4: Door lock locations



- 3. Open the section door.
 - Using a 5/32-inch hex tool to open the section door lock, turn counterclockwise • and then pull the door toward you.



prevent damage to internal

Figure 5: Use a hex tool to open the door

4. Remove the power bracket from the power distribution plate.



23mm Series A signs ٠

- Remove the screw on the power bracket.
- Lift the power bracket up and off.

Figure 6: Power bracket location in 23mm Series A signs

All other Excite signs .



- Remove the screw on the power bracket.
- Lift the power bracket up and off.

Figure 7: Power bracket location in a 23mm Series B sign and in 20mm and 35mm signs

5. Remove the circuit breaker from the power bracket.



Circuit breaker (S

Figure 8: Remove the circuit breaker

- 6. Install the replacement circuit breaker.
 - Reattach the line voltage wires to the replacement circuit breaker.
 - Using the two screws removed in step 5, attach the replacement circuit breaker to the power bracket.
 - Using the screw removed in step 4, reattach the power bracket to the power distribution plate.
 - Turn the replacement circuit breaker on.
- 7. Close the sign door, tighten door locks, and apply power to the sign.

AlphaEclipse RoadStar sign installation instructions



Figure 9: 30A SPST circuit breaker

WARNING! Hazardous voltage. Contact with high voltage may cause death or serious injury. Always disconnect power to unit prior to servicing.

Notice: Observe appropriate precautions to prevent electrostatic discharge (ESD) or "static" damage to the replacement part. For safe handling of ESD-sensitive parts, see TechMemo #00-0005.

1. Disconnect all power to the sign at the power source.

Notice: All power switches must be in the off position to remove power from the sign. On a two or more line sign, odd numbered lines have power switches that must be turned off prior to servicing.

2. On the control cube, locate the two door locks on the right sign door.

Э Ю) S))))	ЭX0	<u>مر</u>) Second	<u>م</u> ر) (
) O	Э.	OXO	ЭXQ	<u> </u>	œ	<u>o</u> co	0
<u>م</u> ره) S	<u>مر</u> و	Ø	i de la come	0.0	<u>م</u> ره	o, į
<u>م</u> ر	ox0	<u>مر</u> و	Ø	<u>مر</u>	0	<u>م</u> ر	œ
) S	Ø	ЭX0	ЭXФ) Seo) S	<u>مره</u>) Second
Э,C) Second) See	œ) Second	0.0	Э х о	Ø
ġ,©) Second) See	œ) Seo	9.0	©,©	<u>م</u>
) (9,69) Second	9,0	©X0	ОXО	©,©	Оש

Left sign door (front) Right sign door (front)

Figure 10: Door lock locations

closing.

3. Use a 5/32-inch hex tool to open each door lock and then pull the door back.

WARNING! Possible fall or crush hazard. Remain clear of door when opening or



Figure 11: Use a hex tool to open the sign door

4. Remove the power bracket from the controller plate.



Figure 12: Remove the power bracket

5. Remove the circuit breaker from the power bracket.



Circuit breaker (side view)

Figure 13: Remove the circuit breaker

- 6. Install the replacement circuit breaker.
 - Reattach the line voltage wires to the replacement circuit breaker.
 - Using the two screws removed in step 5, attach the replacement circuit breaker to the power bracket.
 - Using the screw(s) removed in step 4, reattach the power bracket to the controller plate.
 - Turn the replacement circuit breaker on.
- 7. Close the sign door and apply power to the sign.

AlphaEclipse StreetSmart sign installation instructions

- StreetSmart 17X/35X signs require a 30A circuit breaker for each power entry. Consequently, a breaker could be used for multiple sign rows.
- StreetSmart 35V/35M signs require a 30A circuit breaker for each sign row. For example, a four row sign with only one power entry must have four circuit breakers—one breaker for each row.



Figure 14: 30A SPST circuit breaker

WARNING! Hazardous voltage. Contact with high voltage may cause death or serious injury. Always disconnect power to unit prior to servicing.

Notice: Observe appropriate precautions to prevent electrostatic discharge (ESD) or "static" damage to the replacement part. For safe handling of ESD-sensitive parts, see TechMemo #00-0005.

1. Disconnect all power to the sign at the power source.

Notice: All power switches must be in the off position to remove power from the sign. On a two or more line sign, odd numbered lines have power switches that must be turned off prior to servicing.

2. Locate the door locks in the section door with the circuit breaker.



Door locks

Figure 15: Door lock locations

3. Open the section door.



Figure 16: Use a hex tool to open the sign door

4. Remove the power bracket from the power distribution plate.



Figure 17: Remove the power bracket

- A Remove the screws on the circuit breaker.
- B Remove the screw on the power bracket.
- **C** Lift the power bracket up and off.

5. Remove the circuit breaker from the power bracket.



Circuit breaker (side view)

Figure 18: Remove the circuit breaker

- 6. Install the replacement circuit breaker.
 - Reattach the line voltage wires to the replacement circuit breaker.
 - Using the two screws removed in step 5, attach the replacement circuit breaker to the power bracket.
 - Using the screw(s) removed in step 4, reattach the power bracket to the power plate.
 - Turn the replacement circuit breaker on.
- 7. Close the sign door and apply power to the sign.