


# Walker Rider Lawnmowers

## OWNER'S MANUAL

Safety, Assembly, Operating, and Maintenance Instructions

Model MDD (Diesel 16.5HP)  
Model MDG (Gasoline 21.0HP)



CE

### **Please Read and Save These Instructions**

For Safety, Read All Safety and Operation  
Instructions Prior to Operating Machine

P/N 7000-1  
Price \$5.00



## Foreword

**Thank you.** . .for purchasing a Walker mower. Every effort has been made to provide you with the most reliable mower on the market, and we are sure you will be among our many satisfied customers. If for any reason this product does not perform to your expectations, please contact us at (970) 221-5614. Every customer is important to us. Your satisfaction is our goal.

**Please.** . .read this manual thoroughly! This manual is to be used in conjunction with the engine manufacturer's manual for the specific engine on the mower model you have purchased. Before you operate your new mower, please read this entire manual. Some of the information is crucial for proper operation and maintenance of this mower - it will help protect your investment and ensure that the mower performs to your satisfaction. Some of the information is important to your safety and must be read and understood to help prevent possible injury to the operator or others. If anything in this manual is confusing or hard to understand, please call our service department, at (970) 221-5614, for clarification before operating or servicing this mower.

This manual covers Model MDD and Model MDG with the following engines, respectively: Kubota D600-B 16.5 HP diesel engine (liquid cooled) and Kubota WG600-B 21.0 HP gasoline engine (liquid cooled).

**All shields and guards must be in place for the proper and safe operation of this machine.** Where they are shown removed in this manual, it is for illustration purposes only. **Do not operate this machine unless all shields and guards are in place.**

Specifications given are based on the latest information available at the time this manual was produced.

Walker Mfg. Co. is continually striving to improve the design and performance of its products. We reserve the right to make changes in specifications and design without thereby incurring any obligation relative to previously manufactured products.

Sincerely,  
WALKER MANUFACTURING COMPANY

A handwritten signature in cursive script that reads "Bob Walker".

Bob Walker, President

# Table of Contents

<b>General Information</b>	1
HIGHLIGHTED INFORMATION	1
GLOSSARY	1
IDENTIFYING NUMBER LOCATIONS	1
ENGINE SERIAL NUMBER LOCATION	2
SERVICING OF ENGINE AND DRIVETRAIN COMPONENTS	2
<b>Specifications</b>	3
ENGINE	3
ELECTRICAL SYSTEM	3
TRANSMISSION	3
BLADE DRIVE	4
TIRE SIZE	4
TIRE PRESSURE	4
DIMENSIONS (TRACTOR AND MOWER)	5
MOWER DECK	5
CURB WEIGHT	5
DRIVE BELTS	5
GHS SYSTEM (Optional)	6
SEAT	6
FRAME/BODY CONSTRUCTION	6
<b>Component Identification</b>	7
<b>Safety Instructions</b>	11
BEFORE OPERATING	11
OPERATING	12
MAINTENANCE	13
SAFETY, CONTROL, AND INSTRUCTION DECALS	15
<b>Assembly Instructions</b>	17
SETUP INSTRUCTIONS	17
Tire Installation (Tractor)	17
<b>Battery Service</b>	17
Wet Battery Service	17
Dry Battery Service	17
Battery Charging	18
Battery Installation	18
<b>Mower Deck Assembly</b>	18
Deck Caster Wheels Installation	18
Deck Discharge Chute Installation	19
Deck Discharge Shield Installation	19
PTO Shaft Guard Installation	19
<b>Mower Deck Installation on Tractor</b>	19
Deck Installation	19
Deck Leveling	21
PREOPERATING CHECKLIST	22

<b>Operating Instructions</b>	24
<b>CONTROL IDENTIFICATION, LOCATION, AND FUNCTION</b>	24
<b>Operating Controls</b>	24
Engine Choke	24
Engine Throttle	25
Forward Speed Control (FSC)	25
Steering Levers	25
Blade Clutch (PTO)	25
Parking Brake	25
Front Body Latch Release	26
Transmission Lockout Levers	26
Cold Start Lever (Jackshaft Drive Belt Release)	26
<b>Instrument Panel</b>	29
Voltmeter	30
Water Temperature Gauge	30
Oil Pressure Warning Light	30
Water Temperature Warning Light	30
Ignition Switch	30
Light Switch (For Optional Lights)	30
Hourmeter	31
Circuit Breakers	31
Glow Plug Indicator - Model MDD	31
Warning Horn	31
<b>STARTING THE ENGINE - MODEL MDD</b>	31
<b>STARTING THE ENGINE - MODEL MDG</b>	32
<b>ADJUSTING GROUND</b>	
<b>SPEED AND STEERING</b>	33
<b>ENGAGING THE MOWER</b>	34
<b>STOPPING THE MACHINE</b>	35
<b>ADJUSTING CUTTING HEIGHT</b>	36
<b>TRANSMISSION LOCKOUT</b>	36
<b>RECOMMENDATIONS FOR MOWING</b>	37
<b>GRASS HANDLING SYSTEM (GHS)</b>	38
General Information	39
Clogging Checklist	40
Using the GHS Catcher	41
Powerfil	41
"Full" Signal Horn	41
Cleaning the GHS Exhaust Screen	41
Dumping the Catcher	42
Tailgate Dumping	42
Using the Dump Bag	42
Power Dump Option	43

# Table of Contents

<b>Maintenance Instructions</b>	45
<b>MAINTENANCE SCHEDULE CHART</b>	45
<b>IMPORTANT TIPS</b>	
<b>FOR CARE OF THE KUBOTA ENGINE</b>	46
Fuel System	46
Starting	46
Cooling System	46
Air Cleaner	46
Oil	46
<b>LUBRICATION</b>	47
<b>Engine Oil</b>	47
Engine Break-In Oil	47
Checking Engine Crankcase Oil Level	47
Changing Engine Crankcase Oil/Oil Filter	47
<b>Grease Fitting and Oil Point Lubrication</b>	48
<b>Mower Deck Gearbox Lubrication</b>	50
<b>DSD62 Mower Deck Lubrication</b>	50
<b>Tractor PTO Gearbox Lubrication</b>	51
Checking Gearbox Oil Level	51
Changing Gearbox Oil	51
<b>Gear Axle Lubrication</b>	51
<b>Hydrostatic Transmission Fluid</b>	52
Checking Hydrostatic	
Transmission Fluid Level	52
Changing Hydrostatic Transmission Fluid	53
<b>CLEANING</b>	53
<b>Engine Air Cleaner System</b>	53
Cyclone Precleaner	53
Air Cleaner Dust Cup	53
Air Filter Element	54
<b>Engine Cooling System</b>	55
Radiator Screen and Cooling Fins	55
Flushing Radiator and Changing Coolant	55
<b>Grass Buildup in Mower Housing</b>	55
<b>GHS Blower</b>	56
<b>GHS Exhaust Screen</b>	57
<b>Hydrostatic Transmission Cooling Fins</b>	57
<b>CHECKING/SERVICING</b>	57
<b>Engine Cooling System</b>	57
Coolant Level	57
Fan Belt Tension	58
<b>Security of Air Filter Element</b>	58
<b>Battery</b>	58
Electrolyte Level	58
Cleaning the Terminals	58
Charging the Battery	58
<b>Tire Pressure</b>	59
<b>Sharpen Mower Blades</b>	59
<b>Drive Belts</b>	60
<b>Mower Deck Gearbox Oil Seals</b>	60
<b>Spark Plugs - Model MDG</b>	60
<b>Ignition Wires - Model MDG</b>	61
<b>Breaker Points - Model MDG</b>	61

<b>Fuel Lines and Clamps</b>	61
<b>Radiator Hoses and Clamps</b>	61
<b>Engine Valve Clearance</b>	61
<b>Fuel Injection Nozzle</b>	
<b>Pressure - Model MDD</b>	61
<b>Fuel Valve Solenoid - Model MDD</b>	61
<b>Blade Brake Action</b>	62
<b>REPLACING/REPAIRING</b>	62
<b>Drive Belts</b>	62
Jackshaft Drive Belt	64
Engine PTO Drive Belt	65
GHS Blower Drive Belt	66
Hydrostatic Ground Drive Belt	67
Engine Fan Belt	68
<b>Fuel Filter - Model MDD</b>	69
<b>Fuel Filter - Model MDG</b>	69
<b>Blade Overload Shear Bolts</b>	69
<b>Mower Blades</b>	70
<b>Mower Deck Gearbox Replacement</b>	70
<b>GHS Blower Assembly</b>	71
GHS Blower Assembly Removal	71
Blower Wheel Removal	72
Blower Wheel Installation	72
GHS Blower Assembly Installation	72
<b>Replacing Fuel Valve Solenoid</b>	73
<b>ADJUSTMENTS</b>	73
<b>Safety Switches</b>	73
Seat Switch	73
FSC Neutral-Park Switch	73
PTO Switch	73
<b>Tail Wheel Bearing Preload</b>	73
<b>Blade Clutch (PTO)</b>	73
Clutch Disengagement/Brake Action	73
Clutch Engagement/Belt Tension	74
<b>Transmission Control</b>	75
Set Forward Travel Limit (Stop)	75
Steering Lever End Play Adjustment	75
Neutral Function Adjustment	75
Straight Ground Travel Adjustment	76
<b>Forward Speed Control Friction Lock</b>	76
<b>Fuel Valve Solenoid Linkage - Model MDD</b>	77
<b>Carburetor - Model MDG</b>	77
<b>GHS "Full" Signal Horn</b>	
with Grass-Pak Switch	78
Troubleshooting	
(When Horn Fails to Operate)	78
Adjustment	
(When Horn Sounds at the Wrong Time)	79
<b>ELECTRICAL SYSTEM</b>	80
<b>Circuit Breakers</b>	80
<b>Wiring Diagram - Model MDD</b>	81
<b>Wiring Diagram - Model MDG</b>	82
<b>Warranty</b>	83

# General Information

## HIGHLIGHTED INFORMATION

Walker Manufacturing recommends that any service requiring special training or tools be performed by an authorized Walker Mower Dealer. There are several general practices to be aware of in the area of safety. Most accidents associated with the operation or maintenance of a Walker Mower are caused by disregarding basic safety precautions or specific warnings. Such accidents, in most cases, can be prevented by being aware of the dangers present.

Information of special importance has been highlighted in bold type in this manual. Refer to **Safety Instructions** for the meanings of **DANGER, WARNING, CAUTION, IMPORTANT, and NOTE**.

## GLOSSARY

There are many terms that are either unique to this equipment or that are used as acronyms. The following terms and their definitions will help while using this manual:

- **DECK** is the mowing attachment mounted on the front of the tractor which includes the carrier frame, deck housing, blade drive gearboxes, and cutter blades.
- **FORWARD SPEED CONTROL (FSC)** controls the maximum forward speed of the tractor; functioning as a cruise control.
- **GRASS HANDLING SYSTEM (GHS®)** collects mowed material and deposits it in the catcher.
- **GRASS-PAK SWITCH®** is mounted on the grass delivery spout (in the catcher) and activates the "full" signal horn when the grass catcher is full.
- **GROUND DRIVE** refers to the dual hydrostatic transmissions which drive the main wheels.
- **HYDROSTATIC TRANSMISSION** transmits and controls power from the ground drive belt to the main drive wheel.

- **POWER TAKE-OFF (PTO)** transmits engine power to run the cutter blades and GHS blower.
- **POWERFIL®** spreads the mowed material throughout the interior of the grass catcher by an oscillating delivery spout.
- **SIDE DISCHARGE (SD)** mows but does not collect the mowed material.
- **STEERING LEVERS** steer the tractor by controlling the dual hydrostatic transmissions.
- **TRACTOR** is the prime mover, including the engine, drive train, operator seat, and controls to operate the mower.
- **TRANSMISSION LOCKOUT** releases the hydrostatic transmissions to permit freewheeling the tractor.


## IDENTIFYING NUMBER LOCATIONS

The tractor serial number plate is affixed to the tractor body just below the left rear corner of the seat. The mower deck serial number plate is affixed alongside the angle iron framing on the RH side of the RH mower blade drive. Model and serial numbers are helpful when obtaining replacement parts and maintenance assistance. For ready reference, please record these numbers in the space provided.


Tractor Model No.	_____
Tractor Serial No.	_____
Deck Serial No.	_____
Engine Model No.	_____
Engine Serial No.	_____
Date of Purchase	_____

**Fill In By Purchaser**

# General Information




**Tractor Serial Number Location**



**Mower Deck Serial Number Location**

## ENGINE SERIAL NUMBER LOCATION

Refer to the engine manual that accompanies this manual for the location of the engine serial number. For mower models covered by this manual, engine manuals are available covering the Kubota D600-B diesel engine (liquid cooled) and the Kubota WG600-B gasoline engine (liquid cooled).



**Engine Serial Number Location**

## SERVICING OF ENGINE AND DRIVETRAIN COMPONENTS

The detailed servicing and repair of the engine, hydrostatic transmission, and gearboxes are not covered in this manual. Only routine maintenance and general service instructions are provided. For the service of these components during the limited warranty period, it is important to find a local, authorized servicing agent of the component manufacturer. **Any unauthorized work done** on these components during the warranty period **may void the warranty**. If you have any difficulty finding an authorized outlet or obtaining warranty service, please contact our Service Department for assistance:

### Walker Manufacturing Company

5925 E. Harmony Road  
Fort Collins, CO 80525  
1-970-221-5614

Service manuals are available for each of these components from their respective manufacturers as follows:

Kubota Engines

### Kubota Tractor Corp.

1300 Remington Road  
Schaumburg, IL 60173

Hydrostatic  
Transmissions

### Eaton Corporation

15151 Highway 5  
Eden Prairie, MN 55344

Gearboxes (Deck)

### Tecumseh Products Co.

900 North Street  
Grafton, WI 53024

# Specifications

MODEL	MDD	MDG
<b>ENGINE</b>		
Manufacturer/Model	Kubota D600-B, 3 Cyl., Diesel (Liquid Cooled)	Kubota WG600-B, 3 Cyl., Gasoline (Liquid Cooled)
Displacement	36.61 cu. in. (600 cc)	36.61 cu. in. (600 cc)
HP (@ 3600 RPM)	16.5	21.0
Max. RPM (No Load)	3800	3850
Governed RPM	3600	3600
Max. Torque [ft-lb (N·m) @ RPM]	25.5 (34.6) @ 2600	30.5 (41.4) @ 2800
Idle RPM	1000 ± 50	1200 ± 50
Spark Plug Type	N/A	NGK BCP4ES-11
Spark Plug Gap	N/A	.043 in. (1.1 mm)
Crankcase Capacity	3.1 qts (2.9 liters)	3.1 qts (2.9 liters)
Crankcase Lubricant	API CC/CD/CE Grade Oil Only with 10W-30 Viscosity or 30W above 77° F (25° C) Only	API SF Grade Oil Only with 10W-30 Viscosity or 30W above 77° F (25° C) Only
Fuel Tank Capacity	3.0 Gallons (11.4 liters)	3.0 Gallons (11.4 liters)
Fuel	Diesel Fuel Oil 2-D	Regular Grade Unleaded Gasoline (87 Octane)
Cooling System Capacity (Approx.)	1.0 Gallon (3.8 liters)	1.0 Gallon (3.8 liters)
Coolant	50/50 Pre-Mix Antifreeze/Water	50/50 Pre-Mix Antifreeze/Water
<b>ELECTRICAL SYSTEM</b>		
Battery	12 Volt, 41AH, 340 CCA (Interstate U1-SP40)	12 Volt, 41AH, 340 CCA (Interstate U1-SP40)
Charging System	Automotive Type Alternator	Automotive Type Alternator
Charging Output	12.5 Amp DC (Regulated)	12.5 Amp DC (Regulated)
System Polarity	Negative Ground	Negative Ground
Ignition	Diesel with Glow Plugs	Transistorized (No Points)
Starter	12 Volt Electric Ring-Gear Type, Solenoid Shift	12 Volt Electric Ring-Gear Type, Solenoid Shift
Interlock Switch	Ignition Lockout by Seat Switch, Transmission Neutral and Blade Clutch	Ignition Lockout by Seat Switch, Transmission Neutral and Blade Clutch
Circuit Breaker	Manual Reset (40A)	Manual Reset (20A)
<b>TRANSMISSION</b>		
Manufacturer/Model	Dual Hydrostatic, Eaton Model 7, Each Wheel Independently Driven	Dual Hydrostatic, Eaton Model 7, Each Wheel Independently Driven
Steering	Hand Lever Control/ Individual Wheel	Hand Lever Control/ Individual Wheel
Forward Speed Control	Precision Friction Lock Lever, Cruise Control, with Neutral-Park Position	Precision Friction Lock Lever, Cruise Control, with Neutral-Park Position

# Specifications

MODEL	MDD	MDG
<b>TRANSMISSION (continued)</b>		
Service Brake	Dynamic Braking through Hydrostatic Transmission	Dynamic Braking through Hydrostatic Transmission
Parking Brake	Mechanical Pin Lock in Transmission Gear	Mechanical Pin Lock in Transmission Gear
Neutral	Transmission Release by Manual Dump Valve	Transmission Release by Manual Dump Valve
Final Drive	Gear Drive Axle	Gear Drive Axle
<b>Transmission Fluid</b>		
Factory Service	SAE 30W Straight Viscosity Motor Oil (Mobil DTE 18M Hydraulic Oil Installed at Factory)	SAE 30W Straight Viscosity Motor Oil (Mobil DTE 18M Hydraulic Oil Installed at Factory)
Alternate Transmission Fluid	Mobile 1 Synthetic Motor Oil (5W30)	Mobile 1 Synthetic Motor Oil (5W30)
Transmission Fluid Capacity	1 qt (1 liter)	1 qt (1 liter)
Transmission Cooling	Cooling Fan Mounted on Drive Pulley	Cooling Fan Mounted on Drive Pulley
<b>Ground Travel Speed</b>		
Forward m.p.h. (km/h)	0-5 (0-8) Infinitely Variable	0-5 (0-8) Infinitely Variable
Reverse m.p.h. (km/h)	0-5 (0-8) Infinitely Variable	0-5 (0-8) Infinitely Variable
<b>BLADE DRIVE</b>		
PTO Shaft	Quick Disconnect Rectangular Shaft with Two High-Speed U-Joints	Quick Disconnect Rectangular Shaft with Two High-Speed U-Joints
Blade Spindle	Each Blade (2) Mounts Direct on Peerless Right Angle Gearbox with Tee Gearbox in Center Connected to PTO Shaft (Complete Geared Drive, Peerless Model 1000 Gearboxes)	Each Blade (2) Mounts Direct on Peerless Right Angle Gearbox with Tee Gearbox in Center Connected to PTO Shaft (Complete Geared Drive, Peerless Model 1000 Gearboxes)
Blade Drive Clutch and Brake	Manual Belt Tightener Clutch and Band Brake (Stops Blades within Five (5) Seconds of Disengagement)	Manual Belt Tightener Clutch and Band Brake (Stops Blades within Five (5) Seconds of Disengagement)
Max. Blade Speed [25 in. (64 cm) Blade] @ 3600 RPM Engine	2400 RPM [15700 FPM (4785 m/min)]	2400 RPM [15700 FPM (4785 m/min)]
<b>TIRE SIZE</b>		
Deck Caster Wheel	2.80/2.50-4 Pneumatic (4-Ply)	2.80/2.50-4 Pneumatic (4-Ply)
Deck Caster Wheel (optional) Drive	8.25 x 2.75 Semi-Pneumatic 18 x 9.50-8 (4-Ply)	8.25 x 2.75 Semi-Pneumatic 18 x 9.50-8 (4-Ply)
Rear (Dual)	13 x 5.00-6 (4-Ply)	13 x 5.00-6 (4-Ply)
<b>TIRE PRESSURE</b>		
Deck Caster Wheel	20 PSI (137 kPa)	20 PSI (137 kPa)
Drive	15 PSI (103 kPa)	15 PSI (103 kPa)
Rear	20 PSI (137 kPa)	20 PSI (137 kPa)



# Specifications

MODEL	MDD	MDG
<b>DIMENSIONS (Tractor and Mower)*</b>		
Length	91 in. (231 cm)	91 in. (231 cm)
Width	49 in. (124 cm)	49 in. (124 cm)
Height	44 in. (112 cm)	44 in. (112 cm)
Wheel Base (Tractor)	42-1/4 in. (107 cm)	42-1/4 in. (107 cm)
Tread Width (Tractor)	29-3/4 in. (76 cm)	29-3/4 in. (76 cm)
<b>MOWER DECK</b>		
Width of Cut SD/GHS	42 or 48 in. (107 or 122 cm)	42 or 48 in. (107 or 122 cm)
Cutting Height	1 to 4 in. (3 to 10 cm)	1 to 4 in. (3 to 10 cm)
Height Adjustment	7 Positions - 1/2 in. (1 cm) Increment Hitch Pins Installed in Multi-Position Deck Support	7 Positions - 1/2 in. (1 cm) Increment Hitch Pins Installed in Multi-Position Deck Support
Blade Size (Typical)		
42 in. (107 cm) SD	22 in. (56 cm) 2 in. (5 cm) Center Overlap (Two Blades, CW Rotation)	22 in. (56 cm) 2 in. (5 cm) Center Overlap (Two Blades, CW Rotation)
48 in. (122 cm) GHS	25 in. (64 cm) 2 in. (5 cm) Center Overlap (Two Blades, Counter Rotate)	25 in. (64 cm) 2 in. (5 cm) Center Overlap (Two Blades, Counter Rotate)
Deck Suspension	Torsion-Flex Frame with Caster Wheels and Counterweight Springs	Torsion-Flex Frame with Caster Wheels and Counterweight Springs
<b>CURB WEIGHT (Approximate)</b>		
SD Tractor Only	760 lb (345 kg)	740 lb (336 kg)
GHS Tractor Only	850 lb (386 kg)	830 lb (376 kg)
Tractor and Mower*	1050 lb (476 kg)	1030 lb (467 kg)
<b>DRIVE BELTS</b>		
Engine Fan	Kubota 15841-97010 (Gates 7320)	Kubota 15841-97010 (Gates 7320)
Engine PTO	Walker P/N 7230 Special Gates Power Band	Walker P/N 7230 Special Gates Power Band
Jackshaft Drive	Gates 3VX335 (P/N 7231)	Gates 3VX335 (P/N 7231)
Ground Drive	Walker P/N 7235 or Gates A45	Walker P/N 7235 or Gates A45
Blower (GHS Model)	Gates 3VX280 (P/N 7234)	Gates 3VX280 (P/N 7234)

\*Dimensions and weight shown are for 48 in. (122 cm) GHS Model (typical).

Dimensions for Tractor and Mower with 42 in. (107 cm) deck are:

Length = 88 in. (224 cm)

Width = 43 in. (110 cm)

For SD Models, subtract 7 in. (18 cm) from the height.


Deck weight for 48 in. (122 cm) deck = 200 lb (91 kg). Deck sizes range from 42 to 62 in. (107 to 157 cm), with corresponding deck weights ranging from 170 to 300 lb (77 to 136 kg).

# Specifications

MODEL	MDD	MDG
<b>GHS SYSTEM (Optional)</b>		
Blower	4 x 10 x 1/4 in. (10 x 25 x 1 cm) Three-Blade Paddle Wheel (Driven by Mower Engine)	4 x 10 x 1/4 in. (10 x 25 x 1 cm) Three Blade Paddle Wheel (Driven by Mower Engine)
Blower Brake	Band Brake (Works in Combination with PTO Clutch, Stops Blower within Five (5) Seconds of PTO Disengagement)	Band Brake (Works in Combination with PTO Clutch, Stops Blower within Five (5) Seconds of PTO Disengagement)
Max. Blower Speed	3600 RPM	3600 RPM
Grass Catcher Capacity	65 Gallons (246 liters)/ 7.0 Bushels	65 Gallons (246 liters)/ 7.0 Bushels
Full Signal	Oscillating Vane Switch Mounted on Grass Delivery Spout Triggers Horn Signal	Oscillating Vane Switch Mounted on Grass Delivery Spout Triggers Horn Signal
Powerfil	Oscillating Delivery Spout Driven by 12 Volt Electric Gearmotor Spreads Material throughout Interior of Catcher @ 25 Cycles/Minute	Oscillating Delivery Spout Driven by 12 Volt Electric Gearmotor Spreads Material throughout Interior of Catcher @ 25 Cycles/Minute
<b>SEAT</b>	Contour-Molded, with Nylon Backed Vinyl Cover and Integral Foam Cushion	Contour-Molded, with Nylon Backed Vinyl Cover and Integral Foam Cushion
<b>FRAME/BODY CONSTRUCTION</b>		
Frame	All Welded Unitized Steel Chassis	All Welded Unitized Steel Chassis
Body	14 Gauge Steel	14 Gauge Steel
Deck	11 Gauge Steel	11 Gauge Steel
GHS Catcher and Chutes	Molded Cross-Linked Polyethylene (UV Stabilized)	Molded Cross-Linked Polyethylene (UV Stabilized)
 <b>NOTE:</b> The manufacturer reserves the right to make changes in specifications shown herein at any time without notice or obligation.		


# Component Identification

**NOTE:** Control Identification shown in **Operating Instructions** section.




**Front View and Right Side View**

# Component Identification




# Component Identification



Top View (Engine Compartment) Model MDD


# Component Identification



**Top View (Engine Compartment) Model MDG**

# Safety Instructions

Pay particular attention to any information labeled **DANGER**, **WARNING**, **CAUTION**, **IMPORTANT**, and **NOTE** in this manual.

When you see the Safety Alert Symbol (  ), read, understand, and follow the instructions. Failure to comply with safety instructions may result in personal injury.

The seriousness or degree of importance of each type of information is defined as follows:

## **DANGER**

An **IMMEDIATE** hazard that **WILL** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.

## **WARNING**

A **POTENTIAL** hazard that **COULD** result in severe personal injury or **DEATH**, if warning is ignored and proper safety precautions are not taken.

## **CAUTION**

Possible hazards or unsafe practices that **MAY** result in **MODERATE** personal injury or property damage, or machine damage, if warning is ignored and proper safety precautions are not taken.

**IMPORTANT:** Identifies mechanical information demanding special attention, since it deals with the possibility of damaging a part or parts of the machine.

**NOTE:** Identifies information worthy of special attention.

Walker Manufacturing cannot predict every potentially dangerous situation. Therefore, items labeled as such in this manual do not cover all conceivable situations. Any person using procedures, tools, or control techniques not recommended by Walker Manufacturing must take full responsibility for safety.

The Walker Rider Lawnmower has been designed with many safety features to protect the operator from personal harm or injury. However, it is necessary for the operator to use safe operating procedures at all times. **Failure to follow safety instructions contained in this manual may result in personal injury or damage to equipment or property.**

If you have any questions concerning setup, operation, maintenance, or safety, please contact your authorized Walker Mower Dealer or call Walker Manufacturing Company at (970) 221-5614.

## **BEFORE OPERATING**

1. **Read and understand the contents of this Owner's Manual before starting and operating the machine.** Become thoroughly familiar with all machine controls and how to stop the machine and disengage the controls quickly. Replacement Owner's Manuals are available by sending the Model and Serial Number to:

**Walker Manufacturing Company**  
5925 East Harmony Road  
Fort Collins, CO 80525

2. **Never allow children to operate rider mower.** Do not allow adults to operate without proper instruction.
3. **Clear the area to be mowed of any foreign objects** which may be picked up and thrown by cutter blades. Pick up all sticks, stones, wire, and any other debris.
4. Keep everyone, especially children and pets, a safe distance away from the area being mowed. **Do not mow with bystanders in the area.**
5. Do not operate the machine barefoot or wearing sandals, sneakers, tennis shoes, or similar lightweight footwear. **Wear substantial protective footwear.**

# Safety Instructions

6. Do not wear loose fitting clothing that could get caught in moving parts. Do not operate this machine while wearing shorts; **always wear adequate protective clothing**, including long pants. Wearing safety glasses, safety shoes, and a helmet is advisable and required by some local ordinances and insurance regulations.
7. Prolonged exposure to loud noise can cause impairment or loss of hearing. **Operator hearing protection is recommended**; particularly for continuous operation of the GHS Model due to blower noise level. Wear a suitable hearing protective device, such as earmuffs or earplugs.
8. **Keep all protective shields and safety devices in place.** If a protective shield, safety device, or decal is damaged, unusable, or missing, repair or replace it **before** operating the machine.
9. **Be sure interlock switches are functioning correctly**, so the engine cannot be started unless the Forward Speed Control lever is in the **NEUTRAL-PARK** position, and the PTO clutch is in the **DISENGAGED** position. Also, the engine should stop if the operator lifts off the seat with the PTO clutch in the **ENGAGED** position.
10. **Handle gasoline or diesel fuel with care.** Gasoline is highly flammable and its vapors are explosive:
  - a. Use an approved fuel container.
  - b. Never add fuel to a running engine or hot engine (allow hot engine to cool several minutes).
  - c. Keep matches, cigarettes, cigars, pipes, open flames, or sparks away from the fuel tank and fuel container.
  - d. Always fill the fuel tank outdoors using care. Fill to about one inch from the top of the tank. Use a funnel or spout to prevent spilling.
  - e. Replace the machine fuel cap and container cap securely and clean up any spilled fuel before starting the engine.
11. **Never attempt to make any adjustments while the engine is running**, except where specifically instructed to do so.

12. The electrical system battery contains sulfuric acid. Avoid any contact with skin, eyes, and clothing. Keep the battery and acid out of reach of children.

## OPERATING

1. **Operate the mower only in daylight** or in good artificial light with good visibility of the area being mowed.
2. Sit on the seat when starting the engine and operating the machine. Keep feet on the deck footrests at all times when the tractor is moving and/or mower blades are operating.
3. For a beginning operator, **learn to steer (maneuver) the tractor with a slow engine speed before attempting any mowing operation.** Be aware that, with the front mounted mower configuration, the back of the tractor swings to the outside during turns.
4. Remember, for an emergency stop, the forward motion of the tractor can always be stopped by pulling the Forward Speed Control (FSC) into the **NEUTRAL-PARK** position.
5. Disengage the blade clutch and put the FSC in the **NEUTRAL-PARK** position before starting the engine (an ignition interlock switch normally prevents starting of the machine if these controls are in the **OPERATING** position).
6. **Do not run the engine in a confined area without adequate ventilation.** Exhaust fumes are hazardous and can be deadly.
7. **Do not carry passengers** - maximum seating capacity is one (1) person.
8. Watch for holes, rocks, and roots in the terrain and for other hidden hazards. When mowing tall grass, mow higher than desired to expose any hidden obstacles. Then, clean the area and mow to the desired height.
9. **Avoid sudden starts or stops.** Before backing the machine up, look to the rear to be sure no one is behind the machine. Watch carefully for traffic when crossing or working near roadways.



# Safety Instructions

10. Disengage the blade drive when transporting the machine across drives, sidewalks, etc. **Never raise the mower deck while blades are rotating.**
11. **The maximum recommended side slope operating angle is 20 degrees or 33% grade.** When operating the machine on a slope, reduce speed and use caution to start, stop, and maneuver. To prevent tipping or loss of control of the machine, avoid sharp turns or sudden changes in direction.
12. **Never adjust cutting height with the engine running.** Before adjusting cutting height or servicing, disengage the blade clutch (PTO), stop the engine, and remove the ignition key. Wait for all movement to stop before getting off the seat.  
  
**NOTE:** A blade/blower brake should normally stop drive line rotation within five (5) seconds of disengaging the PTO clutch.
13. For side discharge mower decks, **do not operate with the grass deflector chute removed.** Keep the deflector in the lowest possible position.
14. For GHS equipped models, **do not operate the machine with the grass catcher in the DUMP position or with the back door OPEN.** Dangerous projectiles may be thrown out of the discharge chute or the back of the grass catcher.
15. For GHS equipped models, **use care when closing the grass catcher door.** Keep fingers and hands away from the hinge and pinch points when the door is being closed. Also, keep fingers and hands clear of the door frame. The door is held closed with springs and the door may slam shut with considerable force.
16. **In case of a clogged or plugged mower deck or GHS catching system:**
  - a. Disengage the blade clutch (PTO) and turn the engine off before leaving the seat.
  - b. **LOOK** to make sure blade drive shaft and blower drive pulley movement has stopped before trying to unclog the system.

- c. Disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wire (MDG).
  - d. Never place hands under the deck or in the GHS blower - use a stick or similar tool to remove clogged material.
17. If the cutting blades strike a solid object or the machine begins to vibrate abnormally, **immediately disengage the blade clutch (PTO), stop the engine, and wait for all moving parts to stop.** To prevent accidental starting, disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG). Thoroughly inspect the mower and repair any damage before restarting the engine and operating the mower. Make sure cutter blades are in good condition and blade nuts are torqued to 60 ft-lb (81.3 N·m).
  18. **Do not touch the engine or muffler while the engine is running** or immediately after stopping the engine. These areas may be hot enough to cause serious burns.
  19. **Never remove the radiator pressure cap when the engine is hot** (hot water may spray and cause burns).
  20. **Do not use ether or any starting fluid** to assist starting the engine in cold weather.
  21. When leaving the machine unattended, **disengage the blade clutch (PTO), stop the engine, and remove the key.**

## MAINTENANCE

1. To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG).
2. **To reduce fire hazards,** keep the engine free of grass, leaves, excessive grease, and dirt.
3. Keep all nuts, bolts, and screws tight to ensure the machine is in a safe, working condition. Check the blade mounting nuts frequently, making sure they are tight.

# Safety Instructions

4. **Perform only maintenance instructions described in this manual.** Unauthorized maintenance operations or machine modifications may result in unsafe operating conditions.
  5. If the engine must be running to perform a maintenance adjustment, keep hands, feet, and clothing away from moving parts. **Do not wear jewelry or loose clothing.**
  6. **Always use the proper engine service manual when working on the engine.** Unauthorized maintenance operations or modifications to the engine may result in unsafe operating conditions.
  7. For Model MDD (Diesel Engine), the fuel oil injection system operates under high pressure and can penetrate the skin and result in serious injury. Unqualified persons should not remove or attempt to adjust a pump injector, nozzle, or any part of the fuel injection system.
  8. Altering the equipment or engine in any manner which adversely affects its operation, performance, durability, or use will **VOID the warranty** and may cause hazardous conditions.
  9. Never attempt to disconnect any safety devices or defeat the purpose of these safety devices.
  10. Do not change the engine governor settings or overspeed the engine. The governor has been factory-set for maximum-safe engine operating speed.
  11. **Use genuine factory replacement parts.** Substitute parts may result in product malfunction and possible injury to the operator and/or others.
  12. **Use care when charging the battery** or performing maintenance on the battery and electrical system:
    - a. Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.
    - b. Charge the battery in a well-ventilated space, so gases produced while charging can dissipate. Make sure the battery vents in the caps are open.
    - c. Keep sparks, flames, and smoking materials away from the battery at all times. To avoid sparks, use care when removing battery cables from posts.
    - d. Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.
- IMPORTANT:** Keep all applicable manuals immediately accessible to anyone who may operate or service this machine.


# Safety Instructions

## SAFETY, CONTROL, AND INSTRUCTION DECALS

Safety, Control, and Instruction Decals are installed on the machine; if any are missing, illegible, or damaged, a replacement should be ordered and installed before putting the machine into operation. The Decal Part Number is listed below and in the Parts Manual.



Each End of Mower Deck (5808)



Adjacent to Blower Discharge Chute Through Body (5804)



SD Deck Discharge Shield (5848)




Front Body Adjacent RH Steering Lever (7818)




Hydrostat Oil Reservoir (5810)



On Body Adjacent Clutch Control Lever (5806)



Radiator Screen Frame Near Radiator Fill Cap (7826)



Rear of Grass Catcher (5869)



Right Side of Front Body, Below Catch Release Lever for the Front Body Section (7820)




Rear Cross member of Front Body (8825)


# Safety Instructions

## SAFETY, CONTROL, AND INSTRUCTION DECALS

Safety, Control, and Instruction Decals are installed on the machine; if any are missing, illegible, or damaged, a replacement should be ordered and installed before putting the machine into operation. The Decal Part Number is listed below and in the Parts Manual.




Front Corners of Grass Catcher (7817)



Deck Gearbox Cover (5807-1)



Deck Carrier Frame (5865)




Jackshaft Support Adjacent to Dipstick (7827)



Top of Blower Housing (5819)



Right Side, Below Operator Seat (7809)




Left Side of Operator Seat (7819)




Catcher Door Hinge Bar: LH and RH Sides (5868)



Gear Axle (5810-1)



RH Fender (7802)



Instrument Panel (7823)

# Assembly Instructions

## SETUP INSTRUCTIONS

Walker Mowers are shipped partially assembled. After uncrating the tractor and mower deck, initial setup is required.

**NOTE:** During the process of unpacking, any damaged or missing parts should be noted and reported to the delivering carrier immediately (put in writing within 15 days). The carrier will provide directions for proceeding with a claim to receive compensation for damage.

### Tire Installation (Tractor)

- Install the drive tires using the eight (8) lug bolts that are supplied with the owner's packet of materials. Drive tires are 18 x 9.50-8, 4-ply; rear tires are 13 x 5.00-6, 4-ply.
- Check and adjust the inflation of the tires. The tire inflation recommendations are:

Drive = 15 PSI (103 kPa)  
Rear = 20 PSI (137 kPa)

### Battery Service

Raise front mower body up for battery access (refer to *Front Body Latch Release* in **Operating Instructions**). Check the battery for electrolyte level and charge. The electrolyte level should be at the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above plates]. If the specific gravity is less than 1.225, the battery needs charging. If the battery has been shipped dry, or is wet but needs service, refer to the following instructions.

#### *Wet Battery Service*

If the battery has been shipped wet, but the electrolyte level is low or the battery needs to be charged then:

1. Fill each battery cell with drinking water to the bottom of the vent wells.
2. Charge battery. Refer to *Battery Charging* in this section.

#### *Dry Battery Service*



**DANGER**

**Activating a battery can be dangerous. The battery should be taken to a reliable service station, battery store, or power equipment dealer where a trained technician can activate the battery safely. DO NOT attempt to activate the battery unless you are experienced in battery service work. The following activation and charging instructions are provided for use by a trained battery technician.**



**DANGER**

**Battery electrolyte is a poisonous and corrosive sulfuric acid solution.**

- **Avoid spillage and contact with skin, eyes, and clothing - causes severe burns.**
- **To prevent accidents, wear safety goggles and rubber gloves when working with electrolyte.**
- **Neutralize acid spills with baking soda and water solution.**

To fill (activate) battery with electrolyte (if battery has been shipped dry):

1. Remove the battery hold down bar, disconnect the battery cables and lift the battery out of the tray.

**IMPORTANT:** Battery must be removed from the mower before filling with electrolyte.

**IMPORTANT:** Obtain and use only battery grade sulfuric acid electrolyte with a 1.265 specific gravity to activate the battery. **DO NOT** use water or any other liquid during initial activation.

2. Remove the filler caps and carefully fill each cell until the electrolyte is just above the plates.

# Assembly Instructions

3. After the battery is filled with electrolyte, replace the filler caps and charge the battery. Refer to *Battery Charging*.

## Battery Charging

### **DANGER**

#### **BATTERIES PRODUCE EXPLOSIVE GASES**

- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open after the battery is filled with acid (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

1. Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.
2. After charging the battery, adjust the electrolyte level to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].

**IMPORTANT: DO NOT** overfill the battery. Electrolyte will overflow through the vented caps onto parts of the machine and **WILL** result in severe corrosion.


3. Install battery.

## Battery Installation

Install the battery in the mower as shown in **Battery Installation** photo. Connect the positive and negative cables to the proper battery terminal (**red cable and boot connects to the Positive (+) terminal**). Slide the rubber boot up and over the battery post, making sure it covers the post completely **to prevent an electrical short**.

### **WARNING**

**Make sure the battery cap vents are open. Improper venting of the battery COULD cause a battery explosion.**



**Battery Installation**

## Mower Deck Assembly


### *Deck Caster Wheels Installation*

1. Remove the bolt, nut, axle spacer tube, and spacer washers from each deck caster wheel fork.

**NOTE:** Spacer washers are used only when the optional semi-pneumatic deck wheels (8.25 x 2.75) are installed.

2. Fit the axle spacer tube through the wheel hub, position the spacer washer on each side of the hub (if used), and fit the assembly into the wheel fork.
3. Insert the 3/8-16 x 4-1/2 in. bolt through the wheel fork with the bolt head to the outside and install the 3/8-16 in. KEPS nut.
4. Tighten the bolt and nut until the axle spacer tube bottoms against the inside of the wheel fork (will not turn) while the wheel and spacer washers (if used) spin freely without binding.

# Assembly Instructions




## Deck Caster Wheel Installation

**NOTE:** If semi-pneumatic wheels are installed, make sure the spacer washers fit over the spacer tube and are not caught between the fork and the end of the tube. The washers should move freely on the axle spacer tube.

- Grease the caster wheel bearings and caster pivot bearings - one grease fitting for each wheel and each pivot.

## Deck Discharge Chute Installation (GHS Rear Discharge Models Only)

Mount the discharge chute hinge on top of the deck discharge opening using the 1/4-20 x 1/2 in. socket button head bolt and 1/4-20 ESNA nut. Position the bolt with the head inside of the chute and the nut on the outside.



## Discharge Chute and PTO Shaft Guard Installation on Rear Discharge Deck


## Deck Discharge Shield Installation (Side Discharge Models Only)

Attach the deck side discharge shield by positioning the shield hinge lug in **front** of the deck mount and fastening with two 3/8-16 x 1-1/4 in. bolts, 3/8-16 ESNA nuts, and 3/8 in. wave spring washers. The wave washers fit between the two hinging surfaces. Tighten the nuts until the shield moves freely but is not loose.



### WARNING

**DO NOT** operate the machine without the grass deflector chute attached and in the lowest possible position.



## Discharge Shield Installation on Side Discharge Deck

## PTO Shaft Guard Installation

Position the shaft guard as shown and mount with two 1/4-20 x 1/2 in. bolts.

## Mower Deck Installation on Tractor

### Deck Installation

- Lightly grease each deck support arm (2) on the tractor. Refer to **Mower Deck Installation** photo on next page for location of deck support arm.
- Engage the deck carrier frame tube sockets on the tractor support arms (refer to **Discharge Chute and PTO Shaft Guard Installation** photo for socket location). Slide the deck onto the support arms: all the way if SD equipped model, approximately 3 in. (76 mm) if GHS equipped model.

# Assembly Instructions


**NOTE:** When installing the DSD62 Mower deck, make sure to retract the dolly wheel after mounting the deck on the tractor.

3. If the deck is rear discharge (GHS equipped model), the rear discharge chute will need to be **aligned** and connected to the blower inlet during the last 2 in. (51 mm) of slide action on the support arms.


**NOTE:** Raising the mower body may be helpful in fitting and guiding the deck chute into the blower.

4. Install the hitch pin through the hole on the end of each support arm to lock the deck in place (refer to **Deck Counterweight Spring Installation** photo). Two (2) hitch pins are included in the owner's packet of materials.
5. Connect the mower deck PTO drive shaft assembly to the tractor with the splined quick disconnect coupler. This coupler simplifies shaft alignment and installation.
  - a. Use the arrows on the shaft and tube to align and slide the PTO quick coupler onto the deck rectangular shaft.
  - b. Reaching under the tractor, pull the ring back on the coupler, slide onto the spline shaft on the tractor, and release the ring.

**IMPORTANT:** To prevent damage to the mower, make sure the PTO shaft assembly is securely locked on the tractor, with the locking balls fully seated in the groove and the ring in the fully forward position (refer to the **Coupler Ring "Locked" Position** photo). After installation, pull on the shaft to check for security.




**Installing PTO Quick Coupler**



**Coupler Ring "Locked" Position**

6. Raise the front mower body (instead of lifting the front of deck) and clip the counterweight springs to the receptacle on front of body. Lower the front body to tension the springs.



**Mower Deck Installation (PTO Shaft Connection)**

7. With the counterweight springs connected, the weight on the deck caster wheels should be 15 to 25 lb (6.8 to 11.3 kg). Check this weight by lifting on the front of the deck carrier frame. If required, the spring tension can be adjusted by tightening or loosening the elastic stop nuts located underneath the lower spring hook. Refer to **Deck Counterweight Spring Installation** photo.



# Assembly Instructions



**Deck Counterweight Spring Installation**

## Deck Leveling

1. Position mower on a smooth, level surface. Set the cutting height to the highest position - 4 in. (102 mm) - for easy access under the deck to measure blade height. Refer to **ADJUSTING CUTTING HEIGHT** in **Operating Instructions**.


**NOTE:** A block of wood cut **4 in. (102 mm)** high is a convenient gauge to measure blade height above ground during the leveling process.

## **WARNING**

**The machine must be shut off during this procedure.**

2. Check the side-to-side level. **Rotate each blade sideways** and measure the distance from blade tip to ground on each side. If measurements vary more than 1/8 in. (3 mm), add a washer shim under the deck support pins on the low side to level the deck.
3. Check the front-to-rear level. **Rotate the blades to point forward.** Measure the distance from blade tip to ground on the front and rear. The rear of the blade should be 1/8 to 1/4 in. (3 to 6 mm) higher than the front of the blade; shim the rear (or front) deck support pins equally to achieve **at least** 1/8 in. (3 mm) difference.

**NOTE:** The mower deck and support frame are jig welded; within normal tolerances, very little, if any, shimming should be required to level the deck. Tire pressure will influence the levelness of the deck. Check the tire pressure as a possible cause of the deck not being level.



**Deck Leveling**

# Assembly Instructions

## PREOPERATING CHECKLIST

Before operating the mower for the first time, and as a routine before daily operations, it is important to make sure the mower is properly prepared and ready for operation. The following is a list of items to be checked. (For a mower with frequent operation, some of these items will not need to be checked every day, but the operator should be aware of the condition of each.)

For proper fuels and lubricants for your mower model refer to **Specifications**.

### FILL FUEL TANK

Fill the fuel tank with clean, fresh fuel. Refer to **Specifications** for the proper fuel to be used in each model. For Model MDD, clean diesel fuel is particularly important since contaminated fuel will damage the fuel injectors and injection pump.

**NOTE:** For Model MDD, an electric fuel pump makes it unnecessary to bleed (purge out air bubbles) the diesel fuel injection system when initially fueling an empty fuel tank.



## DANGER

Handle gasoline or diesel fuel with care. Gasoline is highly flammable and its vapors are explosive. Use safe refueling procedures:

- **DO NOT** fill fuel tank with the engine running.
- If the engine is hot, allow to cool before refueling.
- Use an approved fuel container.
- Fuel the mower outdoors.
- **DO NOT** smoke while refueling.
- Avoid spilling fuel; use a funnel or spout.
- **DO NOT** overfill the fuel tank; fill up to about 1 in. (25 mm) below the top of tank.

**IMPORTANT: DO NOT** permit dirt or other foreign matter to enter the fuel tank. Wipe dirt from around the filler cap before removing. Use a clean fuel storage container and funnel.

**IMPORTANT: DO NOT mix oil with gasoline.** For Model MDG, always use fresh, automotive grade gasoline. **DO NOT** use premium, white, or high-test gasoline. **DO NOT** use additives, such as carburetor cleaners, deicers, or moisture removing agents. **DO NOT** use gasoline blended with methyl alcohol.

### CHECK ENGINE CRANKCASE OIL LEVEL

Check the engine crankcase oil level before use and **after each 5 hours** of continuous operation. Refer to **LUBRICATION** for *Checking Engine Crankcase Oil Level* in **Maintenance Instructions**.

### CHECK AND SERVICE ENGINE AIR CLEANER SYSTEM

- Check and clean Cyclone precleaner.
- Remove the air cleaner cover. Check and clean the dust cup.
- Check cleanliness and security of the air filter element (clean air filter **every 100 hours**). For detailed procedures, refer to **CLEANING** the **Engine Air Cleaner System** in **Maintenance Instructions**.

### ADJUST CARBURETOR

For Model MDG (initial start-up only), refer to **ADJUSTMENTS** of **Carburetor-Model MDG** in **Maintenance Instructions**.

### CHECK ENGINE COOLING SYSTEM

- Check the radiator air intake screen to make sure the screen is clean and free of obstruction. Also, the radiator cooling fins should be inspected and cleaned if there is any buildup of dirt or debris. (Remove the intake screen assembly to inspect and clean.)
- Check the coolant levels in the radiator and overflow tank. If additional coolant is needed, refer to **CHECKING/SERVICING** the **Engine Cooling System** in **Maintenance Instructions**.

# Assembly Instructions

## **WARNING**

**DO NOT** remove the radiator pressure cap when engine is hot.

- Check engine fan belt.

CHECK GEAR AXLE OIL LEVEL

Refer to **Gear Axle Lubrication** in **Maintenance Instructions**.

INSPECT FOUR (4) DRIVE BELTS

Engine PTO Drive, Jackshaft Drive, Hydrostatic Ground Drive, and GHS Blower Drive (if equipped).

CHECK HYDROSTATIC TRANSMISSION OIL LEVEL

Refer to **LUBRICATION** for *Checking Hydrostatic Transmission Fluid Level* in **Maintenance Instructions**.

CHECK BATTERY ELECTROLYTE LEVEL

Refer to **CHECKING/SERVICING** the **Battery** in **Maintenance Instructions**.

CHECK FUNCTIONS OF INSTRUMENT PANEL AND WARNING HORN

Turn the ignition key to the **RUN** position. Voltmeter, Oil Pressure Light, and Warning Horn should all operate, indicating normal function.

CHECK TIRE PRESSURE

Deck Caster Wheel = 20 PSI (137 kPa)


Drive = 15 PSI (103 kPa)

Rear = 20 PSI (137 kPa)

CHECK AND CLEAN GRASS BUILDUP UNDERNEATH MOWER DECK (and inside GHS blower, if equipped)

Refer to **CLEANING** the **GHS Blower** in **Maintenance Instructions** for blower cleaning information.

**NOTE:** Mower deck is secured in raised position for cleaning and changing blades by hooking the deck lift rod into the body bracket below the counterweight spring clip. The rod is hinged and is stowed along the footrest of the deck carrier frame. A hitch pin on the end of the rod is used to secure it in place with the deck raised.



**Deck Secured in UP Position**

## **DANGER**

**Never operate cutter blades with deck in raised position because it is hazardous.**

CHECK MOWER BLADE CONDITION, SHARPNESS, AND SECURITY OF MOUNTING

The blade mounting nut should be tightened to 60 ft-lb (81.3 N-m). If blade sharpening is required, refer to **CHECKING/SERVICING** for **Sharpen Mower Blades** in **Maintenance Instructions**.

ADJUST MOWER CUTTING HEIGHT, IF REQUIRED

Position the hitch pins in the four deck support pins. Refer to the "Cutting Height Adjustment" decal on the deck gearbox cover.

PERFORM ANY ADDITIONAL PROCEDURES called for on the **MAINTENANCE SCHEDULE CHART** in **Maintenance Instructions**.

# Operating Instructions

## CONTROL IDENTIFICATION, LOCATION, AND FUNCTION

### Operating Controls


 **CAUTION**

Before operating the mower, become familiar with the location and function of all operator controls. Knowing the location, function, and operation of these controls is important for safe and efficient operation of the mower.

### Engine Choke


The choke control knob (Model MDG only) is located just to the rear of the instrument panel on the left hand side. To start a cold engine, pull the choke control to the **ON** position. After the engine starts, push the choke control in toward the **OFF** position, keeping enough choke to allow the engine to run smoothly as it warms up. As the engine warms up, move the choke to the **OFF** position. A warm engine requires little or no choke for starting.

**IMPORTANT:** Make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.



Operating Controls

# Operating Instructions



**Choke and Throttle Location - (MDG)**

## *Engine Throttle*

The throttle is used to control engine speed. Moving the lever **forward** toward the **FAST** position **increases** engine speed; moving it **backward** toward the **IDLE** position **decreases** engine speed.

## *Forward Speed Control (FSC)*

Forward Speed Control (FSC) has two functions: One is to set forward travel speed, and the other is to establish the **NEUTRAL-PARK** position. When the FSC lever is moved into the **FORWARD** position, a friction lock holds any forward speed setting from 0 to 5 mph (0 to 8 km/h). The ground speed is proportional to the lever position; the further the lever is advanced forward, the faster the tractor moves. It is not necessary to hold the FSC in position since the friction lock maintains the selected lever position. Pulling back on the steering levers overrides the FSC setting and slows or stops forward travel. Releasing the steering levers allows the tractor to resume forward travel at the speed set by the FSC lever. To stop and park the machine, the FSC lever is moved backward to the **NEUTRAL-PARK** position.

**NOTE:** A safety interlock switch system requires the operator to be in the seat before the FSC lever can be moved into gear (otherwise the engine will stop).

## *Steering Levers*

Each drive wheel is controlled by its own independent steering lever, for both steering function and **FORWARD/REVERSE** motion. The FSC lever sets the maximum forward speed, and also sets the forward position of the steering levers. The steering levers operate **only with a backward pulling** movement of the lever, which causes the drive wheel for that lever to first slow down, stop, and then reverse with a full backward lever stroke. The levers are released to the **FORWARD** position for "straight-ahead" ground travel.

**NOTE:** Pushing forward on the steering levers will not cause **any** change in tractor motion - there will be no steering lever reaction and there will be no machine damage.

## *Blade Clutch (PTO)*

The blade clutch lever has two positions. Pulling the lever **UP engages** the PTO that drives the mower blades. Pushing the lever **DOWN disengages** the PTO and engages the blade brake.

**NOTE:** On GHS equipped models, the Powerfil motor and Grass-Pak full signal switch are activated by engaging the blade clutch. Refer to **Using the GHS Catcher** in this section for a complete description of GHS operation.

## *Parking Brake*

The parking brake functions by locking a pin into the hydrostatic transmission pinion gear teeth. Moving the lever **FORWARD engages** the parking brake; moving the lever **BACKWARD releases** the brake.

**IMPORTANT:** Stop the tractor completely before engaging the parking brake. The parking brake uses a positive mechanical lock similar to the **PARK** position on an automotive automatic transmission. If the tractor is moving when the brake is engaged, it will result in sudden stoppage and possible internal damage to the axle drive.

**NOTE:** If pressure on the parking brake pin (e.g. parked on a hill) makes it impossible to release the parking brake with the parking brake lever, move the mower gently forward or backward to release the pin.

# Operating Instructions

## Front Body Latch Release


The front portion of the tractor body hinges forward for maintenance access and is latched down in the **OPERATING** position. To raise the body, move the latch release forward.



**Front Body Latch Release**

## Transmission Lockout Levers

The transmission lockout levers disengage the hydrostatic transmissions. By **lifting** the lever on top of the transmission and locking it into place with the lockout cam, the hydrostatic transmissions are released to permit freewheeling. By releasing the cam and **lowering** the lever, the transmissions are engaged for normal operation. The transmission lever in the **LOCKOUT** position is used to enable moving the machine without the engine running (e.g., for service). Refer to **TRANSMISSION LOCKOUT** in this section for operating instructions.




**Lockout Lever Location**


**NOTE:** The transmission plunger on the side of the transmission case (activated by the **LOCKOUT LEVER**) must be completely released during operation of the mower, otherwise operation of the transmission will be erratic.

## Cold Start Lever (Jackshaft Drive Belt Release)

The cold start lever is used for starting the machine in cold weather [below 40° F (4° C)]. Pulling the lever **DOWN disengages** the jackshaft drive belt. When the jackshaft drive belt is released, the hydrostatic transmissions are removed from the engine starter cranking load.




**Cold Start Lever  
Normal Operating Position**



**Cold Start Lever  
Cold Start Position**

# Operating Instructions


(The Forward Speed Control also Establishes the **NEUTRAL-PARK** Position of the Steering Levers.)



**MDD Operating Controls (Top View from Drivers Point of View)**

# Operating Instructions

(The Forward Speed Control also Establishes the **NEUTRAL-PARK** Position of the Steering Levers.)




**MDG Operating Controls (Top View from Drivers Point of View)**



# Operating Instructions

## Instrument Panel

This illustration shows the configuration of the **switches and indicators** located on the instrument panel. For Model MDG, the glow plug indicator is not installed and the ignition switch does not function in the glow plug position.



Instrument Panel

# Operating Instructions

## Voltmeter

The voltmeter displays battery and charging system voltage. An indication of low or high voltage (the red area) indicates an **electrical system failure**. The cause of the failure should be determined and corrected.

## Water Temperature Gauge

The water temperature gauge monitors engine **cooling system temperature**. If engine coolant temperature exceeds 230° F (110° C), an overheat condition exists; the water temperature **light will come on** and the **warning horn will sound**.

### **WARNING**

**If engine cooling system overheating is indicated, continued operation of the engine, even for a short time, COULD result in fire, risk of personal injury, and severe damage to equipment.**

## Oil Pressure Warning Light

The oil pressure warning light indicates that engine oil pressure is below the safe operating level [below 7 PSI (48 kPa)]. This **light (and warning horn)** will come on when the ignition is turned **ON**, but should go off after the engine is started. If the light fails to come on when the ignition switch is turned **ON**, it could indicate a burned out bulb. If the light comes on during engine operation, stop the engine immediately and correct the source of the problem before further engine operation.

**IMPORTANT:** Continued operation of the engine with an illuminated oil pressure light **MAY** cause severe engine damage (if a low oil pressure condition exists).

## Water Temperature Warning Light

The water temperature warning light indicates that engine coolant temperature is above the safe operating limit and the **engine is overheating**. If this light comes on, there may be a problem with:


- Radiator cooling air flow (material packed into radiator cooling fins, clogged air intake screen)


- Low coolant quantity in cooling system
- Engine fan belt
- Thermostat function

Stop the engine and correct the problem before further operation.

**IMPORTANT:** Continued operation of the engine with an illuminated water temperature warning light **MAY** result in severe engine damage.

## Ignition Switch

The ignition switch is used to start and stop the engine (and preheat the diesel engine on Model MDD). The switch has four positions:  is the glow plug preheat position (not used on Model MDG); "O" is the **OFF** position; **RUN** is the position the key returns to after starting; "S" is the **START** position. When starting the engine, turn the key clockwise to the "S" position. Do not hold the key in the "S" position longer than 10 seconds. If the engine does not start, return the key to the "O" position for at least 60 seconds before making a restart attempt. Prolonged cranking can damage the starter motor and shorten battery life. Release the key when the engine starts, and it will return to the "RUN" position. To stop the engine, rotate the key counterclockwise to the "O" position.



**Ignition Switch**

## Light Switch (For Optional Lights)

Operates headlights (when installed).

# Operating Instructions

## Hourmeter

The hourmeter displays **operating time** accumulated while the ignition switch is in the **ON** position.

## Circuit Breakers

Two manual reset circuit breakers are located on the instrument panel. Each has a button that pops out if the circuit breaker trips. The 10 amp circuit breaker protects the circuits to the headlights, fuel valve solenoid (Model MDD), safety switch relays and time delay module, and GHS. The 5 amp circuit breaker protects the instrument panel circuits to the meters, warning lights, and warning horn.

## Glow Plug Indicator - Model MDD

The glow plug indicator glows red during engine pre-heat to indicate when the engine is ready to be started.

## Warning Horn

The warning horn sounds to alert the operator that an **unsafe engine condition** is being indicated - when engine coolant temperature is too high or engine oil pressure is too low. If the horn sounds, check the indicator lights and water temperature gauge and correct the problem before further operation.

## STARTING THE ENGINE - MODEL MDD (DIESEL)

### **CAUTION**

**Before operating the mower, read and understand all Safety Instructions and Operating Instructions.**

### **WARNING**

**NEVER run the engine in an enclosed or poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.**

**IMPORTANT: DO NOT** use starting fluids. This will damage the engine.


1. Before attempting to start the engine, make sure the operator is in the seat, the Forward Speed Control is in **NEUTRAL-PARK** position, and the blade clutch and parking brake are **DISENGAGED**.

**NOTE:** Release parking brake to prevent extra load on the starter if the transmission neutral is slightly out of adjustment.

### **CAUTION**

**A safety interlock switch system PREVENTS CRANKING the engine with either the Forward Speed Control or the blade clutch (PTO) out of neutral. If the engine cranks otherwise, the safety system is not working and should be repaired or adjusted before operating the mower. DO NOT disconnect safety switches; they are for the operator's protection.**

**NOTE:** For starting in cold weather [below 40° F (4° C)], use the cold start lever to release the jackshaft drive belt and remove the hydrostatic transmission from the starter cranking load. After the engine has been started and warmed up, raise the lever to re-engage the jackshaft drive belt.



**Jackshaft Drive Belt Release**

# Operating Instructions

2. Turn and hold the ignition key in the **PREHEAT** position to preheat the engine glow plugs. Watch the glow plug indicator; when it begins to glow red, the engine is ready to be started. The time required is approximately 15 to 30 seconds, depending on engine temperature.
3. Move the throttle 1/4 to 1/2 open (toward **FAST**) and turn the ignition switch to the **START** position to start the engine. Release the key to the **RUN** position as soon as the engine starts.

**IMPORTANT: DO NOT** crank the engine continuously for more than 10 seconds at a time. If the engine does not start, turn the key to the **OFF** position and allow a 60 second cool-down period between starting attempts. Failure to follow these guidelines can damage the starter motor and shorten battery life.

**TROUBLESHOOTING NOTE:** If the engine cranks but does not start, check the following:

- The fuel valve solenoid is operating. Look at the exhaust pipe when cranking the engine - no smoke indicates no fuel is reaching the cylinder. If the solenoid is not operating, refer to **CHECKING/SERVICING the Fuel Valve Solenoid-Model MDD** in **Maintenance Instructions**.
  - The glow plugs are operating. Look at the exhaust pipe when cranking the engine - white smoke indicates improper glow plug operation and inadequate preheat. Consult the Kubota Workshop Manual to check glow plug function.
4. After the engine starts, make sure the oil pressure light goes off. If not, stop the engine immediately and find the cause of the problem. Make sure the oil pressure light is off prior to engaging the mower blades and beginning operation.

## STARTING THE ENGINE - MODEL MDG (GASOLINE)

### **CAUTION**

**Before operating the mower, read and understand all Safety Instructions and Operating Instructions.**

### **WARNING**

**NEVER** run the engine in an enclosed or poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.


1. Before attempting to start the engine, make sure the operator is in the seat, the Forward Speed Control is in **NEUTRAL-PARK** position, and the blade clutch and parking brake are **DIS-ENGAGED**.

**NOTE:** Release parking brake to prevent extra load on the starter if the transmission neutral is slightly out of adjustment.

### **CAUTION**

A safety interlock switch system **PREVENTS CRANKING** the engine with either the Forward Speed Control or the blade clutch (PTO) out of neutral. If the engine cranks otherwise, the safety system is not working and should be repaired or adjusted before operating the mower. **DO NOT** disconnect safety switches; they are for the operator's protection.

**NOTE:** For starting in cold weather [below 40° F (4° C)], use the cold start lever to release the jackshaft drive belt and remove the hydrostatic transmission from the starter cranking load. After the engine has been started and warmed up, raise the lever to re-engage the jackshaft drive belt.



**Jackshaft Drive Belt Release**

# Operating Instructions

2. Move the choke lever to the **ON** position and move the throttle 1/4 to 1/2 open (toward **FAST**). Turn the ignition switch to the **START** position to start the engine. Release the key to **RUN** position as soon as the engine starts.

**NOTE:** The choke may not be required if the engine is warm.

**IMPORTANT:** If the engine fails to start after approximately 10 seconds of cranking, the engine should be checked before further cranking. Turn the key to the **OFF** position and allow a 60 second cool-down period between starting attempts. Failure to follow these guidelines can damage the starter motor and shorten battery life.

3. After the engine starts, make sure the oil pressure light goes off. If not, stop the engine immediately and find the cause of the problem. Make sure the oil pressure light is off prior to engaging the mower blades and beginning operation.
4. Gradually move the choke to the **OFF** position, keeping enough choke on to allow the engine to run smoothly as it warms up. As soon as possible, move the choke to the **OFF** position.

**IMPORTANT:** Make sure the choke is in the **OFF** position during normal engine operation; running with the choke in the **ON** position **CAN** damage the engine.

## ADJUSTING GROUND SPEED AND STEERING

**IMPORTANT:** If the DSD62 Mower deck is installed on the tractor, make sure the dolly wheel is retracted **BEFORE** moving.



### CAUTION

Learn to **START, STOP, and MANEUVER** the mower in a large, open area.

If the operator has not operated a machine with **LEVER STEERING OR DUAL HYDROSTATIC TRANSMISSIONS**, steering and ground operation should be learned and practiced until the operator is completely comfortable handling the machine **BEFORE ATTEMPTING TO MOW**.



### DANGER

Keep feet on footrests all times when the machine is moving.

### Beginning Recommendations are:

◆ Learn operation of the mower in an open area away from buildings, fences, and obstructions. Learn operation on flat ground **BEFORE** operating on slopes.

◆ Start maneuvering the mower with **SLOW** engine speed and **SLOW Forward Speed Control** setting until familiar with all operating characteristics.

◆ Remember it is not necessary to hold the steering levers forward (a unique Walker feature); always **PULL** on the levers for steering or for reverse motion of the mower.

◆ Learn to operate the mower with your left hand on the steering levers and right hand on Forward Speed Control. The use of two hands on the steering levers tends to cause overcontrol.

◆ Learn to operate the steering levers with smooth action. Jerky movements are hard on the transmission and lawn. For sharp turns, do not allow the inside wheel to stop and twist on the grass. Pull the steering lever controlling the inside wheel into reverse for a smooth “rolling” turn (one wheel rolling forward while the other rolls backward).

◆ Practice maneuvering the mower until you can make it go exactly where you are aiming.

◆ Remember, for an emergency stop, or in case of loss of control, machine movement can always be stopped quickly by pulling the Forward Speed Control into the **NEUTRAL-PARK** position.

# Operating Instructions

1. Move the FSC out of **NEUTRAL-PARK** position to the desired forward speed. **DO NOT** hold forward on steering levers. It is not necessary to hold the FSC lever in position since a friction lock maintains the selected lever position (and forward travel speed).

**NOTE:** If the FSC lever will not stay in the selected position, the friction lock needs to be adjusted. Refer to **ADJUSTMENTS of Forward Speed Control Friction Lock** in **Maintenance Instructions**.

2. Steer by pulling the lever on the side of desired direction of turn, e.g., pull the **LH** lever to **turn left**. To minimize the possibility of overcontrol, use only one hand on both steering levers.



**Correct Operator Hand Position on the Controls**

3. Reverse direction of the mower by pulling both levers backward.

**NOTE:** Smooth action on the steering levers will produce smooth mower operation. Remember to keep the engine and ground speed slow until learning the control response.

4. The FSC may be adjusted forward for faster ground speed and backward for slower ground speed. When mowing, ground speed should be adjusted to match the load on the cutter blades, i.e., as the engine pulls down in heavy cutting, pull back on the FSC lever to reduce ground speed. Adjusting ground speed helps maintain a balance between engine power and blade speed for high-quality cutting action.

5. Stop ground travel by pulling both steering levers backward to the **NEUTRAL-PARK** position (tractor not moving) and then moving the FSC lever to the **NEUTRAL-PARK** position.

**NOTE:** If the tractor creeps forward or backward with the FSC lever in the **NEUTRAL-PARK** position, the transmission control needs to be adjusted. Refer to **ADJUSTMENTS of Transmission Control** in **Maintenance Instructions**.

## ENGAGING THE MOWER

1. Set the engine throttle at about 1/3 speed. **Do not attempt to engage the blade clutch at high engine speeds.** This will drastically shorten drive belt life. Use only moderate engine speed when engaging the blade clutch.
2. Pull the blade clutch lever **SLOWLY** up to engage the mower blades.

### **CAUTION**

A safety interlock switch (seat switch) will cause the engine to stop if the blade clutch is engaged and the operator is not in the seat. The function of this switch should be checked by the operator raising off the seat and engaging the blade clutch; the engine should stop. If the switch is not working, it should be repaired or replaced before operating the mower. **DO NOT** disconnect the safety switches; they are for the operator's protection.

**IMPORTANT:** **DO NOT** engage the blade clutch when transporting the mower across drives, sidewalks, loose materials, etc. **DO NOT engage the blade clutch with the PTO shaft disconnected** (the mower deck removed from tractor).

# Operating Instructions



**Blade Clutch Engaged**



**Blade Clutch Disengaged**

## **CAUTION**

If the cutting blades strike a stationary object while mowing, stop the mower immediately, disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG), lift the deck, and inspect the deck and blades thoroughly for damage. Make sure that the blade timing has not been disturbed (the blades should be at 90 degrees to each other). Refer to **REPLACING/REPAIRING the Blade Overload Shear Bolts** in Maintenance Instructions if blades are out of time. Also, make sure the blade retaining nuts are torqued to 60 ft-lb (81.3 N·m).

## **STOPPING THE MACHINE**

1. Slow the engine to idle; put the throttle in the **IDLE** position.
2. Pull the steering levers to the **NEUTRAL-PARK** position and then move the FSC lever backward to the **NEUTRAL-PARK** position.
3. Disengage the blade clutch.

**IMPORTANT:** DO NOT disengage the blade clutch with high engine speed (above 1/2 throttle) since the brake action on the blade drive will cause premature wear of the brake band.

## **WARNING**

A brake stops the cutter blades (and blower on GHS equipped models) from free-wheeling within five (5) seconds after disengaging the clutch. If the brake system malfunctions and the blades do not stop within five (5) seconds, the brake should be adjusted or repaired before operating the mower. Refer to **ADJUSTMENTS of Blade Clutch (PTO)** in Maintenance Instructions.

4. Turn the ignition switch **OFF**.

## **WARNING**

Remove the key from the ignition switch when leaving the mower unattended. This will prevent children and inexperienced operators from starting the engine.

5. Engage the parking brake.

**IMPORTANT:** The hydrostatic transmissions lock to prevent the mower from rolling freely with the engine stopped. However, if the mower is parked on a slope, it is necessary to **ENGAGE** the parking **BRAKE** to prevent the mower from creeping. This is due to a small amount of slippage in the hydrostatic transmissions, especially when transmission fluid is warm.


# Operating Instructions

## ADJUSTING CUTTING HEIGHT

### **WARNING**

The engine must be stopped before adjusting cutting height. Disengage the blade clutch (PTO), stop the engine, and remove the ignition key. Wait for all movement to stop before getting off the seat.

Cutting height is adjusted by positioning the four retainer hitch pins in a series of seven vertical holes on the deck support pins. Lift handles have been provided on each end of the deck to assist in raising the deck while positioning the hitch pins. Cutting heights range from 1 in. (25 mm) [top holes] to 4 in. (102 mm) [bottom holes] in 1/2 in. (13 mm) increments.




**Cutting Height Adjustment**

## TRANSMISSION LOCKOUT

To move the mower with the engine **NOT** running (dead battery, maintenance, etc.), the hydrostatic transmissions are unlocked (released).


1. Raise the front body.
2. Lift the transmission lockout lever on both the RH and LH transmissions and secure into place with the locking cam.

3. The mower will “freewheel” with the levers in the **LOCKOUT** position. The levers must be in the highest position to completely unlock the transmissions.



**Lockout Lever - Freewheel Position**

4. After moving the mower, release the locking cam, placing the lever **DOWN** in the normal **OPERATING** position. Make sure the transmission lockout plunger on the side of the transmission case (activated by the lockout lever) is **completely released**, otherwise the transmission operation will be erratic.



**Lockout Lever - Normal Operating Position**



# Operating Instructions

## RECOMMENDATIONS FOR MOWING

**IMPORTANT:** Operate the engine at **full speed** when mowing, to allow the engine to produce full horsepower and to increase efficiency of the engine cooling system.


- Keep the mower deck and discharge chute clean.
- Mow with **sharp blades**. A dull blade tears the grass (resulting in poor lawn appearance) and uses extra power (slowing the mowing speed).
- It is preferable to cut grass when it is **dry and not too tall**. Mow frequently and do not cut grass too short. (For best appearance, cut off 1/3 or less of existing grass height.)
- When mowing, operate the engine at or near **full throttle** for the best cutting action and performance of the grass handling system (GHS). Mowing with a lower engine RPM causes the mowing blade to not cut clean and tear the grass. The engine is **designed to be operated at full speed**.
- When mowing in adverse conditions (tall and/or wet grass), mow the grass twice. Raise the mower to the highest setting - 4 in. (102 mm) - for the first pass and then make a second pass cutting to the desired height.
- Use a **slow** setting on the FSC for **trimming** operations.
- Make sure the mower is **leveled properly** for a smooth cut. Refer to *Deck Leveling in Assembly Instructions*.
- Use an alternating **stripe mowing pattern** for **best appearance** and vary the direction of the stripe each time the grass is mowed to avoid wear patterns in the grass.
- Avoid damage to the grass by slipping and skidding of the drive tires. Use **smooth control movements** of the steering levers since the hydrostatic transmissions are "power boosted controls" and jerking the levers can easily slip the tires. For sharp turns, do not allow the inside wheel to stop and twist on grass; pull inside steering lever into reverse for a smooth "rolling" turn (one wheel rolling forward while the other rolls backward).

- When using a side discharge mower deck, the side discharge shield **must not be removed** and must be kept in the lowest possible position to deflect grass clippings and thrown objects downward. Orient the side discharge away from sidewalks or streets to minimize cleanup of clippings. When mowing close to obstacles, orient the side discharge away from obstacles to reduce the chance of damage to property by thrown objects.



**Side Discharge Shield in Lowest Position**


- When operating on a slope, **reduce speed and use caution** to start, stop, and maneuver. Avoid sharp turns or sudden changes in direction. The **maximum recommended side slope operating angle is 20 degrees or 33% grade**.



**Maximum Recommended Side Slope**

# Operating Instructions

## GRASS HANDLING SYSTEM (GHS) GHS Model Only



GHS Flow and Components

# Operating Instructions

## General Information

The Grass Handling System (GHS) consists of a rear discharge mower deck connected to a 10 in. (25 cm) blower and a rear mounted grass catcher with 7.0 bushel (246 liters) capacity. The GHS blower operates any time the mower blade clutch is engaged and moves grass through the rear discharge deck chute into the grass catcher. Blower airflow is exhausted out the back of the grass catcher, through a filtering screen. When the grass catcher is full and needs to be emptied, a **“full” signal horn alerts the operator**. When the “full” signal horn sounds, it is important to stop mowing to prevent overfilling and clogging of the blower system.


**IMPORTANT:** Normally, the GHS blower operates with no maintenance or cleaning required. However, under certain operating conditions, the inside of the blower housing may accumulate a deposit of dirt, causing wear and binding of the blower wheel. Normally, dirt buildup occurs when mowing a **combination of dirty and damp grass**, especially in the springtime. When operating in these conditions, **check the blower wheel frequently** for binding and clean the blower housing as required. Refer to **CLEANING the GHS Blower** in **Maintenance Instructions**.

**NOTE:** In Autumn, when using the GHS mower to vacuum leaves, it is recommended to raise the **front** of the mower deck 2 to 3 notches [1 to 1-1/2 in. (25 to 38 mm)] **higher than the rear**. This will avoid “bulldozing” leaves, particularly when the leaves are piled in a thick layer. To make this adjustment, the hitch pins in the **two (2) front** deck support pins are repositioned 2 to 3 notches higher while leaving the rear pins in their original position.

### **DANGER**

**NEVER** operate the GHS catcher with the back door open. Objects may be thrown out the back of the catcher with sufficient force to cause serious injury to bystanders or property damage.

**NOTE:** When a side discharge or mulching mower deck is installed on the GHS model, a blower intake cover should be installed in the blower intake tube. This cover “unloads” the blower and seals the intake to effectively eliminate power loss and blower noise when the blower is not being used.



**Blower Intake Cover**

### **DANGER**

#### **ROTATING BLOWER BLADES**

**NEVER** operate the GHS blower with the blower discharge chute uncovered (grass catcher in the dump position) since dangerous projectiles may be thrown. **NEVER** put hands into the blower discharge chute for any reason. Use a stick or similar instrument to remove any material if clogging has occurred.

### **CAUTION**

**NEVER** leave grass clippings in the grass catcher after mowing. Damp clippings generate heat as they decompose. This **MAY** cause spontaneous combustion.

# Operating Instructions

## Clogging Checklist


In case of clogging, there will be a **distinct change in the sound** of the blower, i.e., the blower sound will stop. Also, the mower deck will begin to leave a trail of grass clippings. When this occurs, stop the engine, disconnect the electrical plug on the fuel shut-off solenoid (Model MDD) or the spark plug wires (Model MDG), and make **sure all movement has stopped before attempting to unclog**.



**NEVER** place hands under the mower deck or in the GHS blower discharge chute. Use a stick or similar tool to remove any clogged material.

Normally, any clogging will first develop at the back of the mower deck in the discharge opening into the blower chute. Clogging at this point **does not indicate a particular problem in this part of the system, but is a symptom of something restricting the flow of material** throughout the entire system. The following list of items should be checked if a pattern of clogging begins to develop. All of these items are capable of causing clogging at the back of the deck.

- Check to see if the RH and LH mower blades are installed **for the correct rotation** - install blades so the cutting edges move toward each other.



**Blade Rotation for GHS Mower Deck  
(view from underneath)**

- Check the amount of **flat section** remaining at blade tip. This is the area that is ground away (removed) when the blades are sharpened. If too much of the flat section is removed, the “air lift” performance or “shovel” effect of the blade deteriorates to the point that discharge of grass clippings into the blower chute is marginal. Replace cutter blades if less than 3/4 in. (19 mm) flat section remains at the blade tip.

- Check that the interior of the deck housing and baffling is reasonably **clean and free of grass and dirt buildup**. While some degree of material buildup can be tolerated, a point is finally reached where the flow of air and grass clippings is restricted.

**NOTE:** One condition that quickly causes a buildup of material in the deck housing is mowing grass and/or weeds which are “juicy.” The material collects under the deck with sticky, green juice. Clover and weeds are especially a problem. The mower deck will need to be cleaned frequently when operating in these conditions.

- Check the deck cutting height setting. When working in thick, tall grass, **lower deck settings [1 to 2 in. (25 to 51 mm) cutting heights] tend to restrict airflow** from moving into and under the deck. Raising the deck cutting height will significantly increase airflow and reduce clogging when working in thick, tall grass.

- Check the interior of the chute connecting the mower deck to the blower for **smoothness and freedom from obstruction**.

- Check the blower wheel for **bent blades and excessive clearance** between the blade tip and the blower housing. A clearance greater than 1/8 in. (3 mm) will cause a significant loss of blower performance.

- Check the blower discharge chute into the grass catcher for **smoothness and freedom from obstruction**.

- Check the elbow inside the grass catcher for a **buildup of material in the radius** of the elbow. In certain conditions (damp/dirty grass) a considerable “clump” of material can accumulate at this point, greatly restricting material and airflow.

# Operating Instructions

- Check that the **openings in the removable air exhaust screen** in the grass catcher are not plugged. If the screen is clogged, refer to **Cleaning the GHS Exhaust Screen** in this section.

Remember, anything that restricts airflow or material flow along the entire path from the mower deck to the grass catcher can cause clogging.

## Using the GHS Catcher

### *Powerfil*

The GHS catcher has an oscillating grass delivery spout (**POWERFIL**) which is designed to spread grass clippings throughout the interior of the grass catcher (even when mowing wet, heavy grass). The oscillating action may be checked by turning the ignition switch to the **ON** position and moving the blade clutch to the **ENGAGED** position. The spout should oscillate approximately 25 cycles per minute.

**NOTE:** If the grass spout fails to oscillate, the clutch switch should be checked for function (the switch closure is adjustable).

### *“Full” Signal Horn*

The GHS catcher has a **“full” signal horn** to alert the operator to **dump the catcher when it is full** (to prevent overfilling and clogging). The “full” signal horn is activated by a vane switch (Grass-Pak switch) mounted on the grass delivery spout. Oscillating action of the spout triggers the vane switch as grass begins to fill in around the spout when the catcher is almost full.

The “full” signal function may be checked by turning the ignition switch **ON**, engaging the blade clutch (engine not running), opening the catcher back door, and triggering the Grass-Pak vane by hand as it oscillates. The horn should sound as the switch is moved in both directions.



## **WARNING**

**DO NOT test the Grass-Pak switch with the engine running. Projectiles may be thrown out of the grass delivery spout, and COULD cause serious injury.**


The “full” signal horn is designed to operate (sound) when the grass catcher is **almost full**. The timing of the signal is adjustable by changing the position of the vane on the Grass-Pak switch. If the signal is coming on too soon (catcher not completely full) or too late (grass clogging in catcher spout and delivery chute), refer to **ADJUSTMENTS of GHS “Full” Signal Horn** in **Maintenance Instructions**.

**NOTE:** The horn signal should be adjusted to sound **BEFORE the catcher is completely full** to give the operator time to react and stop mowing. An indication the horn signal is coming on too late (delayed too much) is if grass clippings are falling out of the grass catcher delivery chute when the catcher is dumped.

## **Cleaning the GHS Exhaust Screen**

To remove the grass catcher screen for cleaning, open the catcher door, push forward and pull down on the grass catcher screen knobs (on either side of the screen), and slide the screen out. Use a high pressure washer or water spray and brush to clean the screen.

Keeping the catcher exhaust screen clean and open is essential to good performance of the catching system. In some mowing conditions, e.g., wet and dirty, it will be necessary to clean the screen frequently to avoid clogging the mower deck, blower, and chutes due to airflow restriction.



**Grass Catcher Screen Removal for Cleaning**

# Operating Instructions

## Dumping the Catcher

For dumping, the catcher either tailgate dumps into a disposal area or dumps into the optional dump bag. The dump bag is a **reusable** nylon fabric bag designed to conveniently move grass clippings from the catcher to a remote disposal area or container.

### Tailgate Dumping

1. Open the back door by lifting on the door handle.

**NOTE:** To prevent accidental door closure, a **safety latch locks the door open** in the fully opened position while the catcher is being dumped.

2. Tilt the catcher back to dump by lifting on the molded hand hold on the lower front corner of the catcher.
3. Lower the catcher smoothly down to the normal operating position. **DO NOT allow the catcher to drop down - the gas spring, that holds the catcher in the raised position, is not a shock absorber for lowering the catcher.**
4. Close the door by holding the door handle with the left hand and releasing the safety latch on the door hinge mechanism with the right hand. The safety latch is released by pressing in on the top of the latch. Then, smoothly close the door, working against the spring pressure that holds the door closed. **DO NOT let the door slam shut** by releasing the door before it is closed.

 **DANGER**

### PINCH POINT - SPRING LOADED DOOR

When lowering the door on the GHS catcher, depress the safety latch on the side of the catcher. **BE VERY CAREFUL** to keep hands, fingers, etc. out of the hinging mechanism and away from the door frame as the door closes. The springs that hold the door closed during operation are very powerful, and the door can slam shut with considerable force.



**Catcher Door Safety Latch**

### Using the Dump Bag

1. Open the back door by lifting on the door handle.

**NOTE:** To prevent accidental door closure, a **safety latch locks the door open** in the fully opened position while the catcher is being dumped.

2. Orient the dump bag with one of the handle straps on the bag opening facing up.



**Positioning Dump Bag on Catcher**

# Operating Instructions

- Hook the bottom of the bag over the rear bumper while lifting on the handle strap.
- Tilt the catcher back to dump into the bag by **lifting on the molded hand hold** on the lower front corner of the catcher **with the one hand** while continuing to **hold up on the bag strap with the other hand**. Refer to photos for positioning the bag and dumping.



**Dumping Catcher into Dump Bag**

- Lower the catcher smoothly down to the normal operating position. **DO NOT allow the catcher to drop down - the gas spring, that holds the catcher in the raised position, is not a shock absorber for lowering the catcher.**
- Close the door by holding the door handle with the left hand and releasing the safety latch on the door hinge mechanism with the right hand. The safety latch is released by pressing in on the top of the latch. Then, smoothly close the door, working against the spring pressure that holds the door closed. **DO NOT let the door slam shut** by releasing the door before it is closed.

## **DANGER**

### **PINCH POINT - SPRING LOADED DOOR**

When lowering the door on the GHS catcher, depress the safety latch on the side of the catcher. **BE VERY CAREFUL** to keep hands, fingers, etc. out of the hinging mechanism and away from the door frame as the door closes. The springs that hold the door closed during operation are very powerful, and the door can slam shut with considerable force.

### *Power Dump Option*

When equipped with the optional power dump system, the operator dumps the catcher while sitting in the seat. A toggle switch operating a power ram is used to raise and lower the catcher. The back door automatically opens and closes during the dump cycle.

Hold the toggle switch **UP** or **DOWN** to **RAISE** or **LOWER** the catcher. When the catcher reaches the full raised or lowered position, the power ram clutch will make a ratcheting sound. Release the toggle switch as soon as this sound is heard. **DO NOT operate the ram with the clutch ratcheting for an extended time** as this will cause extra wear on the clutch mechanism.


## **CAUTION**

The operator should be in the seat and bystanders stay clear when the power dump is operating. The power dump is used **ONLY** for tailgate dumping. Do not attempt to use the optional dump bag or any other bag with the power dump.

**NOTE:** If grass tends to hang up in the catcher after raising the catcher with the power dump, "jiggle" the steering levers and make the tractor bounce a little to unstick the grass and make it slide out of the catcher.

**NOTE:** With the power dump mechanism in the normal operating position (catcher down), the catcher can be **manually raised** for access to the engine and the catcher can be **manually dumped**.

# Operating Instructions





**CAUTION**

Maintenance procedures requiring special training or tools should be performed by a trained technician.

**Maintenance Instructions****MAINTENANCE SCHEDULE CHART - RECOMMENDED SERVICE INTERVALS - MODELS MDD AND MDG**

Service Item	Daily	25 Hours	100 Hours	200 Hours	400 Hours	Yearly	Every 2 Years	Ref. Page
Check Crankcase Oil Level	x							47
Check Coolant Level in Radiator and Overflow Tank	x							57
Clean Radiator Screen and Cooling Fins*	x							55
Clean Air Cleaner Dust Cup and Cyclone Precleaner Bowl*	x							53
Check Security of Air Filter Element	x							58
Clean Grass Buildup Under Deck	x							55
Clean GHS Exhaust Screen*	x							41
Clean GHS Blower*	x							56
Service Mower Blades	x							59
Check Functions of Instrument Panel and Warning Horn	x							23
Lubricate Grease Fittings and Oil Points*		x						48
Check PTO Gearbox Oil Level <sup>ΔΔΔ</sup>		x						51
Check Battery Electrolyte Level		x						58
Check Hydrostatic Transmission Fluid		x						52
Check Tire Pressure		x						59
Check Drive Belts (Jackshaft, Engine PTO, GHS Blower, Ground Drive)		x						60
Check Gearbox Oil Seals		x						60
Change Engine Crankcase Oil**			x					47
Change Engine Oil Filter			x					47
Clean Air Filter Element			x					54
Check Fan Belt Tension			x					58
Check/Adjust Blade Clutch (PTO)/Brake Action			x					73
Check Oil Level in Gear Axle			x					51
Clean Hydrostatic Transmission Cooling Fins			x					57
Check Radiator Hoses and Clamps				x				61
Check Fuel Lines and Clamps				x				61
Check Spark Plugs - MDG					x			60
Replace Fuel Filters - MDD					x			69
Replace Fuel Filter - MDG						x		69
Replace Air Filter Element***						x		54
Flush Radiator and Change Coolant						x		55
Service Battery						x		58
Check Engine Valve Clearance <sup>Δ</sup>						x		61
Check Fuel Injection Nozzle Pressure - MDD						x		61
Check/Adjust FSC Friction Lock						x		76
Change Gear Axle Oil <sup>ΔΔ</sup>							x	51
Change Hydrostatic Transmission Fluid <sup>ΔΔ</sup>							x	53
Replace Radiator Hoses and Clamps							x	61
Replace Fuel Lines and Clamps							x	61
Replace Ignition Wires - MDG							x	61

\* More often in extremely dusty or dirty conditions (refer to notes about air cleaner element in **IMPORTANT TIPS FOR CARE OF KUBOTA ENGINE**)

\*\* Change engine oil and filter after first 35 hours of operation of a new engine (break-in period)

\*\*\* Replace every year or after 6 cleanings

Δ Check every year or 800 hours

ΔΔ Change every 2 years or 1000 hours

ΔΔΔ Change PTO gearbox oil after first 100 hours of operation (break-in period)

## IMPORTANT TIPS FOR CARE OF THE KUBOTA ENGINE

### Fuel System

- Fuel must be clean - free from water, dirt, and organic material. Fuel contamination will greatly shorten the life of the fuel injection pump and injectors (Model MDD).
- Change fuel filters (2 on Model MDD) on a regular basis and when contamination is suspected or found in the fuel.
- Model MDD is equipped with an electric fuel pump; therefore it is normally not necessary to bleed air out of the fuel system (after running out of fuel or fuel system maintenance).
- When checking and bleeding the fuel system on Model MDD, use the air vent plug on the fuel filter and the injector pump. **DO NOT** attempt to bleed the fuel system by loosening fuel lines on the fuel injection pump as this could **damage the pump**.

### Starting

- **DO NOT use ether or any starting fluid** in the air intake. This will **damage the engine**.
- For starting in cold weather [below 40° F (4° C)], use the cold start lever to release the hydrostatic transmissions from the starter cranking load.
- Start engine with the throttle advanced off idle (1/4 to 1/2 throttle). This will aid starting, especially in cold weather.
- **Keep the battery fully charged.** (For Model MDD, the starter is cranking an engine that has a 23:1 compression ratio.)
- Match crankcase oil viscosity to the ambient temperature, allowing the engine to crank faster and start easier.

### Cooling System

- Fill the cooling system with a **pre-mixed** solution of 50/50 antifreeze (ethylene glycol) and distilled water.

**IMPORTANT:** Solution must be pre-mixed before putting it in the engine (adding pure antifreeze into the radiator may cause damage to the engine by causing overheating).

- **Maintain proper fluid levels** in the radiator and overflow tank.

- Operate the engine at full speed when mowing. This will allow the engine to produce full horsepower and move more cooling air through the radiator.

### Air Cleaner

- Use **only** Kubota air cleaner elements. Aftermarket elements may not seal in the air cleaner housing, allowing dirt to enter the engine. Also, aftermarket filters often skimp on the filtration media and require more frequent cleaning and replacement (see instructions below).
- **DO NOT overservice** or frequently “disturb” the **air filter**. A dirty air filter actually cleans better than a new one. Changing and cleaning the filter too often can actually reduce filter efficiency and increase the opportunity for traces of dust to enter the engine. Wait until the element really needs servicing as indicated by the loss of engine power and/or black smoke from the exhaust.
- Do frequently check and **empty the dust cup and precleaner bowl** (check every day in dusty conditions), but **do not** disturb the air filter element.
- When the air filter element is removed or replaced, make sure all **dust is cleaned out** of the **air cleaner housing and hose**. Use a damp cloth and wipe the interior of the canister and hose clean (a little dirt left here will be sucked into the engine and reduce engine life). When the filter is reinstalled, make sure the **element is held tight and straight** in the canister for proper seating and sealing. A light coating of grease on the element seal and wing nut rubber washer is recommended to enhance sealing action in these areas.
- Periodically check the air intake hose for cuts, nicks, etc., and the hose clamps for tightness.

### Oil

- For Model MDD, use any top quality oil with an API classification of CD or greater. **DO NOT** use oil that is rated for gasoline engines only (API SE/SF) as this will cause problems in a diesel engine.
- Single viscosity or multi-viscosity oils may be used with the viscosity matching ambient temperatures for the engine operating conditions. This will **aid starting** in cold weather and assure proper lubrication in hot weather.
- Use only Kubota oil filters. **Aftermarket filters may not seal properly** and/or have the incorrect pressure relief valve for proper lubrication.

## LUBRICATION



### WARNING

**DO NOT attempt to lubricate the machine with the engine running. Disengage the PTO clutch, shut off the machine, and remove the ignition key.**

Proper lubrication is an important maintenance procedure. It reduces wear and makes the machine quieter and easier to operate.

### Engine Oil

#### Engine Break-In Oil

No special break-in oil is required. The engine is serviced with 10W-30, Service Class CD oil from the factory. The oil should be changed after the initial engine **break-in period of 35 hours**. Thereafter, change oil **after every 100 hours** of operation.

#### Checking Engine Crankcase Oil Level

Check the engine crankcase oil level before use and **after each 5 hours** of continuous operation.

1. Park the mower on a **level surface with the engine stopped**. Also, make sure the engine is cool and oil has had time to drain into the sump (allow **at least five (5) minutes** after stopping the engine).


**IMPORTANT: NEVER** check or add oil with the engine running.

2. Before removing the dipstick, clean the area around the dipstick opening in the engine block to keep any dirt or debris out of the engine.
3. Remove the dipstick, wipe off with a clean rag, then reinsert the dipstick making sure it is pushed all the way into the engine. Remove the dipstick and check the level. The oil level should be within the safe range (within the **“A” range** on the dipstick).

**IMPORTANT: DO NOT** operate engine without sufficient oil supply in the crankcase. **DO NOT** operate with oil level below the **LOW** mark or above the **FULL** mark on the dipstick.

4. If additional oil is needed, refer to **Specifications** for proper crankcase lubricant. **Fill to the FULL mark** (oil filler located on top of valve cover).

**IMPORTANT: DO NOT** overfill crankcase (oil above **FULL** level) as this **CAN** result in engine overheating, loss of power, and possible engine damage.




Dipstick “A” Range

#### Changing Engine Crankcase Oil/Oil Filter


Change the engine crankcase oil and oil filter **after every 100 hours** of operation as follows:

1. Drain the oil while the engine is warm. If not warm from operation, start the engine and run a few minutes to warm the oil.
2. Remove the dipstick, oil filler cap, and drain plug and drain oil into a container. Be sure to allow ample time for complete drainage.



**Oil Drain Location**  
(view from left side of tractor)

3. Remove the old oil filter and wipe off the filter adapter on the engine.



**Oil Filter Location**

4. Apply a thin coating of new oil to the rubber gasket on the replacement oil filter.

**IMPORTANT:** Use **ONLY** oil filters from the engine manufacturer (Kubota 15841-32439). Aftermarket oil filters may not seal properly and/or may not have the correct pressure relief valve for proper lubrication.

5. Install the new oil filter on the engine. Turn the oil filter clockwise until the rubber gasket contacts the sealing surface, then tighten the filter an additional **1/2 turn**.

6. Reinstall the drain plug. Make sure it is tightened to 10 ft-lb (13.6 N·m).
7. Fill the crankcase with oil using only crankcase lubricants supplied by the engine manufacturer. Refer to **Specifications** in this manual or the engine owner's manual. Use the recommended oil viscosity for the expected ambient temperature. Oil with the correct viscosity will aid starting in cold weather and assure proper lubrication in hot weather. **Fill to FULL mark** on the dipstick; crankcase capacity is 3.1 quarts (2.9 liters) plus 1/2 pint (.24 liters) allowance for the new oil filter.

**IMPORTANT:** For Model MDD, **DO NOT** use oil that is rated for gasoline engines only (API SE/SF). This will cause problems with a diesel engine.


**IMPORTANT:** Check the dipstick reading before pouring in the last 1/2 pint of oil and **fill only to the FULL mark**. The oil level should never be over the **FULL** mark on the dipstick; overfilling can result in engine overheating and loss of power.

8. Start the engine and check for oil leaks around the oil filter. Stop the engine, recheck the oil level, and add oil if necessary. (When the engine is first operated with a new oil filter, the oil level will drop slightly as the filter is filled with oil.)

### Grease Fitting and Oil Point Lubrication

Lubricate the grease fittings and oil points **after every 25 hours** of operation. Lubricate **more often** when operating in **dusty or dirty conditions**. Use SAE general purpose lithium or molybdenum base grease for grease fittings and light machine oil (SAE 10) to lubricate oil points. **Lubricate the locations shown in the Chassis and Deck Lubrication Points illustration.**

**NOTE:** PTO universal joints (on the deck and tractor) require routine lubrication **after every 8 hours** of running time.



**Chassis and Deck Lubrication Points**

Ident No.	Location	Lubrication Type	No. Places
1	Deck Caster Wheel Fork Pivot	Grease	2
2	Deck Caster Wheel Bearing	Grease	2
3	Steering Lever Pivot	Grease	4
4	U-Joint Shaft Assembly	Grease*	1
5	Deck-to-PTO Coupling (Grease Slide Area)	Grease	1
6	U-Joint Tube Assembly	Grease*	1
7	Parking Brake Lever	Grease	1
8	U-Joint Quick Connect Spline (Grease Slide Area)	Grease	1
9	FSC Actuator Rod Pivot Pins	Oil	2
10	Forward Speed Control Lever Fork (Grease Slide Area)	Grease	1

Ident No.	Location	Lubrication Type	No. Places
11	Forward Speed Control Lever Pivot	Grease	1
12	(FSC) Friction Body Pivot	Grease	1
13	PTO Clutch Lever Pivot	Grease	1
14	PTO Clutch Actuator Rod	Grease	2
15	Choke Control Cable Ends (MDG Only)	Oil	2
16	Cold Start Lever	Grease	1
17	Rear Wheel Bearings	Grease	2
18	Catcher Hinge Point	Oil	2
19	Deck Support Arm Pivot	Grease	2
20	Front Body Hinge Point	Oil	2
21	Deck Support Arm Socket	Grease	2


\* Grease every 8 hours

## Mower Deck Gearbox Lubrication

**NOTE:** These instructions apply to all mower decks with gear-driven blades. Refer to **DSD62 Mower Deck Lubrication** in this section for the DSD62 deck with belt-driven blades.

The mower deck gearboxes (tee gearbox and blade drive gearboxes) are connected as a unitized assembly, and oil flows freely between them. The gearboxes are permanently lubricated (oil filled) and sealed requiring no scheduled lubrication. However, the gearbox oil seals should be checked **every 25 hours** for indication of an oil leak; **particularly the lower seals** on the blade drive gearboxes should be inspected, since they operate in a dirty environment. If an oil leak is noted, replace the oil seal and relubricate the gearbox assembly as follows:

1. Remove gearbox cover (footrest). Deck orientation should be the normal operating position.



**Mower Deck Gearboxes**  
(shown with gearbox cover removed for clarity)

2. Clean the area around the individual gearbox cover plates to prevent contaminants from entering the gearcase.
3. Remove the screws securing the cover plates on the blade drive gearboxes.
4. Check the level of lubricant in the gearboxes. If the lubricant is low, add SAE E.P. (Extreme Pressure) 90W oil until the oil level is up to (submerges) the horizontal shaft in the gearbox (shaft parallel to cover plate).

**NOTE:** In case the gearboxes are completely drained of oil, approximately 5 fl. oz. (15 cl) of oil per gearbox is required to refill the gear drive assembly.

**NOTE:** Since the gearboxes are connected as a unit by connector tubes, it is necessary to add oil slowly. Allow a few minutes after adding oil for the oil to flow throughout the assembly and the oil level to stabilize before reassembly.


**IMPORTANT: DO NOT** overfill the deck gearboxes. The gearbox assembly is not vented, and overfilling with oil will cause excessive pressure and result in oil leaks.

5. Check condition of the cover gasket and replace if worn or damaged. Reinstall gearbox cover plates; torque screws to 24 in-lb (2.7 N·m).

## DSD62 Mower Deck Lubrication


There are several special lubrication requirements for the DSD62 mower deck in addition to the requirements detailed in the **Chassis and Deck Lubrication** illustration. Lubricate the locations shown in the **Blade Spindle Lubrication** and **Gearbox, Dolly Wheel, and U-Joint Lubrication** photos and check and maintain oil in the belt drive gearbox.

1. Lubricate the blade spindles **every 25 hours** with two (2) shots of SAE general purpose lithium or molybdenum base grease.



**Blade Spindle Lubrication**

2. Check the oil level in the belt drive gearbox **every 100 hours** (or sooner if a visible oil leak has developed). With the deck in the normal operating position, remove the level plug in the side of the gearcase. Add SAE E.P. (Extreme Pressure) 90W oil to maintain the oil level to the plug. If the oil level is low, check the gearbox for any indication of an oil leak. If an oil leak is noted, the gearbox will need to be removed and rebuilt.
3. Lubricate the dolly wheel pivot **every 25 hours** with general purpose grease.
4. Lubricate the U-Joint in the drive shaft **every 8 hours** with SAE general purpose lithium or molybdenum base grease.



**Gearbox, Dolly Wheel, and U-Joint Lubrication**


## Tractor PTO Gearbox Lubrication

### Checking Gearbox Oil Level

Check the gearbox oil level **every 25 hours**, and if necessary, add oil [SAE E.P. (Extreme Pressure) 90W gear lube] to maintain oil level to the **FULL** mark on the dipstick.

**IMPORTANT: DO NOT** overfill the PTO gearbox to avoid oil leakage out of the dipstick standpipe.

If the oil level is low, check the gearbox for any indication of an oil leak. If an oil leak is noted, the gearbox will need to be removed and rebuilt.



**Dipstick Location, Tractor PTO Gearbox**

### Changing Gearbox Oil

The tractor PTO gearbox is oil filled and vented. No scheduled oil change is required. However, changing the oil **after the first 100 hour break-in period** will extend gearbox life and is recommended.

1. Remove the drain plug in the bottom of the gearcase, drain the oil, and reinstall the plug.
2. Refill the gearbox through the dipstick standpipe using 7 to 8 fl. oz. (21 to 24 cl) of SAE E.P. (Extreme Pressure) 90W gear lube.
3. Check that the oil level is at the **FULL** mark on the dipstick. **DO NOT** overfill.

### Gear Axle Lubrication

- The gear axle oil lubrication is SAE 80W-90 (API GL-5) gear lube.
- Check the axle oil level **after every 100 hours** of operation by removing the oil level plug. If additional oil is needed, remove the breather vent on top of axle and fill until oil is at the level plug.
- Change axle oil **every 1000 hours** or **two (2) years**.

## Hydrostatic Transmission Fluid


### Checking Hydrostatic Transmission Fluid Level

Hydrostatic transmission fluid level should be checked **every 25 hours** of machine operation. It is preferable to **check the fluid level when fluid is cold**. Check fluid level as follows:

1. Park the mower on a **level surface**. Stop the engine and wipe dirt and contaminants from around the reservoir cap and air bleed plug.

**IMPORTANT:** Before removing the reservoir cap, clean any dirt from around it. Any dirt or contaminants entering the transmission will accelerate wear and eventually cause loss of power to the drive wheels.

2. Remove the reservoir cap and check the level of the fluid. The reservoir has a fluid level **COLD** mark and **HOT** mark. The reservoir **oil level should ALWAYS be at or above the COLD mark and NEVER above the HOT mark**.



**Transmission Reservoir and Air Bleed Plug Location**

3. If the fluid is below the **COLD** mark (or the transmission is not performing properly), **loosen the air bleed plug** (located on the top of transmission case next to the plastic reservoir).
  - a. If a small amount of fluid leaks from around the air bleed plug:
    - \* The transmission is full of fluid.
    - \* Tighten the plug and fill the reservoir to the **COLD** level mark.
  - b. If no fluid leaks from around the air bleed plug:
    - \* Slowly add fluid into the reservoir until fluid starts to leak from around the plug. (Transmissions are serviced from the factory with Mobil DTE 18M hydraulic oil. When it is necessary to add fluid, refer to **Specifications** for the proper fluid. Any of the listed fluids may be used.)
    - \* As soon as there is fluid leaking from around the air bleed plug, tighten the plug and fill the reservoir to the **COLD** level mark. Wipe any excess oil off of the transmission housing.

**IMPORTANT: DO NOT overfill** the transmission reservoir. This will result in oil leaking out of the reservoir cap vent when the transmission warms up. It is preferable to add fluid to the transmission when it is cold and **make sure the oil is not above or below the COLD level mark**.

**IMPORTANT:** The transmission reservoir has a fine mesh screen in the bottom to trap dirt and foreign particles from entering the transmission. When filling the reservoir, fluid will **flow quite slowly** through this screen; so it is essential that there is fluid at the bleed plug before the transmission is considered full.

**IMPORTANT:** Any attempt to remove or in any way alter the filtering screen in the transmission reservoir could cause damage to the transmission and will **VOID** any transmission warranty.



## *Changing Hydrostatic Transmission Fluid*

The hydrostatic fluid should be changed **every 1000 hours** or **two (2) years**. Also, the fluid should be changed if the natural **color** of the fluid has become **black or milky** (indicating possible overheating or water contamination of fluid). The transmission may be refilled using any of the fluids listed in **Specifications**. The fluid is changed as follows:

1. Park the mower on a **level surface** and stop the engine.
2. Remove the lower drain plug and the air bleed plug. Allow the fluid to drain out.

**IMPORTANT:** Clean any dirt from around the plugs and reservoir cap **before** removing them.

3. Reinstall the lower drain plug, making sure the rubber O-ring on the plug is in place and in **good condition**.
4. Refill the transmission through the air bleed plug hole until it is as full as possible.

**IMPORTANT:** Avoid fluid contamination when filling the reservoir. Use clean container, spout, funnel, etc. when pouring the fluid into the reservoir.

5. Rotate the transmission input shaft about five (5) revolutions to allow any trapped air to escape.
6. Before installing the air bleed plug, fill the reservoir with fluid allowing a small amount to leak out of the air bleed plug hole.
7. Install the air bleed plug and fill the **reservoir** to the **COLD** level line.

## **CLEANING**


### **Engine Air Cleaner System**

#### *Cyclone Precleaner*

A Cyclone Precleaner is attached to the Kubota air cleaner inlet. The Cyclone Precleaner must be checked and cleaned **daily or more frequently** in extremely dusty conditions.

1. Remove the wing nut and metal cover.
2. Remove the bowl. Empty and clean it.
3. Reassemble the precleaner. Make sure the wing nut is tight.

**NOTE:** The Cyclone precleaner is the primary dust trap. If the precleaner is functioning as it should, it will fill with dust several times before the dust cup will need to be cleaned.



**Cyclone Precleaner**

#### *Air Cleaner Dust Cup*

1. Remove and clean the Kubota air cleaner dust cup **daily or more frequently** in extremely dusty conditions. The dust cup should be cleaned **before** it becomes **half full** of dust.
2. With the dust cup removed, check the filter element for security and tightness of the wing bolt mounting the filter. **Do not disturb the filter element** until cleaning or changing is required (usually **every 100 hours**).

3. Reinstall the dust cup with the word "TOP" properly oriented to the top of the canister. Make sure both the top and bottom draw latch are securing the dust cup in place.




**Air Cleaner Dust Cup**

### Air Filter Element

**IMPORTANT:** The Kubota engine uses a dry paper-type air filter element. **NEVER** apply oil to the paper element.

Clean and inspect the paper element **after every 100 hours** of service and **replace** the element **yearly or after six (6) cleanings** (or when dirty or damaged). Service the air filter as follows:

**NOTE:** Black smoke from the exhaust pipe is a visual clue of air filter restriction and the need to service the air filter element.



**Air Filter Element**


1. Remove the filter element and clean using **low pressure** compressed air [less than 100 PSI (689 kPa)]. Blow out the filter from the interior of the element while turning the element.

**NOTE:** Washing the element in water or cleaning solution is **not recommended**. Replace the element if it does not clean up with compressed air.

2. Use a bright light inside the element to inspect for damage. Check the element very carefully for **pin holes or other damage** that will allow dirt to leak through the paper media. Replace element if necessary.
3. Check the condition and resilience of the filter gasket. Replace filter if the gasket has hardened or cracked or if there is evidence of the gasket not seating evenly.

**IMPORTANT:** Use **only** Kubota air filter elements for replacement (Kubota 70000-11221). Aftermarket filters may not seal properly or filter efficiently.

4. Check the air cleaner canister. Make sure it is secure and **not bent or damaged**. Also, make sure the air filter element sealing surface inside the canister is smooth and flat. Replace any damaged air cleaner components.
5. Use a clean, damp cloth and wipe the interior of the air cleaner canister clean (including the filter seating area and hose inlet).



**Air Filter Reinstallation**

6. Reinstall the paper element, making sure it is held tight and straight in the canister for proper seating and sealing. Tighten the wing-head bolt finger tight; **DO NOT** overtighten.

**NOTE:** A light coating of grease on the **filter gasket** and **mounting bolt washer** is recommended to enhance sealing and prevent dust leaks at these points.

7. Check the air intake hose for cuts, nicks, etc., and the hose clamps for tightness.

## Engine Cooling System

### Radiator Screen and Cooling Fins

To prevent the engine from overheating and possible engine damage, clean grass clippings, chaff, and dirt from the fine mesh radiator intake screen **daily**. In certain mowing conditions (dry grass, leaves, tree "cotton", etc.), it may be necessary to check and clean the screen several times during use to prevent engine overheating.

1. Unlatch and remove the screen. To clean the screen, wash with soapy water or blow out with compressed air.
2. Inspect the radiator cooling fins for material lodged in this area which would restrict cooling airflow. Use pressurized air or water to clean. **DO NOT use any tool, like a screwdriver or knife**, to clean material out of the fins as this may damage the cooling fins. **DO NOT** use cold water on a hot radiator.

**NOTE:** Directing pressurized air or water from the fan side of the radiator outward is recommended to dislodge material packed on the outside of the cooling fins. **DO NOT** use cold water on a hot radiator.

### **WARNING**

**Radiator and engine parts can become extremely hot during operation. Wear gloves and avoid touching hot parts while cleaning the radiator screen and cleaning debris away from the engine and cooling system.**

### Flushing Radiator and Changing Coolant

Change engine coolant **every year**. Drain the coolant from the engine and radiator:

1. Remove the radiator cap.
2. Open the drain cocks on the engine block and radiator (see the Kubota Owner's Manual for location of the drain cocks). Also, drain the coolant recovery tank.
3. If there is any **indication of deposits** or scaling inside the radiator, use a commercial scale remover and **flush the cooling system** thoroughly before adding fresh coolant.

Use a pre-mixed 50/50 solution of antifreeze (ethylene glycol) and distilled water to refill the cooling system.

**IMPORTANT:** The solution of antifreeze and water must be thoroughly pre-mixed before putting it in the engine. Adding pure antifreeze into the radiator may cause damage to the engine from overheating.

**IMPORTANT:** Maintain **proper coolant level** in the radiator and coolant recovery tank. The coolant level should be maintained between **FULL** and **LOW** marks on the coolant recovery tank. **Recheck** the coolant level after the first time the engine has been operated after filling the coolant system (it would be normal to add a little coolant after initial operation).

### Grass Buildup in Mower Housing


#### **DANGER**

**Before raising or removing the mower deck for cleaning, stop the engine, remove the ignition key, and disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG).**

1. Raise the deck and **secure it** in the **UP** position by hooking the deck lift rod into the body bracket below the counterweight spring clip. The rod is hinged and is stowed along the footrest of the deck carrier frame. A hitch pin on the end of the rod is used to secure it in place with the deck raised.

**⚠ DANGER**

**NEVER** operate cutter blades with the deck in the raised position.



**Deck Secured in UP Position**

2. Clean grass buildup underneath the deck using a pressure washer (and scraper if required).

**NOTE:** If the buildup is severe, it may be easier to clean the deck by removing the deck assembly from the tractor and standing the deck assembly on its “nose”.

**NOTE:** While some degree of material buildup in the mower deck housing can be tolerated, a point is finally reached **where cutting quality deteriorates and clogging begins to occur** because of too much buildup on the baffling and housing.

**GHS Blower**

Normally, the GHS blower operates with no maintenance or cleaning. However, when mowing **grass that is dirty and damp** (especially springtime mowing), a deposit of dirt may accumulate inside the blower housing, causing wear and binding of the blower wheel. When operating in these conditions, **inspect the blower frequently for dirt buildup.**

**NOTE:** A visual clue of binding of the blower wheel is the blower **blade tips are polished** from rubbing on dirt.


When a dirt deposit is found, use a high pressure washer or water spray to clean the inside of the housing as follows:

**⚠ DANGER**

**Before attempting to wash the blower, stop the engine, remove the ignition key, and disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG).**

1. Remove the GHS blower drive belt by unhooking the belt tension spring from the hook on the chassis frame (located above the blower pulley). Lift the belt tightener idler pulley up and roll the belt off of the blower pulley. The belt should be clear of the blower pulley, allowing **free movement** of the blower wheel.

**IMPORTANT:** With the belt removed, the blower wheel **must spin freely**. Any binding or dragging of the wheel is an indication of dirt buildup. This **buildup must be cleaned** to avoid abrasive wear of the blower blades, excessive power loss and eventual loss of blower performance (clogging).



**Collapse Blower Belt Tightener to Remove GHS Blower Drive Belt**

2. Use a pressure washer or water spray, and direct the spray inside the blower housing against the blower blades. Water pressure will cause the blower wheel to begin to spin and the combination of spinning action and water will effectively wash the inside of the housing. Spray may be directed against the blower blades vertically and horizontally to cause rotation in both directions for thorough washing action. **Wash blower until the blower wheel spins freely** in both directions.
3. Reinstall the GHS blower drive belt by reversing the removal procedure.

### GHS Exhaust Screen

Refer to **Cleaning the GHS Exhaust Screen** in **Operating Instructions**.


### Hydrostatic Transmission Cooling Fins

Keeping the cooling fins on the hydrostatic transmissions clean and free of obstruction is **essential to avoid overheating** the transmission fluid and shortening transmission life. The cooling fins should be checked **every 100 hours**; and cleaned if necessary.

To clean the fins, use compressed air and/or a pressure washer. The cooling fins extend all the way around the housing -- the fins underneath need to be clean as well as the more visible fins above. Also, pay close attention to the area under the drive pulley.

**IMPORTANT:** In case an oil leak develops on the input shaft, the cooling fan blowing dusty air and oil on the transmission will **quickly** pack the cooling fins with **oily dirt**. If this condition occurs, replace the seal immediately to avoid overheating and damaging the transmission. The input shaft assembly and seal are easily replaced without removing the transmission from the machine.

An additional procedure in maintaining transmission cooling is to inspect the cooling fans. Replace the fan(s) if blades are missing or damaged.



Hydrostatic Transmission Cooling Fins

### CHECKING/SERVICING

#### **DANGER**

To prevent accidental starting of the engine when servicing or adjusting the machine, remove the key from the ignition switch and disconnect the electric plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG).

### Engine Cooling System

#### Coolant Level

#### **WARNING**

**NEVER** remove the radiator pressure cap when the engine is hot — hot water could spray and cause a burn if the cap is taken off too soon.


Check the coolant level in the coolant recovery tank and **maintain the coolant level between the FULL and LOW marks on the recovery tank**. When the engine is cold, the coolant level should be at or slightly above the **LOW** mark on the recovery tank.

If the coolant level is low, remove the radiator cap and fill to the overflow port level and then fill the recovery tank above the **LOW** mark. Use a pre-mixed 50/50 solution of antifreeze (ethylene glycol) and distilled water to fill the cooling system.

**IMPORTANT:** The coolant solution of antifreeze and distilled water must be thoroughly pre-mixed before putting it in the engine (adding pure antifreeze into the radiator may cause damage to the engine by causing overheating).

### Fan Belt Tension

Check and adjust the fan belt tension **to avoid engine overheating and insufficient battery charging**. Push on the belt in the middle of the span between the alternator and crankshaft. If properly tensioned, it should deflect about **0.4 in. (10 mm)**. Also check the belt for cracks or deterioration.



**Fan Belt Tension**

### Security of Air Filter Element

The security of the air filter element is checked **daily** in conjunction with cleaning the air cleaner dust cup. Refer to **CLEANING** the *Air Cleaner Dust Cup* in this section.

### Battery

**NOTE:** For initial battery service during setup, refer to **Battery Service** in **Assembly Instructions**.

#### Electrolyte Level

The battery electrolyte level should be checked **after every 25 hours** of operation. To check electrolyte level:

1. Remove battery cell filler caps.
2. Check the electrolyte level. If the level is below the bottom of the vent well, fill with drinking water to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].
3. Replace filler caps.

**IMPORTANT: DO NOT** overfill the battery. Electrolyte will overflow through the vented caps onto parts of the machine and **WILL** result in severe corrosion.

#### Cleaning the Terminals

If battery terminals are corroded, **remove battery** from the mower. Using a wire brush, remove corrosion with a solution of **one part baking soda and four parts water**. Rinse with clean water. Coat the terminals with petroleum jelly or terminal protector spray to retard further corrosion.

#### Charging the Battery

Check the battery charge by measuring the specific gravity of electrolyte; if specific gravity is less than 1.225, the battery will need to be charged as follows:

1. Charge the battery at 15 amps for 10 minutes. **DO NOT** exceed 20 amps maximum recommended charging rate. Charge until specific gravity is at least 1.250. Total charging time should not exceed one (1) hour.

2. After charging the battery, use drinking water to adjust the electrolyte level to the bottom of the vent wells [1/4 to 1/2 in. (6 to 13 mm) above the plates].

 **DANGER**

**BATTERIES PRODUCE EXPLOSIVE GASES**

- Charge the battery in a well-ventilated area, so that gases produced while charging can dissipate.
- Keep sparks, flames, and smoking materials away from the battery at all times.
- Make sure the battery cap vents are open (check manifold vent on each cap).
- Make sure the battery charger is unplugged before connecting or disconnecting cables to the battery.

### Tire Pressure

Inflate tires to pressures shown below:

Deck Caster Wheel = 20 PSI (137 kPa)  
 Drive = 15 PSI (103 kPa)  
 Rear = 20 PSI (137 kPa)

### Sharpen Mower Blades

Check mower blade(s) for **straightness, sharpness, condition of the cutting edge**, and **balance every 10 hours** of operation (or more often when mowing abrasive type grass or operating on sandy soils). **Replace blades if worn, bent, cracked, or otherwise damaged** (refer to **REPLACING/REPAIRING the Mower Blades** in this section). Use the following procedure to check and sharpen blades:

**NOTE: Keep blades sharp** - cutting with dull blades not only yields a poor mowing job but slows the cutting speed of the mower and causes extra wear on the engine and blade drive by pulling hard.

1. Stop the engine, remove ignition key, and disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG) **before** raising the mower deck to service blades.
2. Raise the deck and **secure it** in the **UP** position by hooking the deck lift rod into the body bracket below the counterweight spring clip (refer to **Deck Secured in UP Position** photo in **CLEANING the Grass Buildup in Mower Housing** in this section). The rod is hinged and is stowed along the footrest of the deck carrier frame. A hitch pin on the end of the rod is used to secure it in place with the deck raised.

 **DANGER**

**NEVER operate cutter blades with the deck in the raised position.**

3. Check the blades for **straightness** by marking the blade tip position inside the deck housing, and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.

 **WARNING**


**DO NOT try to straighten a blade that is bent. NEVER weld a broken or cracked blade. ALWAYS replace with a new blade to assure safety.**

4. If the blade cutting edge is **dull or nicked**, it should be sharpened. Remove blades for sharpening by grasping the end of the blade using a rag or a thick, padded glove, while loosening and removing the nut, lock washer, and flat washer that mounts the blade.
5. Grind cutting edge at the same bevel as the original. Sharpen only the top of the cutting edge to maintain sharpness.

**NOTE:** Blades can be sharpened with an electric blade sharpener, conventional electric grinder, or a hand file.


**CAUTION**

**ALWAYS** wear eye protection and gloves when sharpening a blade.



**Mower Blade Profile For Sharpening**

6. Check blade balance by positioning the blade **horizontally** on a blade balancer or use a nail or shaft through the center hole. If either end of the blade rotates downward, grind (remove) metal on that end until the blade will balance. The blade is properly balanced when neither end drops. Balance of a blade is generally maintained by removing an equal amount of material from each end of the blade when sharpening.



**Blade Balanced on Magnetic Wall-Mounted Balancer**

7. Mount the blade with wing tips pointing up into the housing. Reinstall the blade, washer, lock washer, and nut. **Tighten the nut to 60 ft-lb (81.3 N·m).**

**NOTE:** When reinstalling blades on **GHS** models, remember, the **blades turn toward each other** (counter-rotate) and the RH and LH blade cannot be switched. Check for proper blade rotation before installing blades on the deck. Refer to **Blade Rotation for GHS Mower Deck** illustration shown in **Clogging Checklist** in **Operating Instructions** for correct blade rotation.

### Drive Belts

Raise the body and inspect the condition of the five (5) belts (4 belts on SD models) **every 25 hours** of operation - engine PTO drive, jackshaft drive, hydrostatic ground drive, GHS blower drive, and engine fan belt. If the belts show **signs of cracking or deteriorating**, the belts should be **replaced**. Refer to **REPLACING/REPAIRING the Drive Belts** in this section.

### Mower Deck Gearbox Oil Seals

The mower deck gearbox seals should be inspected **every 25 hours** for evidence of oil leaking; **particularly the lower oil seal on the blade drive gearbox**. This seal is protected by the trash guard on the blade hub and seal protector plate on the housing, but is still vulnerable to seal damage due to operating in an adverse environment. The mower blade must be removed for inspection of the seal, so it is recommended to **inspect the gearbox seals when blades are removed for sharpening**. If an oil leak is noted, the seal should be replaced and the gearbox assembly relubricated. Refer to **Mower Deck Gearbox Lubrication** in this section.

### Spark Plugs - Model MDG

**Every 400 hours**, remove the spark plugs, inspect, clean, and reset the gap (or replace with **new plugs**). Clean spark plugs with a wire brush. If the electrodes are burned short or pitted, replace the plug (refer to **Specifications** for the proper type of replacement plug). Check the spark plug gap with a wire-type feeler gauge and set the gap to 0.043 in. (1.1 mm). Reinstall and tighten to 17 ft-lb (23 N·m).



### Ignition Wires - Model MDG

Good preventive maintenance calls for complete **replacement** of spark plug wires **every two (2) years**.

### Breaker Points - Model MDG

The Kubota engine is equipped with electronic ignition. No breaker points, maintenance, or adjustments are necessary with this system. Contact an authorized Kubota engine dealer in case of ignition failure.

### Fuel Lines and Clamps

**Every 200 hours**, inspect the fuel supply line from the tank to engine for deterioration or damage. Also, inspect the fuel line **clamps for tightness**. Good preventive maintenance calls for complete **replacement** of fuel lines and clamps **every two (2) years**.

**NOTE:** This procedure is of special importance for the diesel engine (Model MDD) due to poor performance when air is injected with the fuel.

### Radiator Hoses and Clamps

Inspect the radiator hoses **every 200 hours** for deterioration or damage. Also check the tightness of the hose clamps. Good preventive maintenance calls for complete **replacement** of the radiator hoses and clamps **every two (2) years**.

### Engine Valve Clearance

Check and adjust the Kubota engine valve clearance **every 800 hours**. Refer to the Kubota Engine Owner's Manual and Workshop Manual for specifications and procedure to check the valve clearance. For engine servicing, contact an authorized Kubota engine dealer or a trained engine technician.

**IMPORTANT:** Always use the proper engine service manual when working on the engine. Improper engine maintenance or adjustments will adversely affect engine operation, performance, and durability and may **VOID** the warranty.

### Fuel Injection Nozzle Pressure - Model MDD

Check and adjust the Kubota diesel engine fuel injection nozzle pressure **yearly** or **every 1000 hours** (or in case of low power). Refer to the Kubota Workshop Manual for specifications and procedures to check nozzle pressure. For engine servicing, contact an authorized Kubota engine dealer or a trained engine technician.

**IMPORTANT:** Always use the proper engine service manual when working on the engine. Improper engine maintenance or adjustments will adversely affect engine operation, performance, durability, and may **VOID** the warranty.




### WARNING

**The fuel oil injection system operates under high pressure and can penetrate the skin and result in serious injury. Unqualified persons should not remove or attempt to adjust a pump injector, nozzle, or any part of the fuel injection system.**


### Fuel Valve Solenoid - Model MDD

The starting and stopping of the diesel engine is controlled by the fuel shut-off valve. If the engine cranks, but does not start or the engine does not stop when the ignition switch is turned **OFF**, check operation of the fuel valve.

Raise the mower body and locate the fuel valve on the engine. The valve is operated by an electric solenoid which is **controlled by the ignition switch**. The valve is open when the ignition key is moved to the **START** or **RUN** position, and the valve is closed when the ignition key is moved to the **OFF** position.



**Fuel Valve Closed  
(Engine OFF Position)**



### Fuel Valve Open (Engine START and RUN Position)

If the fuel valve solenoid is not operating properly, the problem may be isolated by **first** checking the operation of the solenoid as follows:

1. Disconnect the fuel valve solenoid wire plug from the wire harness.
2. Make jumper wire connections from the solenoid to the battery:
  - a. Red wire to positive terminal (+), black wire to ground (-).
  - b. Touch white wire to the positive terminal (+) and the solenoid should pull closed (open the fuel valve).
  - c. Remove the white wire and the solenoid should **hold** the fuel valve open.
  - d. Remove the red wire and the solenoid should open (close the fuel valve).

Replace the solenoid if it does not operate properly by the above test. If it does operate, the problem is in the electrical system and can be checked using the wiring diagram. Refer to **ELECTRICAL SYSTEM** for **Wiring Diagrams** in this section.

### Blade Brake Action

#### **WARNING**

**It is important to check and maintain blade brake action for safe operation of the machine.**

Check the function of the cutter blade brake (and blower brake on GHS models) by engaging the blade clutch (PTO), operating the engine at full throttle, then disengaging the clutch and measuring how quickly the blades stop. Watch the rotation of the blade drive shaft and blower pulley as a visual indication that movement has stopped. If the brake is **working properly, all rotation will stop five (5) seconds after disengagement** of the clutch. If the brake system malfunctions - blades do not stop in five (5) seconds - adjust or repair the brake before operating the mower. Refer to **ADJUSTMENTS of Blade Clutch (PTO)** in this section.

### REPLACING/REPAIRING

#### **DANGER**

**To prevent accidental starting of the engine when replacing parts or repairing the machine, remove the key from the ignition switch and disconnect the electrical plug on the fuel shut-off solenoid (MDD) or the spark plug wires (MDG).**


**IMPORTANT: ALWAYS** use genuine factory replacement parts. Substitute parts **CAN** result in product malfunction and possible injury to the operator and/or others.

### Drive Belts

There are **five (5) individual belts** on GHS models or **four (4)** belts on SD models:

- Jackshaft Drive Belt
- Engine PTO Drive Belt  
(3 Groove Power Band)
- GHS Blower Drive Belt (GHS Model Only)
- Hydrostatic Ground Drive Belt
- Engine Fan Belt

The belts may be removed and replaced using the **procedures described on the following pages.**



Belt Locations


## Jackshaft Drive Belt

1. To remove the jackshaft drive belt:

a. Relax the belt by releasing spring tension from the jackshaft drive idler arm using the **cold start lever**.


b. Slide the idler arm release down to unlock the idler arm from the spring lever. Then pivot the arm up and away from belt.

c. Roll the belt off the jackshaft pulley and remove.



**Jackshaft Drive Belt (Disengaged)**

2. Reverse the removal procedure to replace the jackshaft drive belt.




**Jackshaft Drive Belt (Engaged)**

## Engine PTO Drive Belt (3 Groove Power Band)

1. To remove the engine PTO drive belt:
  - a. Remove the jackshaft drive belt, as described in previous section.


- b. Loosen the brake band adjustment nut to allow the clutch idler pulley to drop down against the frame. This provides maximum looseness of the belt to assist removal.
- c. Remove the PTO drive belt by "walking" the belt off of the engine and PTO pulleys one groove at a time until the belt is completely removed.



## Engine PTO Drive Belt Assembly (Disengaged)

2. Install the PTO drive belt by reversing the removal procedure. Refer to **ADJUSTMENTS** of **Blade Clutch (PTO)** in this section to make the following adjustments:


- a. Adjust clutch disengagement (brake band adjustment) and check brake action.
- b. Adjust clutch engagement for proper belt tension.



## Engine PTO Drive Belt Assembly (Engaged)


## GHS Blower Drive Belt

1. Remove the GHS blower drive belt by unhooking the belt tension spring from the hook on the chassis frame (located above the blower pulley). Lift the belt tightener idler pulley up and roll belt off the pulleys.



**GHS Blower Drive Belt Assembly (Disengaged)  
Blower Drive Belt Spring Removal**


2. Reverse the procedure to install the GHS blower drive belt and spring.



**GHS Blower Drive Belt Assembly (Engaged)**


## Hydrostatic Ground Drive Belt

1. To remove the hydrostatic ground drive belt:
  - a. Loosen the belt using a wrench (9/16 in.) on the tension idler pivot bolt to rotate the idler pulley away from the belt.
  - b. Lift belt off the pulleys, then release the idler.



**Hydrostatic Ground Drive Belt Assembly (Disengaged)**


2. Reverse the procedure to install the hydrostatic ground drive belt.



**Hydrostatic Ground Drive Belt Assembly (Engaged)**


## Engine Fan Belt

1. To remove the fan belt:
  - a. Loosen the alternator mounting pivot bolt and the alternator bracket tensioner bolt.
  - b. Pivot the alternator as shown to relax and remove belt.



**Engine Fan Belt (Loose)**

2. Reverse the procedure to install the belt. Adjust and check the belt tension by referring to **CHECKING/SERVICING** the *Fan Belt Tension* in this section.




**Engine Fan Belt (Tight)**



## Fuel Filter - Model MDD

Model MDD has **two (2) fuel filters**. Replace both the in-line filter and the Kubota filter element **every 400 hours** of operation.



**Fuel Filter Location (Model MDD)**

**IMPORTANT:** Replace fuel filters only in a clean area where the fuel line and connections will not be contaminated by dust and dirt.

1. Close the fuel tank shut-off valve and the Kubota fuel filter cock.
2. Remove and replace the in-line filter; expand and slide clamps on either side of the filter away from filter and pull fuel lines off filter.
3. Loosen the ring screw on the Kubota filter assembly, remove the filter pot and filter element.
4. Clean the filter pot and reassemble the filter assembly with a new filter element (use only a Kubota replacement filter #15231-43560).
5. Open the fuel filter cock and fuel tank shut-off valve.

## Fuel Filter - Model MDG

Model MDG is equipped with an in-line fuel filter. (Same location as shown for Model MDD.) Replace the filter **yearly**.

**IMPORTANT:** Replace the fuel filter only in a clean area where the fuel line and connections will not be contaminated by any dust and dirt.

## **DANGER**

**Gasoline is extremely flammable and can be highly explosive. To minimize danger:**


- Use only an approved fuel container for gasoline.
- **DO NOT** allow open flames or sparks near the machine while performing maintenance or refueling; **DO NOT** smoke while working with fuel.
- Wipe up spilled gasoline immediately and completely.

1. Close the fuel tank shut-off valve.
2. Expand and slide clamps on either side of the filter away from filter and pull fuel lines off filter.
3. Replace filter.
4. Open fuel tank shut-off valve.

## Blade Overload Shear Bolts

**NOTE:** Shear bolts are not used on the DSD62 mower deck.

The cutting blade is keyed to the blade hub by **two (2) shear bolts** (10-24 x 5/8 in. stainless steel machine screws). These bolts are designed to shear and protect the blade drive gearbox from damage if the blade encounters a shock load.



**Cutting Blade Shear Bolts**

**NOTE:** Tightening the **5/8-18 blade mounting nut to 60 ft-lb (81.3 N·m)** is also important for proper shock load protection. It is important to **not over-tighten** the mounting nut since this defeats (overrides) the function of the shear bolts.

If these bolts shear, remove the blade and install new bolts. Refer to **CHECKING/SERVICING** in this section for **Sharpen Mower Blades** which describes the blade removal and installation procedure.

After reinstalling the blade, check blade timing by moving blades through **one (1) complete revolution**. Make sure blade tips pass clear of each other. If timing is incorrect, refer to **Mower Deck Gearbox Replacement** in this section.

### Mower Blades

Mower blades are removed and remounted as described in **Sharpen Mower Blades** instructions. During the course of sharpening and inspecting mower blades, if there are **any of the following conditions of wear or damage, blades should be replaced** for reasons of safety and performance of the machine:

- An excessive amount of the **flat section** of the blade has been **ground away** (removed) when the blade is sharpened. Replace the blade **when less than a 3/4 in. (19 mm) flat section remains** at the blade tip.
- Examine ends of the blade carefully, especially the intersection where the flat section of the blade turns up to form the “wing tip” (refer to **Mower Blade Profile for Sharpening** illustration in **Sharpen Mower Blades** instructions). Since sand and abrasive material can wear metal away in this area, the blade should be **replaced when metal thickness has worn to 1/16 in. (1.6 mm) or less**.

### **DANGER**

**When blades are operated over sandy soil, and if blades are allowed to wear, a “slot” may be worn into the wing tip of blade. Eventually a piece of the blade may break off creating a serious potential for injury or damage.**

- Check the blades for **straightness** by marking blade tip position inside the deck housing and then rotating the opposite end of the blade to the same position and comparing. If the difference in blade tip track is **more than 1/8 in. (3 mm)**, the blade is bent and **should be replaced**.

- Inspect the blade surface, especially in formed areas, for **cracks**. Replace the blade if any cracks are found.

### **WARNING**

**DO NOT try to straighten a blade that is bent. NEVER weld a broken or cracked blade. ALWAYS replace with a new blade to assure safety.**

Reinstall the blades following procedure from **Sharpen Mower Blades** instructions. If blades are replaced, always use **Walker original equipment blades** to ensure safety and optimum performance. The quality and performance of **replacement blades offered by other manufacturers** cannot be guaranteed, they **could be dangerous**.

### **CAUTION**

**ALWAYS use genuine factory replacement parts. Substitute parts CAN result in product malfunction and possible injury to the operator.**

### Mower Deck Gearbox Replacement

**NOTE:** Deck gearbox(es) may be changed with the deck mounted on the tractor. However, the deck may be removed from the tractor making the overall job of removing the gearbox assembly easier. Refer to *Deck Installation* in **Assembly Instructions** and reverse the procedure to remove the deck.

To replace the mower deck gearbox(es), use the following procedure:

1. Remove mower blades. Refer to procedure in **Sharpen Mower Blade** instructions.

2. Remove gearbox cover (two machine screws) and PTO shaft guard (two 1/4-20 bolts).
3. Remove two (2) 3/8-16 mounting bolts from each blade drive gearbox and lift the entire gearbox assembly from the deck (including PTO drive shaft).

4. Remove the screws securing the cover plates on the gearboxes and remove the covers. Remove all covers to be sure oil is completely drained from all gearboxes.

**NOTE:** With oil flow throughout the unitized gear drive assembly; if one gearbox has internal damage or excessive wear, the remaining gearboxes and connector tubes should be completely disassembled and thoroughly flushed out with solvent before reassembly.

5. Drain and properly dispose of oil.
6. Remove the four (4) bolts mounting the gearbox to the connector tube and slide the gearbox off the splined drive shaft coupling.
7. Install the new gearbox on the spline coupling of the drive shaft. Establish correct timing of the blade drive gearboxes by setting flats on the output shaft at 90 degrees when connecting the gearbox(es) to the spline coupling. Make sure the timing is correct before proceeding with assembly.

8. Reinstall the four (4) bolts mounting the gearbox to the connector tube but **do not tighten** them at this time; leave connector tube bolts finger-tight.


9. Position the gear drive assembly on the deck and install the 3/8-16 bolts mounting the entire assembly. Leave the mount bolts finger-tight.

10. Torque all the connector tube bolts to 80 in-lb (9 N·m); then tighten the deck mount bolts.

**NOTE:** This fastener tightening sequence aligns the gearbox assembly with the deck housing and eliminates the possibility of mounting the unitized assembly in a bind.

11. Fill gearbox assembly with oil. Refer to **Mower Deck Gearbox Lubrication** in this section for instructions.

12. Reassemble remaining items onto deck to complete installation. After installing the blades, check that the blade timing is correct by moving the blades through **one (1) complete revolution**. Make sure blade tips pass clear of each other.




**Mower Deck Gearbox**  
(shown with gearbox cover removed for clarity)

### GHS Blower Assembly (and/or Blower Wheel)

#### *GHS Blower Assembly Removal*

1. Remove the mower deck. Refer to *Deck Installation* in **Assembly Instructions** and reverse the procedure to remove the deck.



**Remove Skid Bar for**  
**GHS Blower Removal**


2. Remove the blower faceplate by removing six (6) 1/4-20 nuts.
3. Remove the GHS blower drive belt. Refer to **REPLACING/REPAIRING the Drive Belts** in this section for instructions.
4. Remove the blower assembly from the chassis as follows:
  - a. Remove the blower skid bar by removing front and rear mounting bolts from the skid bar (underneath the blower) and removing the bolt connecting the blower housing to the skid bar.
  - b. Remove the blower belt tightener idler arm assembly by removing the pivot bolt.
  - c. Remove two (2) bolts mounting the blower housing to the frame.
  - d. Lower the blower assembly **straight down** out of the chassis frame and remove.

### Blower Wheel Removal

When required, replace the blower wheel using the following procedure:

1. Loosen blower pulley set screws and remove the pulley using a wheel puller.
2. Remove the **locking collar** from the back bearing (closest to the pulley) by loosening the **set screw** and rotating the collar counterclockwise (use punch to drive).
3. Press blower wheel out of the housing using a wheel puller hooked to lugs on the bearing housing. The bearings have been secured in the housing with a retaining compound - Loctite<sup>®</sup> RC/680, and **considerable force** will be required to break this bond. After the bearings have "broken loose" from the housing, only light pressure should be required to remove the wheel assembly out of the housing.

**NOTE:** It may or may not be possible to remove the front bearing from the blower wheel without damaging it. If the bearing is damaged, it will need to be replaced along with the wheel.



### Pressing Blower Wheel Out of Housing

#### Blower Wheel Installation

1. To install the blower, **reverse the removal procedures**. The front bearing is mounted on the blower wheel shaft, secured by a locking collar. Drive the locking collar clockwise with a punch, and tighten the set screw.
2. Press blower wheel and front bearing into the blower housing. Use Loctite<sup>®</sup> RC/680 retaining compound on the outer bearing race and inside the bearing housing.
3. Press the rear bearing into place, using Loctite<sup>®</sup> on both the outer bearing race and the housing.
4. Install the locking collar on the rear bearing and install the blower pulley to complete the blower assembly. Torque the blower pulley set screws to 250 in-lb (28.3 N·m).

#### GHS Blower Assembly Installation

Reinstall the blower assembly into the mower using the reverse procedures of *GHS Blower Assembly Removal*.

## Replacing Fuel Valve Solenoid

For checking operation of the solenoid, refer to **CHECKING/SERVICING the Fuel Valve Solenoid-Model MDD** in this section. To replace the solenoid:

1. Remove the engine air intake hose for access to the solenoid.
2. Disconnect the electrical plug, remove the two (2) mounting bolts and the cotter pin on the linkage, then remove the solenoid.
3. Unscrew the linkage rod out of the old solenoid and reinstall in the new solenoid. Leave the jam nut on the linkage rod loose.
4. Reinstall the solenoid. At this point, move the solenoid linkage by hand and check for any binding or dragging of the solenoid plunger and linkage. If the solenoid does not move freely, adjust the solenoid mounting position by bending the mount and/or loosening the mounting bolts. The solenoid must move freely for proper operation.
5. Refer to **ADJUSTMENTS of Fuel Valve Solenoid Linkage-Model MDD** in this section and make the fuel valve linkage adjustment for the 1/16 in. (1.59 mm) air gap with injector pump stop.
6. Reinstall the engine air intake hose. Make sure the hose clamps are tight and the hose is secure.

## ADJUSTMENTS



**If the engine must be running to perform a maintenance adjustment, keep hands, feet, and clothing from moving parts. DO NOT wear jewelry or loose clothing.**

### Safety Switches

There are three (3) safety interlock switches on the tractor. Use the panel nuts on the switch body to position the switch for proper activation of the switch. The adjustment procedure for each switch is:

#### Seat Switch

Adjust switch position in body panel to achieve a 1/32 to 1/16 in. (.79 mm to 1.59 mm) air gap between the switch plunger and seat frame with no weight on the seat. Test for proper operation.

#### FSC Neutral-Park Switch

1. Place the FSC in **NEUTRAL-PARK** position.
2. Adjust switch to the point where the starter engages when the ignition switch is turned to the start position.
3. Adjust switch position forward an additional 1/2 to 1 turn of the panel nuts.

**NOTE:** If the switch cannot be adjusted forward enough to achieve proper function, it may be necessary to bend the switch mounting bracket slightly.

#### PTO Switch

With the PTO engaged, adjust switch to achieve a 1/64 to 1/32 in. (.40 mm to .79 mm) gap (plunger extension) between the switch body and the actuator plate.

### Tail Wheel Bearing Preload

Preload the tail wheel bearings by tightening the axle nut until the wheel begins to tighten as it turns (not spin freely), then loosen the nut 1/2 to 1 turn. The wheel should spin freely without excessive end play. Lock the axle nut with the set screw in the nut.

### Blade Clutch (PTO)

#### Clutch Disengagement/Brake Action




**It is important to check and maintain blade brake action for safe operation of the machine.**

The **declutched or disengaged** position of the blade clutch idler pulley is adjustable and is set to give belt release **without excessive slack** and to apply the blade brake. The blade brake is activated by linkage to the clutch idler pulley mechanism. The brake is designed to stop the blades within five (5) seconds after disengaging the clutch.

Use the following procedure to check and adjust clutch disengagement and brake action:

1. Use the adjustment nut on the brake band (refer to **PTO Clutch Disengagement Adjustment** illustration) to set the position of the clutch idler pulley in the **declutched** position. Adjust the declutched pulley position to give **1/2 in. (1.3 cm) pulley travel** from “clutch engaged” to “clutch disengaged.” To check and adjust the pulley travel, first engage the clutch, then measure the distance the pulley moves down as the clutch is disengaged.
2. After the pulley travel is set, **check blade brake** action as described in **CHECKING/SERVICING the Blade Brake Action** in this section. If the brake does not stop the blades within five (5) seconds, check the following:
  - a. Check clearance between the clutch idler pulley and the motor mount when the pulley is in the declutched position. If there is no clearance and the idler pulley rests on the frame, the blade brake will not be applied when the clutch is disengaged. Normally, this problem would be caused by a short engine PTO drive belt. Change the belt (refer to **REPLACING/REPAIRING the Drive Belts** in this section), and readjust pulley travel as described by step 1 (above).




**PTO Clutch Disengagement Adjustment**

- b. Check both the brake band and brake drum on the drive pulley for wear. Replace worn brake parts and readjust pulley travel as described by step 1 (above).


### Clutch Engagement/Belt Tension

The clutch engagement and PTO belt tension are adjusted using the clutch actuator rod. Initially, after installing a new PTO belt, **after 10 hours and every 100 hours** thereafter, check and adjust for the three dimensions in the clutch linkage as shown.

Adjust the bolt head clearance [1/4 in. to 3/8 in. (6.35 mm to 9.53 mm)] first, then adjust spring length. If adjustments are needed more frequently than 100 hours to maintain the linkage dimensions, it may suggest problems with pulley wear or belt misalignment.



**Clutch Linkage Adjustment - Disengaged**



**Clutch Linkage Adjustment - Engaged**

## Transmission Control


**IMPORTANT:** The proper adjustment of the transmission control stops is **essential** for efficient operation and life of the transmission. These stops are properly adjusted at the factory and should only require readjustment if the transmission or related control linkage is removed or changed.

**NOTE:** It would not be unusual for a new machine, after initial 5 or 10 hours of operation, to begin to not travel straight (this is due to the break-in of the transmissions). In this case, proceed to *Straight Ground Travel Adjustment - Step 4*.

**IMPORTANT:** The following adjustment procedures are sequential. Check and adjust each function in the order given.

### Set Forward Travel Limit (Stop) - Step 1

1. Move the Forward Speed Control (FSC) lever to the most **FORWARD** position.
2. Check clearance of the RH and LH steering lever actuator arms with the frame and **adjust forward stop bolt** so each lever clears the frame by at least 1/16 in. (1.6 mm). Clearance of the arm to the frame should be checked while **applying pressure back** on the arm to remove any slack in the linkage.
3. Tighten the jam nut on the forward travel stop adjusting bolt.



**Forward Speed Control Stop and Steering Lever Adjustment**

### Steering Lever End Play Adjustment - Step 2

1. Position the FSC lever to the most **FORWARD** position.
2. Loosen the adjustment nut on each steering lever actuator until end play develops between the lever actuator and the adjustment nut (sliding on transmission control rod).
3. Hold the actuator back as shown (against the spring pressure) and tighten the nut to the point where the end play is removed and **then tighten two additional turns**.

**IMPORTANT:** If the **adjustment nut is too loose** (end play exists) excessive loads are placed on transmission internal control stops. If the **adjustment nut is too tight** (preferred condition), the maximum forward travel speed is reduced.


### Neutral Function Adjustment - Step 3

1. Move the FSC lever to the **NEUTRAL-PARK** position (rear travel limit).
2. Start the engine (operate first at idle and then normal operating speeds) and **check for movement of the drive wheels**.

**NOTE:** If the engine will not start, check and adjust the neutral safety switch (see item 4 below).

### CAUTION

**NEVER attempt to disconnect any safety devices or defeat the purpose of these safety devices.**



**Neutral Function Adjustment**


3. If drive wheels are moving, stop the engine and **adjust the FSC neutral stop** by adjusting the FSC actuator clevis (see **Neutral Function Adjustment** photo for clevis location). If the drive wheels are moving backward, remove the cotter pin and clevis pin and screw the clevis forward. If the drive wheels are moving forward, screw the clevis backward. Restart the engine and check for wheel movement (several “trial and error” adjustments may be required). At this point it may **not be possible** to adjust **both** wheels stationary since the differential adjustment has not been made. (This is covered by the *Straight Ground Travel Adjustment - Step 4.*) In this case, the neutral adjustment should be made for one wheel stationary and the other moving **forward** slightly.
4. Check and **adjust the neutral safety switch** for closure and function with the FSC in neutral (the engine will not start when the switch is open). Use panel nuts on the switch body to adjust switch position for closure in neutral. Refer to adjustment description for **Safety Switches** in this section.

### *Straight Ground Travel Adjustment - Step 4*

1. Sit in the seat, start the engine (operate at normal speed), and with the FSC in the **NEUTRAL-PARK** position check for **forward movement** of either drive wheel (if either wheel moves **backward**, refer back to *Neutral Function Adjustment - Step 3* and readjust). **Tighten the steering lever adjustment nut on the side of the mower with the wheel moving forward until wheel movement stops.**
2. Check for straight ground track on a **level surface** (with **hands off** the steering levers). Set the FSC at several different speeds and observe if the mower moves in a straight line (use cement joint or other line on ground for reference).

**NOTE:** The final tracking adjustment is made with the mower moving, since the adjustment is quite sensitive and is more easily “fine tuned” when moving.


3. If travel is not straight, **tighten the adjustment nut that is on the same side of the mower as the wheel that is moving too fast**, e.g., the mower tracks to the right, indicating the LH wheel is moving too fast, tighten the LH adjustment nut.



**Straight Ground Travel Adjustment**

### **Forward Speed Control Friction Lock**

The FSC friction lock is adjusted to **hold the selected forward speed** when the steering levers are moved and yet the friction is not too heavy to make **moving the control difficult** (too much friction). The procedure for checking and adjusting the FSC friction lock is as follows:



**Forward Speed Control Friction Lock**



1. Place the FSC in the full **FORWARD** position and pull both steering levers back; the FSC lever should not move. If the FSC lever moves back when the steering levers are pulled back, the **friction needs to be increased**.
2. With the steering levers held back, move the FSC lever back from the **FORWARD** position. With a proper amount of friction adjusted, the FSC lever should move back with a slight amount of resistance (friction). If the FSC lever movement is "stiff", the **friction needs to be decreased**.
3. The FSC friction is **increased** or **decreased** by **tightening** or **loosening** the **friction adjustment nut**. Loosen or tighten the nut and check the control function until conditions of both steps 1 and 2 (above) are met.


### Fuel Valve Solenoid Linkage - Model MDD

To prevent damage to the fuel valve solenoid, the linkage to the engine must be adjusted so the solenoid bottoms out before the control arm on the engine contacts its stop (when the engine is running). A solenoid that does not bottom out when the engine is running will become overloaded and burn out.

**IMPORTANT:** The solenoid linkage should be checked and adjusted any time the solenoid is removed and replaced (either reinstalling an existing solenoid or installing a new replacement).

Check and adjust the solenoid linkage as follows:

1. Manually pull the fuel valve open and check the gap between the control arm on the injector pump and the stop. The required gap is approximately 1/16 in. (1.6 mm).



**Fuel Valve Solenoid Linkage Adjustment - (MDD)**

2. If the gap is **incorrect**, adjust the linkage by **loosening** the jam nut at the solenoid, removing the cotter pin and washer from the connection to the fuel valve control arm, and screwing the linkage rod in or out of the solenoid as required.
3. After adjusting the linkage for the proper gap, turn the ignition key **ON**, and check the gap by operating the solenoid.

### Carburetor - Model MDG

#### **CAUTION**

**DO NOT change the engine governor settings or overspeed the engine. The governor has been factory-set for maximum-safe engine operating speed.**

Carburetor adjustments are required to compensate for differences in altitude, temperature, and fuel. Once the carburetor has been set, no further adjustments should be required. However, if the engine exhibits any of the following symptoms, the carburetor adjustment should be checked: black, sooty exhaust smoke, lack of power, engine miss or backfire, hard to start, rough running or idle.

**NOTE:** Also refer to the Kubota Workshop Manual for detailed carburetor adjustment information.

#### **CAUTION**

**ALWAYS use the proper engine service manual when working on the engine. Unauthorized maintenance operations or modifications to the engine MAY result in unsafe operating conditions.**


**NOTE:** The air cleaner and air intake hose must be connected to the carburetor when adjusting the carburetion.

The carburetor main jet on Model MDG is **fixed** (non-adjustable). For operation above 5000 ft (1,524 m) above sea level, the carburetor main jet should be changed for best fuel economy and power. Contact an authorized Kubota engine dealer to change the carburetor main jet.

To adjust the carburetor for engine idle, use the following procedure:

1. Gently close the idle mixture needle valve screw by turning it **clockwise** until it bottoms lightly.

**IMPORTANT:** The needle valve and carburetor seat may be **damaged** by turning the adjustment screw **too tight**.



**Carburetor Adjustment - (MDG)**

2. Preliminary Setting: Turn the idle mixture needle valve out (counterclockwise) 1-1/2 turns from the closed position. This **initial adjustment** will allow the engine to be started and warmed up prior to the final adjustment.

**⚠ DANGER**

**The engine must be running to adjust the carburetor for engine idle. To guard against injury, keep hands, feet, face, and other parts of body away from the muffler/exhaust pipe, other hot parts of the engine, and moving or rotating parts of the engine.**

3. Start the engine and allow it to warm up for approximately five (5) minutes.

4. Move throttle to the **IDLE** position. Adjust idle speed for 1200 RPM by adjusting the idle speed screw on the carburetor butterfly valve (throttle). Check the idle speed using a tachometer.
5. With the engine idling, adjust the idle mixture by turning the needle valve in until the engine slows (clockwise - lean mixture). Then turn the needle valve out past the smooth operating point until the engine slows again (counterclockwise - rich mixture). Now turn the needle valve to midpoint between rich and lean mixture. Check engine acceleration from the idle. If the engine will not accelerate properly, readjust the idle mixture, usually to a slightly richer mixture (open the valve).
6. Recheck idle speed after the final idle mixture adjustment.

**GHS "Full" Signal Horn with Grass-Pak Switch**

If the GHS "full" signal horn is not sounding or is not adjusted to sound when the catcher is full, the following troubleshooting and adjustment instructions apply:

*Troubleshooting (When Horn Fails to Operate)*

1. Check the horn.
  - a. Disconnect the two wires from the Grass-Pak switch electric connector plug and make a jumper wire connection between these wires (bypassing switch).
  - b. Turn the ignition switch **ON** and move the blade clutch to the **ENGAGED** position (engine not running) to make the horn sound.
  - c. If the horn does not sound, the horn is bad and needs to be replaced.
  - d. If the horn does sound, proceed to step 2.
2. Check the Grass-Pak switch.
  - a. Reconnect the wires to the Grass-Pak switch electric connector plug.
  - b. Turn the ignition switch **ON** and move the blade clutch to the **ENGAGED** position (engine not running).

- c. Open the catcher back door and trigger the Grass-Pak vane by hand as it oscillates.

**WARNING**


**PINCH POINT - SPRING LOADED DOOR**

When lowering the door on the GHS catcher, depress the safety latch on the side of the catcher as the door closes. The springs that hold the door closed during operation are very powerful, and the door CAN slam shut with considerable force.

**WARNING**

DO NOT test the Grass-Pak switch with the engine running. Projectiles CAN be thrown out of the grass delivery spout and CAN cause serious injury to bystanders or property damage .

- d. The horn should sound as the switch is moved in both directions. If the horn does not sound, the switch is bad and needs to be replaced.




**Checking the Grass-Pak Switch**

*Adjustment (When Horn Sounds at the Wrong Time)*

Very little, if any, adjustment to the Grass-Pak switch is required. However, to fine tune the timing of the full signal, **the vertical position of the switch vane is adjustable approximately 3/4 in. (1.9 mm).**

1. Loosen the screw mounting the vane on the switch and adjust the position of the vane as follows:
  - a. Move the vane **UP** to **delay** the signal.
  - b. Move vane **DOWN** to **advance** the signal.
2. Retighten the screw.

**NOTE:** It will not be possible to adjust the switch to give a signal at the precise instant the catcher is full for a wide variety of mowing conditions. For example, wet heavy grass will fill the catcher differently than dry, fluffy grass, causing the signal to come on a little sooner or later than usual. Primarily, the switch should be adjusted to give the "full" signal with a **little advance warning before overflowing and clogging** of the grass delivery chute begins (regardless of mowing conditions).



**Grass-Pak Switch Vane Adjustment**

## ELECTRICAL SYSTEM

For troubleshooting, refer to **Wiring Diagram** for either Model MDD or Model MDG.


**IMPORTANT:** Disconnect both battery cables before unplugging any wiring connectors or making repairs on the electrical system.

**IMPORTANT:** Disconnect the battery cables before unplugging and removing the instrument panel.


### Circuit Breakers

Location	Reset Amperage	Circuits (Electrical Load)
Master Circuit Breaker Mounted on Bracket Behind Battery	40 AMP - MDD 20 AMP - MDG	<ul style="list-style-type: none"> <li>- Instrument Panel</li> <li>- Starter Solenoid</li> <li>- Fuel Pump</li> <li>- Glow Plugs (MDD Only)</li> <li>- Pull Circuit, Fuel Valve Solenoid (MDD Only)</li> </ul>
Instrument Panel	5 AMP	<ul style="list-style-type: none"> <li>- Panel Gauges</li> <li>- Warning Lights/Horn</li> </ul>
Instrument Panel	10 AMP	<ul style="list-style-type: none"> <li>- Headlights</li> <li>- Safety Switch Relays and Time Delay Module</li> <li>- Hold Circuit, Fuel Valve Solenoid (MDD Only)</li> <li>- Powerfil Motor (GHS Only)</li> <li>- "Full" Signal Horn (GHS Only)</li> </ul>

## Wiring Diagram - Model MDD



## Wiring Diagram - Model MDD



# LIMITED WARRANTY FOR WALKER COMMERCIAL RIDER MOWER

## 1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within one (1) year\* after date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine  
Kubota Engine  
Kawasaki Engine  
Eaton Hydraulic Transmission  
Peerless Gearboxes  
Battery  
Tires

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

\* An extended three (3) year warranty is offered on the Walker P/N 6200 Gear Axle Assembly.

## 2. WHAT THIS WARRANTY DOES NOT COVER:

- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Owner's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

## 3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80525. Proof of the date of purchase may be required to verify warranty coverage.

## 4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### *Sound - Model MDD*

#### Sound Test

**Lwa**  
**106**

Sound test conducted was in accordance with 79/113/EEC and was performed on 22 March 96 under the conditions listed:

**LpA**  
**96**

OPERATOR

General Condition: Clear  
Temperature: 50 (F)°10 (C)°  
Wind Speed: < 5 mph (< 8 kmh)  
Humidity: 52%  
Barometric Pressure: 24.9" HG (759 mm Hg)

### *Sound - Model MDG*

#### Sound Test

**Lwa**  
**102**

Sound test conducted was in accordance with 79/113/EEC and was performed on 22 March 96 under the conditions listed:

**LpA**  
**95**

OPERATOR

General Condition: Clear  
Temperature: 50 (F)°10 (C)°  
Wind Speed: < 5 mph (< 8 kmh)  
Humidity: 52%  
Barometric Pressure: 24.9" HG (759 mm Hg)

### *Vibration - Model MDD*

#### Vibration Level

**0.7g**

Vibration levels at the operators handles were measured in the vertical, lateral, and longitudinal directions using calibrated vibration test equipment.

Tests were performed on 22 March 96 under the conditions listed:

General Condition: Clear  
Temperature: 50 (F)°10 (C)°  
Wind Speed: < 5 mph (< 8 kmh)  
Humidity: 52%  
Barometric Pressure: 24.9" HG (759 mm Hg)

### *Vibration - Model MDG*

#### Vibration Level

**0.2g**

Vibration levels at the operators handles were measured in the vertical, lateral, and longitudinal directions using calibrated vibration test equipment.

Tests were performed on 22 March 96 under the conditions listed:

General Condition: Clear  
Temperature: 50 (F)°10 (C)°  
Wind Speed: < 5 mph (< 8 kmh)  
Humidity: 52%  
Barometric Pressure: 24.9" HG (759 mm Hg)

# WALKER MOWERS

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80525 • (970) 221-5614  
FORM NO. 092795 PRINTED IN USA ©1996 WALKER MFG. CO