




VRP[®] Variable Refrigerant Packaged Heat Pump - 36000 BTU

Innovative | Intelligent | Inverter



36000 BTU

For Commercial and Residential Applications

One or more of the following patents may apply:

10408504
10436457
10488083
10731899

Additional patents pending



Table of Contents

Warnings	3
----------	---

General

Specifications	4
Dimensions	5
Electrical Data	6
Air Flow Data	7

Installation

Minimum Clearances	8
Installation Orientations	9
Rough Opening Dimensions	10
Wall Plenum Installation	12
Louver Installation	16
Unit Installation	18
Drain Installation	21
Ductwork Installation & Base Pan Heat	22
Wall Controller Installation	23
Electrical Connection	25
Return Air Door Installation	26
FreshAire™ System Set-Up and Operation	27

Reference

Electrical Wiring Diagrams	28
Final Installation Checklist	29
Service and Warranty	30
Accessories	31
Diagnostic Error Codes	33
VRP Limited Warranty	34

Congratulations!

The Friedrich VRP has been carefully engineered and manufactured to provide many years of dependable, efficient operation while maintaining a comfortable temperature and humidity level. Many extra features have been built into the unit to ensure quiet operation, optimal circulation of cool, dry air, and the most economic operation.

Please carefully read and follow the installation instructions and safety warnings detailed in this manual. All applicable national and local mechanical and electrical codes should be followed and take precedence over any Friedrich requirements or recommendations regarding installation applications detailed in this manual.



WARNING

Please read this manual thoroughly prior to equipment installation or operation. It is the installer's responsibility to properly apply and install the equipment. Installation must be in conformance with the NFPA 70-2008 National Electric Code or current edition, International Mechanic code 2009 or current edition and any other applicable local or national codes.

WARNING

Refrigeration system under high pressure. Do not puncture, heat, expose to flame or incinerate. Only certified refrigeration technicians should service this equipment. R410A systems operate at higher pressures than R22 equipment. Appropriate safe service and handling practices must be used. Only use gauge sets designed for use with R410A. Do not use R22 gauge sets. Failure to do so can result in property damage, personal injury, or death.



WARNING



Electrical shock hazard.

Turn OFF electric power before service or installation. Unit must be properly grounded. Unit must have correct fuse or circuit breaker protection. Unit's supply circuit must have the correct wire conductor size. All electrical connections and wiring must be installed by a qualified electrician and conform to the National Electrical Code and all local codes which have jurisdiction. Failure to do so can result in property damage, personal injury and/or death.

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety Alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others. All safety messages will follow the safety alert symbol with the word "WARNING" or "CAUTION". These words mean:

WARNING

Indicates a hazard which, if not avoided, can result in severe personal injury or death and damage to product or other property.

CAUTION

Indicates a hazard which, if not avoided, can result in personal injury and damage to product or other property. All safety messages will tell you how to reduce the chance of injury, and tell you what will happen if the instructions are not followed.

NOTICE

Indications property damage can occur if instructions are not followed.

THINK SAFETY FIRST

⚠ WARNING

Do not remove, disable or bypass this unit's safety devices. Doing so may cause, fire, injuries or death.

⚠ AVERTISSEMENT

Ne pas supprimer, désactiver ou contourner cette l'unité des dispositifs de sécurité. faire vous risqueriez de provoquer, le feu, les blessures ou la mort.

⚠ ADVERTENCIA

No eliminar, desactivar o pasar por alto los dispositivos de seguridad de la unidad. Si lo hace podría producirse fuego, lesiones o muerte.

General Specifications


Nomenclature

V	R	P	3	6	K	0	0	S	S	C	S	-A
Series												Engineering code
VRP Heat Pump												S - Standard L = Low Ambient Heat
Nominal Capacity (Btu /Hr.)												Plenum and louver configuration C= Only for 36000 Btu units
36 = 20,000 - 36,000												
Voltage												S= Standard
K = 230/208 V												
Heater watts												Outdoor Air/ Ventilation** S= Standard unit. No FreshAir™ F= Single OA Fan Powered FreshAir System 80 CFM D= Dual OA Fans Powered FreshAir System 130 CFM
00 = 0.0 kW												
10 = 10.0 kW												
15 = 15.0 KW												

Model	VRP36K
Cooling Performance Data (Cooling Standards: 95°F DB/75°F WB outdoor, 80°F DB/67°F WB indoor)	
Voltage	230/208
Cooling Btu (Rated)	33,400
Cooling Btu (Min. - Max)	20,000 - 36,000
Outdoor Operating Range (°F)	55 - 115
Power (W)	2990
SEER	15.5
EER	10.9
Sensible Heat Ratio	0.76
Cooling Amps	14.2
Heat Pump Performance Data	
Voltage	230/208
Heating Btu (Rated @ 47° F)	28,500
Heating Btu (@ 17° F)	18,300
Heating Btu (Min. - Max.)	16,000 - 30,000
Heat Pump Outdoor Operating Range (°F)*	0 - 70
COP (Rated @ 47° F)	3.25
HSPF	8.6
Heating Power (W)	2570
Heating Amps	12.26

Due to continuing research in new energy-saving technology, specifications are subject to change without notice.

Dimensions



Model	VRP36K
Dimensions (W x D x H)	31 3/4" x 29 7/8" x 77 1/4"
Shipping Dimensions (W x D x H)	34" x 35" x 81"
Net Weight (lbs.)	330
Shipping Weight (lbs.)	357
R410A Charge (oz.)	125

Electrical Data

VRP Model	Voltage	Electric Heater Watts	Electric Heating Btu	Electric Heater Amps	MCA	MOP / MOCP
VRP36K00	230	0	0	0	18.2	30
	208	0	0	0		
VRP36K10	230	8820	30090	38.3	49.2	50
	208	7210	24600	34.7		
VRP36K15	230	13230	45120	57.5	49.2 / 24.0	50 / 25
	208	10820	36900	52		

MCA = Minimum Circuit Ampacity

MOP / MOCP - Maximum Over-current Protection / Breaker Size

Minimum Circuit Amps (MCA) and MOCP values in the above table are calculated in accordance with The NEC Article 440

NOTE: 15 kW electric heat models require dual service (50A + 30A)

Electrical Requirements	
Wire Size	Use ONLY wire size recommended for single outlet branch circuit.
Fuse/Circuit Breaker	Use ONLY type and size fuse or HACR circuit breaker indicated on unit's rating guide. Proper over current protection to the units is the responsibility of the owner.
Grounding	Unit MUST be grounded from branch circuit to unit, or through separate ground wire provided on permanently connected units. Ensure that branch circuit or general purpose outlet is grounded.
Wire Sizing	Use recommended wire size given in tables and install a single branch circuit. All wiring must comply with local and national codes. NOTE: Use copper conductors only.

Electrical Rating Table

NOTE: Use copper conductors **ONLY**. Wire sizes are per NEC.

Recommended Branch Circuit Sizes*	
Nameplate Maximum Circuit Breaker Size	AWG Wiring Size**
25A	10
30A	10
50A	6
60A	6

AWG - American Wire Gauge

* Single circuit from main box.


** Based on 100' or less of copper, single insulated conductor at 60° C

NOTE: All field wiring must comply with NEC and local codes. It is the installer's responsibility to ensure that the electrical codes are met.

Air Flow Data

Indoor CFM & External Static Pressure

Model	VRP36K	
Air Flow Data		
Indoor CFM	Low	High
.15" ESP *	1015	1200
.20" ESP	875	1160
.30" ESP - Max @ Low Speed	750	1080
.40" ESP	565	970
.50" ESP - Max @ High Speed	440	835
* Rated at 0.15" ESP, High and includes 0.08" ESP for factory installed 1" filter		



Condenser CFM & External Static Pressure

VRP is designed to install through an exterior wall with a plenum (VRPXWP*-8, VRPXWP*-14) and a Friedrich external louver .

Condenser External Static Pressure			
VRP Model	Design		Maximum
	CFM	ESP ("WC)	ESP ("WC)
VRP36K	2030	0.03	0.20

If the Friedrich designed plenum and louver combinations are not used, the selections and design must be evaluated by Friedrich to ensure the total pressure drop does not exceed the maximum allowable limits.

VRP® Required Minimum Clearances

Building Exterior Unit Opening Requirements

VRP units must be installed on an outside wall. Confined spaces and/or covered areas should be avoided. Units must be installed no closer than 12" apart when two units are side by side. If three or more units are to operate next to one another, maintain a minimum of 60" between units or pairs of units (Figure B). If more than two units are sharing a floor with adjacent, outset units, a minimum distance of 64" must be kept between units (Figure C). Also, a vertical clearance of 60" must be maintained (Figure A) between units. Units installed on the bottom floor must be mounted at least 6" off of the ground.




Figure A




Figure B




Figure C





Figure D

Grill Clearance Requirements

Where obstructions are present use the following guidelines for proper spacing from the VRP exterior louvered grill. Friedrich recommends that ALL obstructions are a minimum of 72" from the exhaust.


For minor obstruction(s) such as lamp poles or small shrubbery, a clearance of 24" from the outdoor louver must be maintained.

For major obstructions such as a solid fence, wall, or other heat rejecting devices like a condensing unit, a minimum distance of 72" must be kept.



The example pictured above is for reference only and does not represent all possible installations. Please contact Friedrich Air Conditioning for information regarding effects of other installation arrangements.

Installation Orientation




NOTE: The VRP 3-ton unit comes equipped with bi-directional casters for ease of movement. The casters only allow for movement forward and backward. The VRP 3-ton should be installed with the access door positioned in front of the unit.

Exterior Wall Opening Dimensions

Exterior Wall Rough Opening Dimensions		
Unit	Width	Height
VRPXWPC-*	32 1/4"	52 1/2"

NOTE: The distance between the rough opening and the finished floor/platform must be 2 7/8".




Interior (Closet) Wall Opening Dimensions

Return Air Access Door Wall Cut-Out

Interior Wall Rough Opening Dimensions		
Unit	Width	Height
VRP36	36"	84"

NOTE: Dimensions based on standard 36" door frame.




Wall Plenum Installation

Parts included in Plenum kit:


Outside Plenum (Part A)
Inside Plenum (Part B)

Divider (Part C)
Baffle (Part D)


Outside Plenum
(Part A)




Inside Plenum
(Part B)



Divider
(Part C)



Baffle
(Part D)




Field Supplied Parts:

Sealant, attachment screws, and flashing are field supplied. Silicone sealant is recommended.


VRPXWPC-8 adjusts for walls 4" - 8" thick.

VRPXWPC-14 adjusts for walls 8" - 14" thick

All installations are similar.



Sealant



Flashing




Shim



1"-3" Screws to attach the plenum assembly to the wall studs

Wall Plenum Installation

Step 1 - Outside Wall Plenum Half




Note: The wall plenum is not designed to carry any structural load. A load bearing header must be built above the rough opening.

- 1) Prepare the rough opening. The rough opening should be lined with metal or wood. The plenum will warp if sealed against concrete or brick.
- 2) Dry fit the outside plenum half into the rough opening and check the fit and level.
- 3) Remove the outside plenum half, flash the rough opening to ensure proper fit and level.
- 4) Pre-installing the exterior louver as shown above is optional (See Page 17).
- 5) Apply sealant to the outside plenum half and insert into the rough opening to ensure a water-tight seal. Ensure that the outside plenum half is securely attached to the framed opening.


Wall Plenum Installation

Step 2 - Inside Wall Plenum Half



Detail A


Apply Sealant to all 4 flange corners and unused holes.



- 1) Apply sealant to all 4 flange corners and unused holes. See Detail A.
- 2) Flash the inside of the rough opening to ensure the proper fit and level.
- 3) Insert inside plenum half (Part B) into Outside Plenum Half (Part A). Ensure that Part A does not back out of the rough opening.
- 4) Remove the inside plenum half.
- 5) Apply sealant to the inside plenum half and insert into the rough opening to ensure a water-tight seal.

Wall Plenum Installation

Step 3 - Inside Wall Plenum (cont.)




Note: Do not place any screws, fasteners, or penetrating holes through the top or bottom of the plenum assembly.

- 1) Drill pilot holes on the interior of the inside plenum half (Part B) as show in Detail A. Pilot holes should be located approximately 4" from the top and bottom of the inside plenum half, on both the left and right sides.
- 2) Install fasteners through each pilot hole. Fastener must pass through both Part A and Part B. If the inside and outside plenum halves do not overlap at fastening point, be certain to drill extra holes where needed to secure both Part A and Part B to the rough opening.

Louver Installation

Installation of the louver PRIOR to Wall Plenum Installation

Hold the louver up to the Outside Wall Plenum Part A and line up the louver top with the very top edge of the 3/4" flange. Line up the Wall Plenum holes with the threaded holes in the louver, install and tighten the 8 screws.




NOTE: Louvers & Drip Ledge orientation is down

Optional Pre-assembled Outside Element (Grill and Plenum)

Installation of the louver AFTER the installation of wall plenum on elevated floors


From the interior of the utility closet:

- 1) Tie a rope or tether to the architectural louver and the divider in the wall plenum to prevent it from falling if dropped.
- 2) Turn the louver sideways and push the louver out below the divider in the wall plenum.
- 3) Pull the louver back against the wall plenum and align the holes.
- 4) Insert and tighten all eight provided fasteners. When the louver is secured, remove the safety tether.




Final Wall Plenum and Architectural Louver Installation

Plenum Divider Extension Plate (Baffle)



Plenum Divider Extension Plate Installed into Full Plenum Assembly




Ensure that the weather strip is undamaged and provides a continuous seal around the inner perimeter of the plenum.

Apply silicone grease or other non-petroleum-based lubricants to the weather strip to enhance the sealing capability of the weather strip and ease installation of the air conditioner chassis.

- 1) Install the plenum adjuster plate. Ensure the exterior edge is seated against the inside of the architectural louver.
- 2) Secure the plenum divider extension plate to the architectural louver using the two provided screws.
- 3) Use tape and sealant to seal any gaps.

Unit Installation


Unit Placement Prior to Installation (Front-Install Configuration)



All louver, plenum, rough plumbing, and rough wiring steps must be complete prior to final installation of the air conditioning chassis.

Final Unit Installation Overview



Unit Final Placement - Front Install



- 1) Ensure that power is off at the junction box feeding power to the air conditioner until all process steps are completed.
- 2) Move the unit from the shipping base and onto the installation site.
- 3) Insert the unit's rear extension into the wall plenum, it should butt up against the compression gasket.
- 4) Remove the front panel to access the chassis clamps. Attach the hooks into the plenum braces and close.
- 5) Reattach the front panel.
- 6) Identify the appropriate drain port to use and complete plumbing (See Page 22).
- 7) Attach the ductwork to the unit at the supply-air outlet and ensure the seal is air tight (See Page 23).
- 8) Wire and connect the wall controller (See Pages 24-27).
- 9) Connect the main power (See Page 25).

Final Unit Installation Overview

Unit Final Placement - Plenum Attachment




DETAIL A
SCALE 1 / 2

- 1) Ensure that power is off at the junction box feeding power to the air conditioner until all process steps are completed.
- 2) Ensure that the unit is pushed flush against the start of the wall plenum.
- 3) Remove the front panel from the unit.
- 4) Reach under and behind the electrical box and locate the panel mounted fasteners (Detail A). There is one on each of the left and right interior panel.
- 5) Align the hook of each fastener with the brackets mounted on the interior portion on the wall plenum.
- 6) Pull back on the fastener handles until locked.

NOTE: Once the unit is fastened there should be a gap of at least 1" between the unit and finished wall

Final Drain Installation


Unit Drain Installation



NOTE: Failure to follow the following procedures may result in serious property damage. A field supplied secondary condensate pan may be required. Check with local codes. In case of drainage system blockage, the unit base will allow excess water to flow out of the unit through the plenum and the architectural louver. It is critical to ensure that the drainage path is not blocked or obstructed in any way during installation.

- 1) The supplied drain kit must be connected to one of the two (left or right) 3/4" FPT connections on the unit base-pan.
- 2) Insert the provided 3/4" nipple into the determined connection using field-supplied Teflon tape or pipe joint compound.
- 3) With the slip end of a 3/4" union, connect to the nipple with Teflon tape or pipe joint compound.
- 4) Hand-tighten all fittings to prevent damage to unit or fittings.
- 5) Install a field-supplied drain system to the slip end of the union. A trap is required and drain connections should be connected to building DWV system. Pitch the drain line of a 1/4" downward slope for every foot (1') of lateral horizontal run to the DWV.
- 6) Plug the unused connection port with the provided 3/4" pipe plug and field-supplied Teflon tape or pipe joint compound. High tighten to prevent damage to the unit or fittings. Do not thread metal or copper pipe fittings directly into unit.
- 7) Check the system for leaks.

Ductwork Installation & Base Pan Heat Option



Supply air duct connection is the responsibility of the installer and should be installed per industry best practices.

Supply discharge area is 8 1/16"D x 26 1/16"W.

Sheet metal or duct board may be used for the transition from the discharge to 10" or larger diameter flexible ducting.

Avoid sharp transitions in the ductwork to ensure optimal indoor blower performance.

Allow at least 18" from the discharge of the unit to the final reduced-size transition to support optimal efficiency of the blower system.

Basepan Heat Thermostat

VRP model numbers that end with the 'L' character will come equipped with a basepan heater. The basepan heat engages and disengages automatically based on outdoor ambient and base-pan temperatures.

Wall Controller Installation

Proper Wiring of VRP unit to Wall Controller

Use shielded and stranded CAT 6 cable with twisted pairs to wire the wall controller. Use the wire colors with the corresponding terminals on the wall controller to the VRP unit as shown in the table below.












Wire Color		Label
Orange		V +
Green / White		
Brown		D +
Blue / White		
Blue		D -
Brown / White		
Green		V -
Orange / White		
Ground Shield Wire		GND



Table shows which wire pairs go with which screw terminal.

Wall Controller Installation



WIRE COLOR		LABEL
Orange		Connection 1
Green/White		V+ Orange
Brown		Connection 2
Blue/White		D+ Brown
Blue		Connection 3
Brown/White		D- Blue
Green		Connection 4
Orange/White		V- Green
Ground Shield Wire		GND


1. Strip and untwist the individual CAT 6 wires.
2. Pair the wires on both ends based on the combinations detailed in the table above.
3. Pair one end of the twisted pairs with the corresponding single wire on the controller using the provided pairing clamps.



4. Remove the filter from the unit and unplug the green molex controller plug.
5. Insert the corresponding color pair into the appropriate screw terminal and tighten.
6. Insert the sheath into the "GND" screw terminal and tighten.
7. Plug in the green molex plug into the green receptacle and re-install the return air filter.



NOTE: These steps are to be followed for use with the VRPXEMRT2, VRPXEMWRT2, and VRPXWCT.

Electrical Installation



Remove and discard hole knock-out from the side of the unit (Detail A)


NOTE: Only one punch-out needs to be removed for 0.0 kW and 10.0 kW models.. Both punch-outs must be removed on the 15.0 kW models for dual service.



Remove the front access panel (Detail A) to expose the electrical box and incoming Power terminal block (see below)


B

Ground L1 L2



A

Ground L1 L2



Insert all wires through the punched out hole(s) and fasten wires as shown.



The 0kW and 10kW models will require the use of only one of the terminal blocks (Block 'A'). The 15kW models will connect the extra 5kW electric heat to the remaining terminal block (Block 'B') and separate 30A service.

Return Air & Door Installation



1. A 36" door louvered door is recommended for all VRP36 installations.
2. The louvered portion of the door should have a minimum of 325 sq. in. of free area.
3. Alternatively, a solid door may be used in tandem with a transfer register on an adjacent wall to the closet. The transfer register should have a minimum free area of 325 sq. in.

FreshAire™ System Set-Up and Operation




If equipped with the FreshAire™ System, the unit will come with a FreshAire filter and blank-off plate.


Remove the blank-off plate prior to turning the unit on.

To remove the blank off plate, pull the attached tab shown in Detail A. The blank-off plate can be discarded or retained for future use.


To engage the FreshAire™ System, flip the switch into the ON position. The fresh air switch is located behind the return air filter.



Electrical Wiring Diagram - 208/230V



Final Installation Checklist

⚠ WARNING	
	<p>Electrical Shock Hazard</p> <p>Pull out electrical disconnect on front of the chassis and turn off all power to the unit before servicing.</p> <p>Failure to do so can result in property damage, personal injury and/or death.</p>

- Inspect and ensure that all components and accessories have been installed properly and that they have not been damaged during the installation process.
- Ensure that all installation instructions concerning clearances around the unit have been adhered to.
- Check to ensure that the unit air filter, indoor coil, and outdoor coil are free from any obstructions.
- Ensure that the circuit breaker(s) or fuse(s) and supply circuit wire size have been sized correctly.
- Check the condensate water drain(s) to ensure that they are adequate for the removal of condensate water and that they meet approval of the end user.
- Ensure that the entire installation is in compliance with all applicable national and local codes and ordinances having jurisdiction.
- **ENSURE THAT THE SUPPLY VOLTAGE TO THE UNIT IS WITHIN THE OPERATING RANGE**
- Secure all access panels (i.e. front cover and/or control box), apply power to the unit. The unit commissioning should be done at this time to ensure unit function.

NOTE: Maintaining a log for recording the dates of maintenance and/or service is recommended, and should be suggested to the owner or operator of the equipment.

- Present the owner or operator of the equipment with the Installation & Operation Manual, all accessory installation instructions, and the name, address and telephone number of the Authorized Friedrich Warranty Service Company in the area for future reference if necessary.

Chassis Operation

Cooling Operation

The set point must be at least 3°F below room temperature to ensure compressor operation. In the cooling mode, when demand is present, the indoor blower and outdoor fan will operate. The compressor will vary operating speed to maintain desired set point.

Heat Pump Operation

The set point must be greater than 0.3°F but not greater than 6°F above room temperature to ensure compressor operation. In the heating mode, when demand is present, the indoor blower and outdoor fan will operate. The compressor will vary operating speed to maintain desired set point.

Electric Heat Operation

If the set-point is greater than 5°F - 15°F (depending on outdoor conditions) above room temperature, the heat pump operation will be terminated and the electric heater will be energized to satisfy the heating demand. If heat pump operation is not available due to defrost or error, the electric heater will be used to satisfy heating demand. In 10kW and 15kW models, 5kW of electric heat will be allowed to run concurrently with the compressor.

FreshAir™


The FreshAir™ System (optional) delivers outside air to the indoor space. The system has a fan that draws outdoor air into the system. The outdoor air leaves the system through a filter and enters the indoor space in front of the indoor conditioning coil. The outdoor air mixes with the return air and is drawn through the indoor conditioning coil. The optional system can be configured to have either a single (F option) outdoor air fan and filter, or dual (D option) outdoor air fans and filters.

The FreshAir™ System uses two (2) 6 x 6 x 1. The filters are accessed through the front of the unit just below the main unit filter. Slide the filter straight out to remove and straight in to replace.

Service & Warranty


Servicing / Chassis Quick Change Outs

The chassis is designed for quick disconnect and change out. For minor electrical service, the Electrical Access Panel is easily removable once the screws are removed. For major electrical, refrigeration and fan service the chassis may be removed from utility closet.

⚠ WARNING	
	Electrical Shock Hazard Pull out electrical disconnect on front of the chassis and turn off all power to unit before servicing. Failure to do so can result in property damage, personal injury and/or death.

Routine Maintenance Performing Routine Maintenance

With proper maintenance and care, your system will operate economically and dependably. Maintenance can be accomplished easily by referring to the following directions. However, before performing any maintenance, see above stated WARNING.

⚠ CAUTION	
	Cut/Sever Hazard Some edges may be sharp, use gloves or other hand protection when handling unit. Failure to do so can result in minor to moderate personal injury.

Replace Air Filter

A dirty air filter reduces the efficiency of your VRP unit and allows lint and dirt to accumulate on the indoor-air coil. Lint and dirt on the indoor-air coil can damage your unit.

The air filter should be replaced as it becomes dirty.

To replace the chassis mounted return air filter:

1. Slide the holders away from the filter.
2. Remove the filter.
3. Install a new disposable filter.
4. The unit filter size is 20" x 30" x 1"

NOTE: DO NOT OPERATE YOUR SYSTEM WITHOUT A FILTER IN PLACE OR BLOCK THE FRONT OF THE UNIT RETURN AIR OPENING.

To Remove the Chassis from the Closet:

- A. Switch the wall controller off.
- B. Disconnect the power coming into the unit from the main breaker panel or the closet mounted disconnect.
- C. Disconnect the electrical connection.
- D. Disconnect the duct work.
- E. Slide the chassis out of the wall plenum.
- F. Roll the chassis out of the utility closet.

Inspect and Clean Indoor Air Coil

Eventually, minor amounts of lint and dirt may pass through the filter and collect on the indoor-air coil. These minor accumulations can be carefully vacuumed away with a brush attachment on a vacuum cleaner. Care must be taken to avoid bending the aluminum fins on the coil. Bent fins should be straightened using a special fin tool available from most HVAC supply depots.

Inspect Outdoor Air (OA) Intake and Exhaust

The unit's outdoor-air intake and outdoor-air exhaust paths must remain clear. Keep it free of all debris, snow, or ice. The OA intake should also be kept free of obstructions. Blocking the OA exhaust or OA intake opening will reduce the efficiency of your unit and could damage it.

Inspect and Clean Condensate Drain

The condensate drain must be routed to a suitable drainage area. Check the unit condensate drain periodically. Keep it free of anything that may block or impede the flow of condensate water. If there is any accumulation of foreign matter in the drain pipe, it should be removed and cleaned. The entire drain line must be protected from freezing.

Warranty

All warranty service work must be done by an authorized servicer. See Product Warranty, and consult your dealer or contractor for details.

Electronic Control Error Code Diagnostics and Test Mode



Error Code Diagnostics

The VRP electronic control continuously monitors the unit operation and will store error codes if certain conditions are witnessed. In some cases the unit may take action and shut the unit off until conditions are corrected.



To enter the error code menu, do a long press (3 seconds) of the Fan Mode and Fan Speed keys. When the menu opens an E will be displayed on the screen. Navigate through the diagnostics with the Up and Down keys. The displayed number denotes the number of the active diagnostic test.

To exit, press the Enter key.

Accessories

ITEM	DESCRIPTION	CHECK LIST
VRPXWPC-8	Wall Plenum for VRP36 with VRPXALC for 4" to 8" thick wall	Require One of these Wall Plenums per unit
VRPXWPC-14	Wall Plenum for VRP36 with VRPXALC for 8" to 14" thick wall	
		
VRPXALC	Architectural louver (VRP36 only) (30° Blade angle)	Require One of these Louvers per unit
VRPXSCC	Architectural louver (VRP36 only) Custom Color - Special Order (30° Blade angle)	
		
VRPXAP1	Return Air Access Panel	Require One per unit

Accessories

TYPE	ITEM	DESCRIPTION	CHECK LIST
WALL CONTROLLER	VRPXWCT	Wall Controller <div>  <p>VRPXWCT</p> </div>	Required one per unit
	VRPXEMRT2	VRP Energy Management Wired Wall Controller with Occupancy Sensor	Require One of the Controllers per unit
	VRPXEMWRT2	VRP Energy Management Wireless Wall Controller with Occupancy Sensor	
	EMOCT	Online Connection Kit – Optional with VRPXEMRT2/VRPXEMWRT2	Optional
	EMRAF	Remote Access Fee – Optional with VRPXEMRT2/VRPXEMWRT2	Optional
		<div>  <p>VRPXEM(W)RT2</p> </div>	

Diagnostic Error Codes

Code	Description
3	Return air thermistor open/shorted
4	Indoor coil (cool inlet) thermistor open/shorted
5	Outdoor coil (heat inlet) thermistor open/shorted
6	Discharge air thermistor open/shorted
7	Outdoor ambient thermistor open/shorted
8	Indoor coil (heat cond.) thermistor open/shorted
9	Compressor discharge thermistor open/shorted
10	Compressor suction thermistor open/shorted
11	Liquid cool thermistor open/shorted
12	Liquid heat thermistor open/shorted
13	Humidity sensor open/shorted
14	Pressure limit switch open
19	Outdoor coil temperature above 175F
20	Indoor coil frozen
21	Unit cycles more than five (5) times an hour
23	Room freeze protection
24	Discharge air temperature above 185F
26	Ambient temperature beyond operating limits
27	Minimum configuration not met
31	Outdoor fan over current
32	Compressor over current
34	Unit not provisioned
35	DC bus over voltage
36	DC bus under voltage
39	Low blower speed
40	Wall controller disconnected
41	EEV fault
43	MCS communication failure
46	Indoor Coil above 175F
47	Compressor I2T fault
49	Outdoor fan I2T fault
51	Incorrect MCS firmware
52	PFC over voltage
53	AC line under voltage
54	AC line over voltage



Friedrich Air Conditioning Co.
10001 Reunion Place, San Antonio, TX 78216
800.541.6645
www.friedrich.com

VRP Variable Refrigerant
Packaged Heat Pump

LIMITED WARRANTY

1. A) ONE YEAR PARTS WARRANTY - FRIEDRICH AIR CONDITIONING CO. (FRIEDRICH) warrants to the original end-user of this product that should it prove defective due to improper workmanship and/or material under normal use for a period of one years from the date of installation, FRIEDRICH will repair or replace, at its option, any defective part without charge for the part. Replacement parts are warranted for the remainder of the original warranty period.

B) THIS WARRANTY DOES NOT INCLUDE LABOR or other cost incurred for servicing, repairing, removing, installing, shipping, or handling of either defective or replacement parts, or complete unit. Such cost may be covered by a separate warranty provided by the installing contractor.

C) SECOND THROUGH FIFTH YEAR (Sixty (60) months from the date of installation). On the sealed REFRIGERATION SYSTEM. Any part of the sealed refrigeration system that is defective in material or workmanship will be repaired or replaced free of charge (excluding freight charges) by our authorized service center during normal working hours. The sealed refrigeration system consists of the compressor, metering device, evaporator, condenser, reversing valve, check valve, and the interconnecting tubing. LABOR IS NOT INCLUDED FOR INSTALLING REPLACEMENT PARTS.

These warranties apply only while the unit remains at the original site and only to units installed inside the continental United States, Alaska, Hawaii, Puerto Rico, and Canada. The warranty applies only if the unit is installed and operated in accordance with the printed instructions and in compliance with applicable local installation and building codes and good trade practices. For international warranty information, contact the Friedrich Air Conditioning Company - International Division.

D) NOTICE: To obtain service and/or warranty parts replacement, you must notify an authorized FRIEDRICH Air Conditioning Co. distributor, dealer, or contractor of any defect within the applicable warranty period.

2. Any defective part to be replaced must be made available to FRIEDRICH in exchange for the replacement part. You must present proof of the original date of installation of the product in order to establish the effective date of the warranty. Otherwise, the effective date will be deemed to be the date of purchase plus thirty days. The return of the owner registration card is not a condition of warranty coverage. However, please detach and return it so that we can contact you should a question of safety arise which could affect you.

3. TO OBTAIN WARRANTY SERVICE, please contact your authorized FRIEDRICH distributor, dealer, or the contractor who installed the equipment. If your dealer or contractor needs assistance, the authorized FRIEDRICH distributor is available for consultation, and FRIEDRICH supports the efforts of the distributor.

4. This limited warranty applies only to units remaining at the site of the original installation (except for mobile home installations) and only to units installed within the continental United States, Alaska, Hawaii, and Canada. This limited warranty applies only if the unit is installed and operated in accordance with FRIEDRICH instructions and in compliance with applicable local installation and building codes and good trade practices.

5. THIS WARRANTY DOES NOT COVER damages caused by: (a) accident, abuse, negligence, or misuse; (b) operating the product in a corrosive atmosphere containing chlorine, fluorine or any other damaging chemicals; (c) modification, alteration, poor service practices; (d) improper matching or application of the product or components; (e) failure to provide proper maintenance and service to the product according to manufacturer's instructions; (f) installation or operating of the product in a manner contrary to the instructions of the manufacturer; (g) lightning, fluctuations in electrical power or other Acts of God; (h) operation of the unit during construction. This LIMITED WARRANTY also excludes all cost of installation, disconnection or dismantling the product, parts used in connection with normal maintenance such as air filters or belts and owner-required maintenance. Consult the instructions enclosed with the product for information regarding recommended maintenance.

6. No one is authorized to change this LIMITED WARRANTY in any respect, or to create any other obligation or liability in connection with this product.

7. YOUR ONLY REMEDIES ARE PROVIDED IN THIS LIMITED WARRANTY. ANY EXPRESS WARRANTY NOT PROVIDED HEREIN, AND ANY REMEDY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION OR OPERATION OF LAW, IS HEREBY EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF ONE YEAR FROM THE DATE OF ORIGINAL INSTALLATION. UNDER NO CIRCUMSTANCES SHALL FRIEDRICH BE LIABLE TO THE OWNER OR ANY OTHER PERSON FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THIS PRODUCT, WHETHER ARISING OUT OF BREACH OF WARRANTY, BREACH OF CONTRACT OR OTHERWISE.

8. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental, special or consequential damages, so the above limitations or exclusions may not apply to you.

9. This warranty gives you specific legal rights, and you may have other rights which vary from state to state and province to province.

10. This warranty is valid in the U.S.A. and Canada and is not transferable.

(11-2019)

THIS PAGE INTENTIONALLY LEFT BLANK.

VRP[®] Variable Refrigerant Packaged Heat Pump

Innovative | Intelligent | Inverter

