

# PHONE USER GUIDE – UNIVERGE 3C

## Placing an Internal Call

---

- Lift handset
- Dial extension or press a speed dial

## Placing an External Call

---

- Lift handset
- Dial access code 9 + number

## Answering a Call

---

- Lift handset **OR**
- Press headset or speaker button

## Placing a Call on Hold

---

- While on a call press **Hold**
- Line key will flash

**Note: A held call will ring back after 1 minute**

## Retrieving a Held Call

- Press **Hold** **OR** **Resume**

## Redial

---

- Press **Redial** to call back the last number dialed

## Transferring a Call

---

### Transfer

- While on a call, press **Transfer**
- Dial number or press a speed dial
- Wait for an answer, then announce the call
- Hang up to complete the transfer

### Transfer to Voicemail

- press **Transfer**
- Dial \*74 + extension
- Press **Dial**

## Conference Calls

---

- While on a call, press **Conference**
- Dial number or press a speed dial
- Press **Conference** again and all parties will be connected

**Note: Before Conference is established, press shuttle to speak directly with party's individually before completing conference call**

## Message Waiting Light

---

Located in the Top Center of the phone, when you have a voicemail, this will be lit up red

## SoftKeys

---

The softkeys are the buttons located directly below the LCD display that control Speed dial, voicemail features, and conference

### Softkeys on LCD Screen

**New Call** - Generates dial tone for a call

**Voicemail** – Automatically dials the voicemail extension

**Pick up**- pick up another ringing extension or parked call

**End Call**- Terminates current call

**Conference** - Initiates/completes a conference

**Resume** - takes a call off hold status

**Dial** - dials the number

**Reject** - Transfers call to your voicemail or forwarding condition

## Park

---

- Press the Park Button
- The light will light while call is in park
- To retrieve the Parked Call, press the Park button again

## HardKeys

---

**Recall-** Used to recall dial tone

**Feature-** Used to set up speed dials

**Hold-** Places caller on hold

**Mic -** Press to mute microphone, the LED light on this key flashes when microphone is muted. Press key again to un-mute microphone

**Redial-** calls the last number dialed

**Speaker-** allows for hands free conversation

**Transfer-** Allows user to transfer calls

## Audio Control

---

Located in the lower right corner of the phone, increase volume by pressing up and decrease volume by pressing down

- Change the ring volume
- Control the volume of the Speaker / Receiver during conversation

## Programming Buttons

---

Any button on your phone that does not have a designated feature or line appearance may be programmed as a speed dial

### Programming

- Press **Feature**
- Press **Program**
- Press line key to be programmed
- Enter Name
- Press **OK**
- Dial phone number (Include 9 for external numbers)
- Press **OK**
- Press **OK** to select speed dial key
- Select **Visual**
- Press **OK**
- Select **OK** to save in directory
- Select **Save**
- Press **OK**
- Press **Exit**

## Hot-Desking

---

Allows you to assign another phone as your phone

### Logging In

- Press **Feature**
- Press **Home**
- Highlight Hot-Desking Log-in
- Press **Select**
- Enter Extension
- Enter Voicemail Password
- Press **OK**

## Logging Out

- Press **Feature**
- Press **Home**
- Highlight Hot-Desking Logout
- Press **Select**
- Press **OK**

## Headset (Wired or w/o lifter)

---

- Press **Menu**
- Press 3 for User Settings
- Press 1 for Headset
- Press 1 to Enable/Disable
- Press 2 to enable headset
- Press **OK**
- Press **Exit**

**Note: To use Headset, press **Headset** which will automatically appear when Headset is enabled**

## Training Links:

<http://www.loffler.com/support/training/voice-solution-training/nec-telephony-phone-systems/>

**LOFFLER**