

BED, PAN & LEGS

Front sump cover	A-59022	Gasket	B-62854
Rear sump cover	A-59023	Coolant pump brkt.	A-95295
Bed	L-94819	Bedway nut (22)	B-85475
Pan	A-95157	Stud	B-95019
Leg (right)	A-95187	Knob	B-95020
Leg (left)	A-95188	Spacer	A-95216
Stop rod plunger	B-31995	Stop rod	A-95217
Screw plug	B-32063	Rack	A-95222
Strainer	A-34325	Bedway (2)	A-95144
Bedway stud (20)	B-34331	Splash guard	A-95296
Stop rod screw	B-35350	Side splash guard	A-95297
Oil gage cover	B-36350	Strainer knob	788
Oil gage glass	B-36358	Spring	1551
Oil gage gasket	B-38359	Vicker oil filter	B-71003
Gasket (4)	B-47848		
Pan plate	A-56089	For machine with hand C.C.	
Gasket	B-58655	Stop rod brkt.	A-95219
Gasket cap	B-59026	Spacer	B-95221
Front sump gasket	A-59027		
Rear sump gasket	A-59028	For machine with air C.C.	
Gasket	B-59029	Stop rod brkt.	A-95218
Bedway stud (2)	B-62379	Plug	B-95220
Gasket	B-62853		
		Gits oiler (2)	502-G

COMMONHEAD

Housing - (8338)		{ A-84628	Tooth clutch fork	B-41111
Brake housing		{ A-84629	Intermediate shaft	A-41149
Clutch gear		A-66250	Three gear cluster	A-84282
For'd clutch gear		A-34309	39T gear	B-84295
High clutch gear		A-34310	34T gear	A-84281
Low clutch gear		A-84280	29T gear	A-84284
Cover	(2)	A-84285	45T gear	B-84293
Steel clutch disc	(28)	B-84632	25T gear	B-84294
Bronze clutch disc	(32)	B-34127	Detent plug	(5) B-42281
Clutch spacer	(2)	B-34128	Adjustment nut	B-42616
Idler gear stud		D-34352	Lever spring	(2) B-42667
Adjustment nut		B-34353	Gasket	(2) B-95732
Adjustment nut		B-34356	Hi-lo clutch plunger	A-43840
Gear shift lever shaft		B-34357	Spray head	(3) B-45696
Gear shift lever shaft		B-34358	Gear shift fork	B-84296
Hi-lo clutch washer		B-34359	Reverse clutch shaft	A-47804
Hi-lo clutch washer		B-84291	Clutch plunger	A-47807
Tooth clutch gear plate		B-34377	Brake piston	B-47817
Idler gear spacer		B-34381	Sleeve	B-47820
Bearing spacer		B-34383	Outer brake disc	(5) B-47822
Bearing spacer		B-34386	Handle	(2) B-92351
Bearing spacer	(2)	B-34387	Lever	(2) B-95189
Clutch shaft washer		B-34388	Lever block	(2) B-95190
Spacer & oil retainer		B-34389	Spray pipe	B-47842
Motor shaft brg. sp.		B-34531	Idler gear	B-50589
H & L clutch shaft washer		B-34532	Idler spacer	B-50591
Clutch finger	(4)	B-34798	Locknut	B-55247
Chambered locknut		D-39183	Hi & lo clutch shaft	A-84286
Clutch plunger spool	(2)	B-39258	Clutch brkt. gasket	A-61411
Motor shaft gear		B-40640	Brake disc cup	B-66249
		B-73730		

HEADCOMMON

Gasket	B-66251
Motor shaft spacer	B-67242
Motor shaft spacer	B-67243
Motor shaft spacer	B-84290
Motor shaft gear	B-67245
Inner brake disc (4)	B-67844
Locknut	B-83041
Adj. nut	B-84289
156 Truarc-snap ring	5100-
MRC ball bearing-09 int. fit	5209K
MRC ball bearing " " (3)	5210K
MRC ball bearing " " (3)	5211K
MRC ball bearing (2)	205SG
MRC ball bearing (4)	207S
MRC ball bearing (3)	208S
MRC ball bearing	208SZ
MRC ball bearing	308S

2 in. CAP. SPINDLE-PARTS

Spindle gear spacer	B-34603
Rear bearing closer	B-34605
Bearing spacer	B-34607

Front bearing closer	A-47851
Balancing ring	B-59612
Spindle	A-37284
Spindle adj. nut	B-34606
Oil thrower	B-35088
Driving button	B-37291
Driving button scr.	B-37292
Gear nut	A-54658
Timken roller brg #3 precision	593,592A
Timken roller brg #3 precision	581,572

118-1505 SPD. RANGE

Tooth clutch gear	A-84283
Tooth clutch pinion	B-84292
Small spin. gear	B-84297
Large spin. gear	B-84298

143-1820 SPD. RANGE

Tooth clutch gear	A-85326
Tooth clutch pinion	B-85332
Small spin. gear	B-85328
Large spin. gear	B-85334

HEAD END BRACKET

End cover	B-34411	Bearing block	A-95199
Top cover	B-34412	33-32T gear	A-95200
Gear stud	B-34420	66T gear	A-95201
Bearing spacer (2)	B-34422	Drg. closer	B-95202
Spindle gear	B-34620	Filler block	B-95203
35T gear	B-34621	MRC bearing (4)	202-S
40T gear	B-34622	MRC bearing (2)	204-S
45T gear	B-34623	MRC bearing	5302-SB
Spacer	B-34642	Victoprene seal	60449
Feed shaft	B-95521		
Oil gage cover	B-36350	Mach. with hand oper. C.C.	
Oil gage glass	B-36358	H.E.B.	L-95204
Oil gage gasket	B-38359	Gear stud (2)	B-34624
Cover gasket	A-38457		
Feed shaft extension	B-95522	Mach. with air oper. C.C.	
Spacer	B-67013	H.E.B.	L-95205
Oil seal guard	B-67014	Gear stud (2)	B-70364

CLUTCH LEVER BRACKET

Clutch lever	(2)	B-47823	Shaft	B-56360
Clutch lever brkt.		A-61376	Lever	A-56361
Clutch brkt. cover		A-61377	Brake valve const.	A-59519
Spring		B-31760	Valve body	A-59521
Oil pump gear stud		B-34369	Valve stem	B-59523
Oil gage cover		B-41415	Oil gage gasket	B-60018
Oil gage glass		B-41720	Oil gage gasket	B-60317
Lever pin		B-44288	Oil pump gear	B-60724
Reverse clutch fork	(2)	B-47824	Oil pump pinion	B-60725
Clutch lever shaft		B-47825	Plug	B-62160
Spacer	(2)	B-47826	Plug	(2) B-64870
Clutch fork collar	(2)	B-47827	Pump pinion bushing	B-63954
Pin	(2)	B-47828	Adjustment screw	B-67460
Lever lock pin		B-47833	Relief valve	B-67839
Plunger		B-47834	Lever notice plate	B-72812
Spring		B-47843	Lever	A-95192
Clutch brkt. cov. gask.		B-47846	Lever block	B-95193
Button		B-48062	Lever	A-95195
Valve body gasket		B-49263	Lever block	B-95196
Plate stand		B-50870	Linear "0" ring	11-110
Clutch lever shifter		A-56359	Linear "0" ring	11-111
Handle	(2)	B-92351	Dieco spring	M-111A

TURRET SLIDE & SADDLE

Turret clamp	A-74321	Lever roller	B-34177
Turret cover	B-42668	Lever washer	B-34178
Hex turret	A-57941	Lock bolt spring	B-34179
Slide	L-74319	Pawl pivot	B-34184
Saddle	L-94816	Pawl stop pin	B-34185
Tumbler	A-62940	Spacer	B-72326
Lockbolt lever	B-62938	Locating pin (2)	B-65368
Pawl	B-62939	Binder bolt (6)	B-39857
Spring retainer	B-70942	Locating ring	A-41138
Tumbler seat	B-71971	Chip guard	B-41820
Stop scr. carrier	B-70536	Chip guard support	B-41825
Stop scr. carrier nut	B-12004	Guard	B-74327
Knock out spring	B-31760	Steel way screw (12)	B-42367
Knock out rod plug	B-80810	Bevel gear	B-43630
Ratchet	B-75553	Lever washer	B-63347
Turret bevel gear	B-34166	Lockbolt bushing (6)	B-47906
Clamp stud	B-74296	Oil plug	B-58855
Washer	B-74302	Taper gib	B-59747
Set screw block	B-74303	Taper gib	B-59748
Clamp ring locator (2)	B-77660	Straight gib	B-59749
Jam nut	B-80811	Left front gib	B-63016
Release trip	B-74323	Pawl spring	B-39246
Clamp release	B-74324	Binder hub	B-92239
Lock bolt sleeve	B-70941	Binder handle	B-92325
Link	B-74325	Binder handle	B-92351
Lever pin	B-65416	Saddle way-rear	A-59751

TURRET SLIDE & SADDLE

Saddle way-front	B-59752	Shoe	(3)	2359
Rack	A-59753	Brass shoe	(6)	2261
Slide cap-front	B-59754	Brass shoe		2253
Slide clamp cap	B-59755			
Slide cap-rear	A-74322	For T.S. & S.-W/O-S.A.		
Slide cap-front	A-59757	Pinion shaft		A-34540
Saddle cap-front	A-59758	Pinion shaft washer		B-34541
Saddle cap-rear	A-59759	Turnstile sleeve		B-34542
Block	B-59760	Slide cap-front		B-66587
Ind. stop shaft	B-59764	Slide cap-front		B-66588
Stop rod	B-59765	Slide cap-rear		A-78004
Stop shaft collar	B-59766			
Clamp nut	B-59767	With Bijur lubricator		
Tumbler screw	B-59768	Brkt.		B-73928
Stop screw	(6) B-59769	Front cover		A-81026
Knock out rod	B-95169	Bijur lubricator		LBK-2036
Clamp stud	B-95170	Caton snap ring		309
Bevel gear nut	B-59773	Linear-o-ring	(5)	11-110
Gib screw	(2) B-60136	Linear-o-ring		11-010
Saddle way-front	A-60721	Timken brg. cone		#387
Stop	B-62194	#3 precision		
Lock bolt	B-62326	Gits-oiler		#502
Spacer	B-95739	Gits-oiler		#503
Latch pivot	B-63543			
Latch	B-63544	For T.S. & S.-W/O-S.A.		
Ratchet pin	(3) B-64964	Gits-oiler	(5)	#501
Lockbolt centers	A-65243	Gits-oiler	(2)	#504

SADDLE APRON

Apron	L-94827	Spacer	(2)	B-62521
Apron cover	A-94828	Clutch bolt nut		B-65293
Left side cover	A-94829	Dbl. cluster gear		B-65306
Feed lever	A-94830	Dbl. cluster gear		B-65307
Turnstile sleeve	A-94831	Dbl. cluster gear		B-65308
Right side cover	A-94832	Worm		B-65311
Dial	A-95129	Spacer	(2)	B-65322
Worm gear	B-65296	Dial marker		B-65334
Lever	B-65802	Sleeve		B-65340
Lever	B-65803	Screw		B-65341
Triple cluster gear	A-65808	Shift pin	(2)	B-65342
Cam	A-69916	Bushing	(2)	B-65386
Cam shaft	A-94994	Lever screw		B-65817
Front gasket	A-95122	Fd. lever plunger		B-65822
Left side gasket	A-95123	Tooth clutch		B-65824
Right side gasket	A-95124	Tooth clutch		B-65828
Hollow shaft	A-95125	Gear		B-65829
Shaft	(2) A-95126	Rear cover		B-65834
Clutch bolt	A-95127	Rear gasket		B-65836
Pinion shaft	A-95128	Lever guard		B-67045
Spring	B-31917	Fd. lever cam		B-67046
Pin	(2) B-39805	Clutch plug	(3)	B-69183
Spring	(3) B-52222	Bushing		B-73036

SADDLE APRON

Handle	(5)	B-92351	J.M. #9846	
Knob	(3)	B-93655	Hat gasket	
Lever stop		B-95006	Gits #302	
Cam spacer		B-95009	Oil cap	
Fd. lever stud		B-95019		
Knob		B-95020		
Retainer		B-95024	Tru-arc snap rings	
Spring	(4)	B-95025	5100-78	(2)
Spacer		B-95026	5100-137	
Pin	(2)	B-95027	5100-250	
Gasket		B-95130		
Feed dial		B-95131	Arrow breather	
Dial feed plate		B-95132	vent ASP-3BV	
Detent plate		B-95133		
Spacer		B-95134	Bijur KIC-C-2367	
Brg. spacer		B-95135	lube pump, 1 in. stroke	
Spacer	(2)	B-95136		
Brg. spacer	(2)	B-95137	Bijur B-5734 sight-gauge	
Lg. fd. lever rod		B-95138		
Seal retainer		B-95139	MRC bearings	
Turnstile hub		B-95140	R-4	(2)
Turnstile handle	(5)	B-95141	104-KS	(2)
			107-KS	
			204-S	(2)
			207-S	
0-rings			Aetna bearings	(2) E-7
PRP 568-008	(2)			
PRP 568-010			Jergens #26908 plunger	
PRP 568-012	(2)			
PRP 568-113			Drill jig bushing	(2) GA-92
PRP 568-115	(2)		5/16 hole	
PRP 568-210			Brass shoe	1049
PRP 568-213				
Victoprene seal	(2)			
#60388				

CROSS SLIDE & CARRIAGE

Cross slide gib	B-34391	Handle stud	B-68691
Dial	B-42854	Handwheel	A-95159
Carriage taper gib	B-61693	Feed screw	A-95160
Compensating nut	B-62363	Front carriage cap	A-95161
Binder handle	B-68690	Trip dog	B-95162
Carriage	L-94817	Trip pin	B-95163
Cross slide	A-94818	Feed screw nut	B-95164
Clip (6)	B-31937	<u>Experimental</u>	
Gib screw (2)	B-34399	Adaptor	B-95165
Gib stud	B-37754	Handle hub	B-95166
Gib nut	B-40580	Handle	B-92351
Rear carriage cap	B-42168		
Rear cap gib	B-42171		
Wiper (2)	B-47907	Reid tool SKA-13	
Wiper cover (2)	B-47908	Knurled knob assembly	
Clamp (2)	B-62365		
Feed screw gear	B-62366	Brass shoe (2)	2252
Brg. spacer (2)	B-62367	Brass shoe	2281
Brg. spacer	B-62368		
Wiper cover (right)	B-62805	MRC bearing (2)	7303
Wiper (2)	B-62806		
Wiper cover (left)	B-63151		
Stop	B-63545		
Tee bolt	B-66118		

CARRIAGE APRON

Carriage apron	L-94820	Spacer	(2)	B-65295
Apron cover	L-94821	Tooth clutch		B-65297
Right side cover	A-94822	Fd. lever plunger	(2)	B-65302
Left side cover	A-94823	Dbl. cluster gear		B-65306
Cr. fd. lever	A-94824	Dbl. cluster gear		B-65307
Long. fd. lever	A-94825	Dbl. cluster gear		B-65308
Gear shift lever	A-94826	Idler gear		B-65310
Carriage dial	A-95040	Worm		B-65311
Worm gear	B-65296	40T gear		B-65312
Knockout spring	B-31760	Bunting bushing		B-65318
Fd. lever spring	(2) B-31917	Bunting bushing		B-65319
Rev. detent spring	B-31918	Spacer	(6)	B-65322
Clutch spring	B-34684	Dial marker		B-65334
Stud	B-37754	Gib		B-95855
Pin	(2) B-39805	Bushing		B-65339
Adj. nut	B-40580	Sleeve		B-65340
Spring	B-46766	Screw		B-65341
Spring	(6) B-52222	Shift pin		B-65342
Spring	B-59673	Brq. spacer		B-65352
Spacer	(2) B-62521	Bushing		B-65386
Triple cluster gear	A-65259	Bushing		B-65387
Tooth clutch gear	A-65260	Bushing		B-65388
Gear shifter stud	B-65275	Lever guard	(2)	B-67045
Tooth clutch	B-65286	Fd. lever cam	(2)	B-67046
Bushing	B-65287	Clutch plug	(6)	B-69183
Tooth clutch gear	B-65289	Stop screw	(6)	A-69817
Clutch bolt nut	(2) B-65293	Spacer		B-70631

CARRIAGE APRON

Stop screw roll		A-71323	Brg. spacer	(3)	B-95014
Bushing	(2)	B-73036	25T gear		B-95015
Pin		B-81534	Spacer		B-95016
Handle		B-92351	Fd. disengage pin		B-95017
Knob	(3)	B-93655	K.O. rod plug (1-1/16)		B-95018
Front gasket		A-94991	Fd. lever stud	(2)	B-95019
Left side gasket		A-94992	Knob	(2)	B-95020
Right side gasket		A-94993	Washer		B-95021
Cam shaft		A-94994	Pinion shaft gear		B-95022
Gear shift cam		A-94995	Handwheel shaft		B-95023
Hollow shaft		A-94996	Retainer	(2)	B-95024
Shaft	(3)	A-94997	Spring	(8)	B-95025
Handwheel		A-94998	Spacer	(2)	B-95026
Pinion shaft		A-94999	Pin	(4)	B-95027
Clutch bolt	(2)	A-95000	Cr. fd. lever rod		B-95028
Lever		B-95001	Rev. gear shaft rod		B-95065
Detent holder		B-95002	Plug		B-95066
Shifter block		B-95003			
Shifter rod		B-95004	Victoprene seals		
K.C. rod plug (15/16)	(2)	B-95005	#60096		
Lever stop	(2)	B-95006	#60388		
C.S. knockout rod		B-95007	#60454		
Detent plate		B-95008			
Cam spacer		B-95009	McCord-McKim gasket		507-F
Feed dial		B-95010			
Dial feed plate		B-95011	Bijur B-5734		
Idler gear stud		B-95012	sight gauge		
Sleeve		B-95013			

CARRIAGE APRON

Bijur KIC-C-2367		207-S	
Lube pump, 1 in. stroke		104-KS	(3)
		107-KS	
Tru-arc snap rings		R-4	(2)
5008-137			
5100-78	(3)	Aetna bearings	(3) E-7
5100-137			
5100-250		Torrington	
		NTC-1427 Brg.	
O-rings		TRC-1427 Plate	(2)
PRP 568-008	(4)		
PRP 568-010	(2)	Drill jig bushing	(4) GA-92
PRP 568-113			
PRP 568-115	(4)	Steel ball (5/16 D.)	
PRP 568-210		Steel ball (3/8 D.)	
PRP 568-213			
PRP 568-214		Jergens #26908 plunger	
PRP 568-218			
MRC bearings		Brass shoe	1049
202-S	(2)	Brass shoe	2246
204-S	(3)	Brass shoe	2281
		Brass shoe	(6) 2289

AIR OPER. COL. CHUCK

Wedge shoe	(2)	B-31983	Spd. cont. plug	(2)	B-88698
Switch box		A-65672	Logan - Model 401		B-87942
Yoke bracket		A-72071	R.F.L. unit		
Finger	(2)	A-70711	5 in. bore-2-1/16 in stroke		90436
Spindle guard pin		B-32580	Logan air cylinder		B-95662
Spring	(2)	B-34684			
Finger pivot pin	(2)	B-36830	<u>1-1/2 in. Only</u>		
Finger holder frict.		B-44274	Collet hood guard		B-37595
Detent		B-46705	Yoke		A-67755
Detent plug		B-46706	Collet hood		A-37594
Detent spring		B-46707	Collet		B-34547
Switch bushing	(2)	B-52246	Collet pads		B-35135
Switch plunger	(2)	B-56194	Plunger		B-37596
Finger roller	(2)	B-62784	Wedge shoe stud	(2)	B-62792
Finger roller pin	(2)	B-62785	Wedge		B-67759
Yoke pin		A-65677	Finger adj. ring		B-67760
Link pin		B-65679	Abutment sleeve		B-67761
Cover		B-65681	Finger holder		A-67762
Dog	(2)	B-65682			
Switch pin	(2)	B-65683	<u>2 in. Only</u>		
Guard cover		B-67758	Collet hood guard		A-37287
Spindle guard		A-70378	Yoke		A-70361
Pin		B-77796	Collet hood		A-37289
Cylinder adapter		A-72069	Collet pads		A-36758
Cylinder adapter		A-72070	Collet		A-42589
Link		B-72072	Wedge		B-62790
Spacer-mach. without		A-72037	Finger adj. ring		B-69765
Yoke pin-mach. without		A-72074	Abutment sleeve		B-69766
Oil-rite style dosf.		114	Finger holder		A-69767
Micro-switch	(2)	DZ-2RS	Plunger		B-70362
Air valve		B-88686	Wedge shoe stud	(2)	B-70363
Valve mtg. plate		A-95845	Abutment sleeve ext.		B-83823

AUTO CHUCK

Guard cap hinge	B-12890	Wedge shoe stud	(2)	B-34446
Lever	A-34428	Finger roller	(2)	B-34447
Yoke	A-34608	Finger roller pin	(2)	B-34448
Yoke bracket (mach. w/o HEB)	B-34777	Pin wrench		B-34523
Spindle guard cap	B-35089	Finger pivot pin	(2)	B-34618
Hood guard support	B-35104	Rear spindle guard		A-35108
Collet hood guard	A-37287	Rear spindle guard		A-36440
Crank lever	B-40489	Collet pads		A-36758
Yoke bracket	A-67973	Plunger		B-37288
Sleeve	A-46864	Pivot link pin		B-40496
Wedge shoe	(2) B-62004	Shaft		A-40504
Collet hood	A-37289	Link		B-42021
Finger	(2) B-38091	Collet		A-42589
Hood guard pin	B-32580	Finger holder		A-44256
Abuttment sleeve	B-33563	Finger holder friction		B-44274
Wedge	B-33564	False jaw screw	(4)	#1453
Pivot link pin	(2) B-31970	Gits oiler		#502-G

REVOLVING HEAD BAR HAND FEED

Sliding head	A-36383	Lever pin	B-36752
Rear stand	A-36748	Stand head washer	B-36805
Front stand	A-36749	Support tube	B-37566
Stand head	A-62831	Link pin	B-40496
Lever	B-36751	Link	A-42019
Link lever	B-40490	Stud	B-42020
Ratchet pusher	B-42018	Bars	(2) B-42023
Revolving head	A-83716	Ratchet	B-42025
Link pin	(4) B-31970	Link	B-42026
Chuck jaws	B-36017	Drip trough	A-36894
Chuck screw	B-36018	Spring	B-43666
Front bearing closer	B-36026	Center plug	B-83717
Rear bearing closer	B-36027	Latch handle	292
Chuck plate	B-36028	Knob	788
Bearing spacer	B-36030	Shoe	882
Latch	B-36384	Spring	1530
Chuck guard	A-36385	MRC bearing	(2) 214-SF
		Gits oiler	502-G

LIPE BAR FEED (SPL.)

SL - (12 ft.) lipe
bar feed unit
Bushing
Tube

#225
B-85297
B-85296

Ext'd. piston
Piston const.
Support arm
Arm extension

A-85163
A-85298
A-84536
A-84537

SQUARE TURRET

Binder lever	B-42144	Indexing plate	B-43646
Base	A-58493	Center stud	B-43648
Lockbolt lever	B-63351	Center bushing	B-51196
Lockbolt cam	B-63352	Center sleeve	B-51197
Lockbolt bushing (4)	B-32046	Square turret	A-56325
Lockbolt spring	B-32049	Pivot screw	B-58482
Screw plug	B-32055	Tumbler plunger	B-58483
Lockbolt	B-34234	Tumbler	A-61146
Lockbolt sleeve	B-34235	Tee nut (2)	B-63945
Bottom plate	B-34243	Spring	B-73527
Binder lever collar	B-34248	Spring (2)	2075
Spring plunger	B-34249	Gits/oiler (2)	B-95803
Lever shaft	B-42145		
Lever bushing	B-42146		
Lever collar	B-42147		
Lever collar	B-42148		
Bakelite ball	B-42149		

MOTOR DRIVE

Louis Allis 256T

Motor bracket
Motor housing

A-86291
A-67731

Motor brkt. gasket
Key

A-95734
B-86292

COOLANT PUMP & PIPING

Gusher coolant pump	B-91226	Std. pipe	(3)	1/2 x 12
Model 6P3-long		Std. pipe		1/2 x 8
Manifold	A-95329	Std. pipe		1/2 x 6
Ball valve	(2) B-94875	Std. pipe		1/2 x 2
Flodar fitting	(2)	Swing joint	(4)	1/2
BA-1000-12-8		Street ell	(2)	1/2
American flexible	1/2 x 12	Hyd. tubing		3/4 O.D.
Coolant line with male	1/2 x 16			
coupling & open nozzle				

S.C.A.

Bracket	A-71286	Stop lever	B-71298
Lg. fd. lever	A-71859	Knock out adjustment	B-71299
Lever (#4 UTL only)	B-71288	Bushing	B-71301
Leader	A-71289	Knock out rod	B-71302
Lever (#6 UTL only)	B-80822	Lever catch	B-71303
Lever (#3 UTL only)	B-95148	Detent	B-71304
Leader nut	B-32079	Knock out rod plunger	B-71305
Spring	B-48061	Lever rod	B-95810
Leader bushing	B-71290	Lever pivot	B-71307
Follower	B-71291	Pinion shaft	B-71858
Follower rack	A-71292	Kickout plun. spring	B-52312
Closer	B-71293	Cover	B-71319
Disengage block	B-71294	Spring	B-56121
Pin	B-71306	Knob	B-95020
Kickout plunger	B-71297	Gits oiler	#2201

CROSS SLIDE TAPER ATTACH.

Base	A-34811	Swivel slide	A-34816
Tool slide taper gib	B-34813	Swivel plate	B-34817
Swivel slide taper gib	B-34814	Tool slide stud	B-34821
Yoke	B-34819	Swivel stud	B-34822
Tool slide	A-63199	Bracket	B-47841
Gib screw	(2) B-34399	Tee nut	(2) B-63945
Follower	B-34815	Stud	(2) B-88881

10 in. AIR POWER CHUCK (S-P)

Adapter	A-91730	S-P 10 in. 2-jaw chuck	Model K2	
Mtg. plate	A-95345	S-P 10 in. 3-jaw chuck	Model K2	
Draw rod	A-99483	S-P 10 in. cylinder	Model RM	
Cylinder guard	A-99484	S-P Soft blank top jaw	10-K-325 (1 set)	
Mounting plate	A-98946	Logan RFL unit	Model 401	B-87942
		Valvair speed control plug	(2)	B-88698
		Numatics 4-way valve		B-95900

CHUCK GUARD

Knob	B-84088	Guard	A-95850
Hood	A-95849	Housing	A-84629

10 in. AIR POWER CHUCK (CUSHMAN)

Adapter	A-91730	Cushman chuck #20-672-10-A08	
Mtg. plate	A-95845	Cushman cylinder #10-752-10-000	
Draw rod	A-98944	Cushman H.S. top jaws 24-11055	(1 set)
Guard	A-98945	Logan RFL Unit	B-87942
Mounting plate	A-98946	Valvair speed control plug	B-88698
		Numatics 4-way valve	B-95900

8 in. SMW POWER CHUCK

Mounting plate	A-97160	Logan R-F-L Unit	B-87942
Chuck adapter	(2) A-99076	Valvair speed plug	B-88697
Stand off bracket	(2) A-99077	Numatics 4-way valve	B-97159
Chuck guard	A-99078	SMW chuck-adapter-jaw	B-97161
Knob	B-84088	Bracket	(2) B-99079

INCH/METRIC DIAL

Jergens Conversion		Nut (No. 6 UTL)	B-97152
Dial Unit No. 65103	A-97149	Adapter	B-97153
Increment Ring 0/333	B-97150	Clip	(6) B-97306
Handwheel	A-97151	McMaster Delrin	
Nut (No. 3 UTL)	B-98565	Fluted-Head Finger	(6) B-97330

USING THE CONVERSION DIAL

1. Inch measurement

With the inch engraving on the selector ring to the top, the engraved dial will now revolve at the same speed as the lead screw.

2. Millimetre measurement

The conversion dial can be changed from inch to metric by turning the selector ring slowly 180° in a clockwise direction until it can be felt clicking into the detent position. This will show the mm engraving at the top. The engraved dial will now revolve at a higher speed than the leadscrew spindle, 2.54 to 1.

3. Reversion to inch measurements

The selector ring is returned to the detent position in a counter-clockwise direction. A small arrow engraved beside the inch and mm engraving shows the direction of rotation in each case.

4. Zero set

The engraved dial can be set at zero or any other position on the dial by unscrewing the thumb screw, moving it to the required position and then re-tightening the thumb screw.

ADJ. SPINDLE BACK STOP

Adj. stop
Guard

A-96999
A-97000

Adapter
Sleeve

B-97001
B-97002

TURRET LEADING ATTACHMENT

Follower bracket	A-99435	Coupling	B-71526
Follower bracket cover	A-99436	Closer	B-71528
Leader	A-94437	Spring retainer	B-71530
Splined shaft	A-99438	12T gear	B-71531
Spacer	A-99439	Collar	B-71532
Cover	B-99440	Cover	B-71534
Gits oiler	502	Feed lever plunger	B-71536
Gear housing	L-97769	Eccentric pin	B-71539
Lever bracket	A-97771	42T gear	B-71540
Lever	A-97772	36T gear	B-71541
Spacer	A-97773	Rack	B-71542
Right side cover	A-97774	Roller	(2) B-71543
Bearing closer	B-97775	Cover	B-71545
Knock out rod plug	B-31750	Cam	A-71547
Spring	B-31917	Bushing	B-73454
Spring	B-52222	Spring	B-79065
Follower	A-71511	Shear pin	B-83937
Feed screw gear	B-71513	Feed lever stud	B-95019
Bearing closer	(2) B-71514	Knob	B-95020
Washer	(2) B-71515	Seal spacer	B-97779
Bushing	(2) B-71518	Shift rod	B-97780
Washer	(2) B-71520	32T gear	(2) B-97781
Spacer	B-71521	8T pinion	B-97782
30T gear	B-71522	Long. feed lever rod	B-97783
Splined shaft	B-71523	Gear stud	(2) B-97784
20T gear	B-71525	Closer gasket	B-97785
		Cover gasket	A-97786
		Apron gasket	(2) A-97787
		Washer	(2) 1721
		Garlock seal 92 x 7518	(3) B-95748

CONTENTS

SECTION 1

INSTALLATION

- Unpacking
- Foundation
- Electrical connections
- Leveling
- Lubrication

SECTION 2

OPERATING INSTRUCTIONS

- Before You Turn On the Machine
- Headstock Operation
- Carriage and Cross Slide Operation
- Saddle and Hexagon Turret Operation
- Collet Chuck and Bar Feed
- Collet Chuck
- Square Turret
- Coolant System
- Carriage Thread Chasing Attachment
- Cross Slide Taper Attachment

SECTION 3

MAINTENANCE AND ADJUSTMENTS

- Diagnosis of Improper Head Operation
- Carriage and Saddle Apron Adjustments
- Turret and Slide Adjustments
- Cross Slide and Carriage Adjustments
- Square Turret
- Collet Chuck

SECTION 4

- General Safety
- Machine Specifications

SAMPLE

This instruction manual is for—

Customer _____

Machine _____

Serial No. _____

Lot No. _____

Date Mfg. _____

Note: When ordering tooling, repair parts or requesting information please refer to the above machine, serial number and lot number.

UNIVERSAL TURRET LATHE

INSTALLATION—SECTION 1

The Bardons & Oliver Universal Turret Lathe was designed and built to produce accurate work over a long period under conditions of hard usage. In order that the inherent accuracy be retained, extreme care must be given to the installation of the machine. Thorough inspection of the machine should be made at regular intervals, the frequency depending on the type of work handled and the accuracy desired.

IMPORTANT

Do not attempt to run the machine until all of the following instructions for Unpacking, Installing, Lubrication, Electrical Connections, Leveling, and Safety have been carefully and completely followed.

UNPACKING

Turret Lathes for domestic customers are shipped in individual crates; those for foreign customers are shipped in individual boxes. While the machine is being unpacked, particular care should be taken not to mar the finish or damage the working parts.

Whenever possible, tools, chucks, and fixtures are attached directly to the machine. Wrenches and other items which cannot be attached, together with a data envelope, will be found in a separate box fastened to the platform or skids.

Contained in the data envelope are the instruction manual, electrical diagram, parts catalogue, and packing list. Be sure this data is preserved and delivered to the proper departments.

Check and account for each item on the packing list before disposing of any crating or boxing material.

These plates should be grouted in concrete flush with the floor. If it is impossible to set these plates in or on concrete, they may be bolted down to a wooden floor. Here it is advisable to use plates affording a much larger bearing area on the floor. Drill and tap for the hold down screws after the bearing plates are firmly fastened to the floor.

On machines equipped with an air collet chuck and bar feed unit, assemble the bar feed unit according to the foundation drawing in the manual and place the unit in its approximate position with respect to the machine. The bar feed unit should be located on bearing plates the same thickness as used under the machine.

Connect the two air lines to the collet chuck cylinder underneath the end of the spindle. Each hose is suitably marked.

FOUNDATIONS

The machine is mounted on heavy wooden skids to prevent bed warpage in shipping. Locate the machine approximately in its final position before removing the skids. In removing the skids care must be taken to prevent undue twisting which might cause permanent distortion of the bed.

If possible, the legs should rest on a concrete foundation. A wooden floor lacks rigidity and its surface swells or shrinks according to climatic conditions.

To maintain accuracy, place steel bearing plates under each leg, as shown on the outline drawing of the machine.

ELECTRICAL CONNECTIONS

The machine is shipped from the factory with all electrical equipment wired. It is only necessary to connect the main power lines to the terminals on the disconnect switch in the upper right hand corner of the electric control cabinet. When the headstock oil reservoir is filled as outlined in the "LUBRICATION" instruction, close the disconnect switch and press the "START" button located on the push button control panel. If the power lines have been connected to give the proper rotation of the motors the spindle will rotate in a counter clockwise direction with the start lever in forward.

LEVELING

CAUTION—Before leveling, allow the machine to reach normal operating temperature.

To start machine, read operating instructions first.

The accuracy originally built into the machine will be lost unless the machine is properly leveled. To maintain this accuracy the level of the machine should be checked at least twice a year.

To level, raise the machine by turning the leveling screws so that a 1/8 inch thickness gage may be slipped between the bottom of each leg and the bearing plate. Use a precision level about fifteen inches long. Starting at the head end, place the level lengthwise on the bed ways, and level by turning the adjusting screws. Then place the level across the bed ways and level. Repeat the two operations at the tail end of the machine. After leveling at each end, repeat the leveling process until all readings are equal. After proper alignment, bolt down the legs and recheck the level.

If extremely accurate work is to be done on the machine, the leveling can be further checked by chucking a round bar and taking a turning cut with the carriage or hexagon turret. Any remaining misalignment will be indicated by the amount of taper in the turned diameter. This can be corrected by slight adjustment of the leveling screws.

On machines equipped with the air collet chuck

and bar feed unit, this unit should be bolted to the floor only after it is leveled and aligned with the spindle. To level and align the unit (Figure 1), do as follows: Place the unit in approximately the proper position with respect to the machine, and make necessary electrical and air connections. Insert a test bar (equal to the maximum capacity of the collet) through the revolving scroll chuck and just through the collet. The bar should be straight, of a uniform diameter and about 12 feet long. Close the collet. Place a parallel between the support bars and the test bar. Using a 2 inch parallel, raise the second stand until the test bar is level. Check alignment of support bars by placing level lengthwise on top of the bars and then crosswise on the bars adjacent to the parallel. Adjust by leveling the second stand. Level the first stand lengthwise and at right angle to the support bars. Using the test bar as a guide, align the stands with the center line of the spindle. Recheck level of test bar and support bars. As a check of alignment, the test bar should be concentric with the hole in the abutment sleeve. Recheck the levels throughout the bar feed unit.

To insure proper installation of the bar feed unit, tighten the chuck until it grips the test bar. Loosen the chuck just enough so that it can be moved back and forth over the test bar. It must slide freely over the whole length. After lining up and leveling the bar feed stands, bolt them securely to the floor.




FIG. 1

LUBRICATION

The headstock is fully enclosed and spray lubricated. With the main drive motor on circulating oil should be visible in the sight gauge directly below the forward-reverse lever near the spindle face.

The aprons and head end bracket are splash lubricated. The plunger pumps on the aprons lubricate the bearing surfaces of the turret slide, the cross slide, carriage, feed screw, and nut, as well as bearing surfaces in each apron not reached by the splash system. Since the plunger pumps take oil from the aprons, it may be necessary to add oil to the aprons more often than to the headstock or head end bracket.

The apron oil reservoirs are filled to the proper level before shipment. Fill the headstock and check the aprons and head end bracket. Make sure that the oil level in each reservoir is at approximately the center of the gage glass. Check the oil levels before starting the machine, as the level drops somewhat after the machine is started. Raising the oil level above the center line on the gage will cause oil leakage at various points and excessive oxidation or gumming of the oil.

The instructions on the lubrication chart (Figure 2) must be followed. If the machine is operated on a multi shift basis, the headstock and aprons should be drained, flushed and refilled two or three times as often as called for on the chart.



Site Gage

Apron
Plunger Pump

LUBRICATION CHART

INSTRUCTIONS

- Before Starting — Fill all oil reservoirs to the center line on the gages. Fill oil cups. Depress apron pump plungers 3 or 4 times.
- Every 4 hours — Fill oil cups. Depress apron pump plungers 3 or 4 times.
- Every 3 months — Drain apron and head end bracket oil reservoirs. Flush with solvent type flushing oil. Refill reservoirs.
- Every 6 months — Drain headstock oil reservoirs. Flush thoroughly with solvent type flushing oil. *Clean oil filter on inside of reservoir cover.* Refill headstock.

OIL SPECIFICATIONS

- Headstock and Head End Bracket — High grade mineral oil, Mobil DTE 25 or equivalent.
- Aprons — Mobilgear #626
- Oil Cups — Mobil Vactra oil #2




FIG. 2

NOTE: Mobil Products are listed above to indicate the proper type of lubricant. Many manufacturers of high quality lubricants have equivalents, and it is recommended that you consult the company which has best served your past needs.

OPERATING INSTRUCTIONS

SECTION 2

Safety First

Before you turn on the machine—

- Protect your eyes. Wear safety glasses.
- Wear appropriate clothing—No long sleeves, neckties, or jewelry.
- Make sure floor is clean and free of obstructions in work area. Clean up chips, oil spills, and remove parts or tote boxes to a safe area.
- Before turning on power, put the spindle in neutral.
- Make sure work part and tooling are securely fastened in proper holders or fixtures.
- When main power is on and before spindle is rotated check that hydraulic and air pressure gages show proper operating pressure.

HEADSTOCK OPERATION

The No. 3 Universal Turret Lathe has a 24 speed (with 2 speed motor) headstock. Speeds are easily selected by positioning three levers as indicated on the chart attached to the front of the headstock (Figure 3).

The high-low lever “B” allows spindle speed changes without slowing the spindle. When the position of levers “A” or “C” is changed, the forward-reverse clutch must be disengaged, and the spindle must be allowed to slow almost to a stop. The forward reverse lever when in the neutral position automatically applies the spindle brake. Between the forward and neutral positions there

is a coasting zone which greatly facilitates gear shifting. An automatic lever lock prevents unintentional starting of the machine.

The high-low motor buttons start the main drive motor. Either of these buttons may be pressed with the spindle running allowing an instantaneous shift from high to low motor.

A selector switch turns on and off the separate motor driven coolant pump.

If the machine is equipped with an air operated collet mechanism the switch closest to the operator opens and closes the collet.




FIG. 3

CARRIAGE AND CROSS SLIDE OPERATION


The carriage and the cross slide can be adjusted manually by turning the hand wheels. Power feeds are engaged by lifting the new "easy action" levers and are disengaged by the same levers or by adjustable stop screws or dogs. Positive tooth clutches in each apron assure easy engagement and long life.

Feed selections in each apron are made by means

of a single dial and are easily read on large rotating drums.

The carriage locking lever can be used to lock the carriage into position for facing, grooving or cut-off. The cross slide lock can be used to lock the cross slide in position.

The six position stop screw roll may be set to disengage the feed on longitudinal cuts.



SLIDE AND HEXAGON TURRET OPERATION

The turnstile handles advance, retract and index the hexagon turret.


Power feed is engaged by lifting the new "easy action" lever and may be disengaged by the same

lever or by a stop screw.

Stop screws are set by adjusting the screw in the bottom position on the roll which corresponds to the working face of the hexagon turret.

AIR OPERATED COLLET CHUCK AND BAR FEED

The air operated collet chuck and bar feed are shown below. Controls for the unit are located on the machine control panel on the front of the headstock. See Figure 3.



The operating lever controls the action of the collet separate, or controls the collet and bar feed together.

Bars to be fed into the machine are held in a revolving scroll chuck.

To insert a new bar position the chuck to the right. Swing the support tube forward and insert the bar. Pass the bar through the chuck and just through the collet. Close the collet. Move the chuck all the way to the left. Close the chuck jaws until they grip the bar securely.

As the bar is used, the chuck will advance to the right. When the chuck has reached the end of its travel, loosen jaws and move to left with collet closed. Close chuck jaws as above.

COLLET CHUCK

To change collet pads, remove the pad screws from the master collet. These can be reached through holes in the collet hood. (Figure 4) To avoid runout of stock, clean the master collet and pads carefully before putting in the new pads.

The grip of the collet is adjusted at the rear of the

spindle by use of the spanner wrench for which holes are provided in the end of the abutment sleeve. (Figure 4) The finger holder should at all times abut tightly against the end of the spindle. The collet grip should be adjusted so that the finger rollers snap into the groove in the wedge when the collet is closed.





FIG. 4

SQUARE TURRET

The Bardons & Oliver Square Turret features rugged construction and accuracy, assuring repetitive indexing within a few ten thousandths of an inch. A protective skirt around the bottom of the turret effectively keeps chips from the bearing surfaces. Daily maintenance of the square turret consists of oiling at the point indicated.

Rotate the **Turret Index Lever** counter clockwise to index the square turret.


Four cutters can be held in the square turret and each cutter indexed to the cutting position in sequence, according to the job requirements.




COOLANT SYSTEM

An impeller type pump with integral motor drive is mounted directly over the coolant sump, and is controlled by an independent push button switch mounted on the control panel at the front of the headstock.

The coolant sump, located at the head end of the machine, is divided into two compartments by a baffle. Metal particles settle in the first compartment, and thus the pump located in the second compartment is protected. The sump should be cleaned frequently.



CARRIAGE THREAD CHASING ATTACHMENT




The carriage thread chasing attachment, bolted to the carriage apron and driven by the feed shaft, is simply designed and easy to operate. Lifting the engagement lever meshes the follower with the leader. The quick acting automatic knockout controlled by the carriage stop screws facilitates threading close to a shoulder or blind hole.

When changing leaders disconnect the feed shaft driving coupling by removing taper pin, see above.

Slide the shaft to the right to allow for removal of leader. When tightening leader nut use one wrench on the leader and one on the nut to avoid shearing the pin in the coupling.

To change the follower, remove the top cover on the chasing attachment bracket. After the new follower is inserted, it may be adjusted to the leader by the screw located at the bottom of the chasing attachment.

CROSS SLIDE TAPER ATTACHMENT




The cross slide taper attachment is mounted on the rear of the cross slide in place of the rear tool post. The lower member of the taper guide carries

a yoke which engages a guide plate held by two studs on the head lever bracket.

MAINTENANCE AND ADJUSTMENTS

SECTION 3 HEADSTOCK ADJUSTMENTS


1. There are two double multiple disc clutches, one to obtain forward and reverse spindle rotation and one to provide quick high-low speed changes (Below).



The clutches have split adjusting nuts at each end which may be easily reached by removing the small covers on the top of the headstock. These clutches should not require adjustment more often than once or twice a year. When adjusting the clutches, keep trying the clutch levers in each direction while turning each nut a little at a time. After the right "feel" has been obtained in each clutch, be sure to tighten the locking screws in the split nuts before replacing the covers.

2. The spindle is mounted in two single row precision tapered roller bearings. A split adjustment nut, located on the rear end of the spindle outside the headstock, may be easily reached with a pin wrench after removing the small plate on the top of the head end bracket. In adjusting, all end play should be eliminated but no pre-loading should be introduced.

3. The headstock hydraulic system provides oil to operate the spindle brake and to spray lubricate



all moving parts in the headstock. The hydraulic pump is located in the clutch lever bracket directly in back of the spindle and supplies 50 to 60 lbs pressure to operate the spindle brake.

If the breaking action is slow, insert a pressure gage in place of the pipe plug fitting "D" on the back of the clutch lever bracket. The brake will not operate properly at a pressure below 50 lbs. (See Above)

The pressure may be regulated by adjusting the relief valve at point "E". If oil pressure is still too low, check for the following conditions.

1. Not enough oil in the headstock oil reservoir.
2. Clogged oil filter, located on the inside of the headstock oil reservoir cover.
3. Worn pump gear bushing which allows air to enter the hydraulic system.

If the pressure is correct and the breaking action is still slow, the brake should be disassembled, cleaned, and wire brushed. However, it should not be necessary to do this until the machine has been in use several years.

CARRIAGE AND SADDLE APRON ADJUSTMENTS

Each feed lever contains a safety spring which allows the tooth clutches to slip only under conditions which would be injurious to the machine.

Since the feed engagement clutches are of the

positive multi-tooth type, it is not necessary to adjust them to prevent slippage. The clutch teeth should be fully meshed when the feed lever plunger is engaged.

TURRET AND SLIDE ADJUSTMENTS

The hexagon turret revolves on and is located centrally by a large diameter tapered roller bearing. A double bevel circumference clamp ring tightens the turret against the slide and preloads the bearing for accurate centering and vertical alignment.

The turret slide travels on hardened and ground replaceable alloy steel ways in the saddle. It is guided between double, hardened, ground and lapped alloy steel gibs on each side, and held by sturdy hardened and ground steel top caps.

To move the saddle on the bedways, loosen the eight screws beneath the lower saddle caps. Do not loosen the adjustment screws on the back side of the saddle. A latch is provided for attaching to the cross slide carriage for easy movement of the saddle along the bedways.

A neoprene apron is attached to the front end of the slide just below the turret to keep chips and dirt out of the indexing mechanism. However, the slide should be occasionally removed so that the saddle may be thoroughly cleaned. To remove the slide, place a board across the bedways beneath the front of the slide, remove the saddle caps and raise the rear end of the slide until the front end rests on the board.

The front top cap consists of three separate pieces, the middle portion serving as a slide clamp. The binder handle has a serrated hole for easy positioning.

1. The clamping action of the turret clamp ring is controlled by a toggle arrangement (Figure 5). The clamp bolt should fit freely in both halves of the clamp ring and its nut should be adjusted so that when the turret is in the clamped position, a .005" to .010" feeler can be inserted between a section of the clamp ring and the spacer.




FIG. 5

The height of the trip release should be such that pin "A" lines up with the hole in the back section of the clamp ring (Figure 5) when the turret is in the clamped position. This locates the clamp release 1/16" over center and keeps the clamp ring from releasing. After some period of time the clamp release may become worn. To align pin "A" with the clamp ring hole, raise the threaded, four sided trip release the required amount.

The lock nut on the clamp stud should be tightened until sufficient clamping action results. As the turret slide is moved back and forth by rotating the turnstile and the clamp release rides over the release trip, a slight drag, but no binding should be felt.

To check the clamping action, index the turret half way and then bring the slide forward. In this position the clamp ring is closed, but the lock bolt is not engaged in the turret. Raise two of the turret binder bolts about two inches above the top of the turret. Place a bar between them and try to turn the turret.

2. If, after adjusting the clamp ring, the turret is still inaccurate, proceed as follows: move the slide to the rear, thus opening the clamp ring and indexing the turret. Bring the slide forward about half an inch. Insert a 2 inch bar in one of the turret holes. While applying pressure on the bar back and forth with one hand, place one finger of the other hand so it rests against both the turret and the back of the clamp ring. If movement is felt at this point between the turret and clamp ring, the outer race of the tapered bearing is set too low in the slide. Then place finger against the turret and front of the clamp ring and apply pressure as above. If movement is felt at the front of the turret the lock bolt and lock bolt bushings are worn.

Bring the slide forward until the leading edge protrudes about one inch from the saddle. Locate an indicator on the top surface of the turret. Tap the front of the clamp ring. If the indicator reading drops, either the outer race of the tapered bearing is set too high in the slide, or the flat bearing between turret and slide has become excessively worn.

The conditions outlined here should not occur for several years, even under hard usage. Correcting these troubles will entail one or more of the following operations:—relocating the tapered

bearing outer race, rescraping the bearing surfaces of the turret and slide, replacing the lock bolt sleeve and bushings, and rescraping the clamp ring. Because of the skill and experience necessary to properly perform these operations, we suggest that you contact the factory Service Department before proceeding.

3. After the machine has been in operation a few months it may be necessary to adjust the slide gibs. (Figure 6) The front gibs are not adjustable. There are two adjustable rear gibs. Loosen the cap screws for each gib on the back face of the saddle. The gib adjustment screws are set into each end of the saddle.

CROSS SLIDE AND CARRIAGE

Pairs of adjustable tapered gibs are provided at the outside of the front bedway, the bottom of the rear bedway and the lower or third bedway. One long tapered gib provides adjustment for the cross slide.

The cross feed screw is mounted in two opposed radial thrust ball bearings which are slightly preloaded and do not require adjustment. An adjustable double bronze nut, located in the front face of the carriage, is provided so that backlash can be eliminated from the feed screw.

A binder handle is provided for clamping the carriage to the bedways. The handle has a serrated hole for easy positioning.




FIG. 6




FIG. 7

CROSS SLIDE AND CARRIAGE ADJUSTMENTS

1. After the machine has been run for a few weeks check the adjustment of the gibs. Check these adjustments about twice a year thereafter. To adjust, back off the gibs between the apron and lower bedway. Tighten the gibs between the carriage and the front bedway until the carriage just begins to bind when the handwheel is turned. Then back the gibs off slightly and make sure there is equal tension on each gib screw. After releasing the set screws on the back face of the carriage, adjust the rear gibs in the same manner as indicated for the front gibs. Adjust the gibs between the apron and lower front way last. Tighten the cross slide gib until the slide just begins to bind. Then, back the gib off slightly. Make sure all gibs are held securely in the adjusted positions.

2. To eliminate backlash between the cross slide screw and nut, loosen the locking screws holding the bronze adjustment nut. (Figure 7) Turn the adjustment nut until the backlash is eliminated, and then retighten the locking screws.

SQUARE TURRET

The Bardons & Oliver Square Turret features rugged construction and accuracy, assuring repetitive indexing within a few ten thousandths of an inch. A protective skirt around the bottom of the turret effectively keeps chips from the bearing surfaces. Daily maintenance of the square turret consists of oiling at the point indicated on the figure.

When the indexing lever (1) is in the extreme clockwise position as shown in the figure, the lockbolt (2) is seated in the turret bushing (3) and the turret is clamped to the base. Tapered pins position the lockbolt cam (4) and stud collar (5) on the center stud (6) in the proper timed relationship. The indexing sequence is as follows:—The indexing lever is moved counter-clockwise. The turret is unclamped. The hardened pin (7) in the indexing lever engages the stud collar, causing the center stud to move with the indexing lever. The lockbolt cam engages the tumbler (8), depressing the lockbolt lever (9), which in turn disengages the lockbolt. The second hardened pin (10) in the indexing lever then engages the indexing plate (11) causing the turret to turn. The lockbolt rides on a recess in the turret until the next position is reached. Moving the indexing lever clockwise returns the lockbolt cam against the lockbolt sleeve (12). The indexing lever then disengages the stud collar and moves on the double acme threads causing the turret to be clamped to the base.

To properly maintain the square turret it should be completely disassembled and cleaned at least every six months. To completely disassemble, remove the bottom plate (13), stud collar (5), indexing lever (1), turret, center stud (6), tumbler pivot screw (14), tumbler (8), lockbolt lever (9), tumbler plunger (15), screw plug (16), lockbolt spring, and lockbolt (3) in that order. Reassemble in the reverse order, taking care that each part is placed in its original position, particularly the tumbler and lockbolt lever. Double acme threads locate the indexing lever on the center stud. It is possible to assemble this unit with the lever 180 degrees from the proper position. If the tapered pin which locates the stud collar on the center stud fits flush with both sides of the collar, the lever is properly positioned. If the pin goes in only half way, remove the indexing lever and reengage it opposite to the prior point of engagement. In adjusting the tumbler plunger the set screw should be tightened just enough to keep the tumbler in the proper indexing position. Tightening the set screw too much may cause the plunger to bind and shear.




FIG. 8

DIAGNOSIS OF IMPROPER SQUARE TURRET OPERATION

The following chart lists difficulties which may be experienced with the square turret operation, and indicates the cause and remedy for each trouble. See Figure 8.

TROUBLE	CAUSE	REMEDY
Turret remains stationary although indexing handle is turned one half revolution.	Indexing lever does not engage the indexing plate.	Remove the hardened pin in the indexing lever, clean, and on reassembly be sure the pin works freely.
Indexing lever moves only one quarter revolution and turret will not index.	Lockbolt does not disengage.	
	a) Set screw (17) holding tumbler plunger loosens.	Tighten set screw slowly until turret properly indexes.
	b) Tumbler plunger sticks.	Remove set screw, spring and plunger, clean, and be sure on reassembly that plunger works freely.
	c) Tumbler plunger broken.	Replace plunger. Plunger must work freely.
	d) Tumbler broken or excessively worn.	Replace tumbler.
	e) Lockbolt lever broken.	Replace lever.
Turret "Skips" or fails to stop at the next position on indexing.	Lockbolt spring worn.	Replace with about a quarter inch longer spring.
Repetitive indexing is inaccurate.	Lockbolt spring worn and lockbolt does not fully engage in turret.	Replace with about a one quarter inch longer spring.
	Lockbolt and lockbolt bushing excessively worn.	Recommend the square turret be sent back to the factory for rebuilding.
Turret drags or binds on indexing.	Tools in the turret held too tightly.	Tighten tools only as much as possible with wrench provided. Do not use pipe on wrench handle.
	Bottom plate does not clear the cross slide.	Remove bottom plate, clean, and file nicks which may cause loss of clearance between the bottom plate and the base bottom.

COLLET CHUCK

To change the collet pads, remove the pad screws from the master collet. These can be reached through holes in the collet hood. To avoid stock runout, clean the master collet and pads carefully before assembly.

Dirt and fine chips working into the collet and spindle recess may cause the collet to stick and not release. To avoid this condition, remove the collet hood and clean the collet and spindle recess frequently.

MASTER COLLET & PADS




GENERAL SAFETY

SECTION 4


- Before you turn on machine observe all safety rules in Section 2—Operating Instructions.
- Do not leave your machine running unattended.
- Do not attempt to remove or bypass any safety device on your machine.
- Use the proper size wrenches for tool change or adjustments. Discard worn or broken tools and wrenches. A wrench that slips may cause injury.
- Do not overload machine and stall motor.
- Always stop the spindle to check finish or dimensions.
- Do not use an air hose to blow away chips. Air will force dirt into ways and bearing surfaces. Air may blow chips into your eyes.
- After taking a cut be careful not to touch hot chips or parts. Do not remove chips while the spindle is running.

Do not use an air hose to blow away chips.




CHUCK SAFETY

- When loading or unloading parts, remove chuck wrench immediately. Do not leave the wrench in the chuck.
- Wait until the spindle comes to a complete stop before loading or unloading.
- Do not run the spindle with the chuck empty—centrifugal force may cause the jaws to come loose.
- Clean and inspect your chuck regularly—do not overload it. Know its limitations.
- Use the correct jaws for the job.
- Always use the chuck guard to direct chips and coolant down.
- Lubricate chuck as recommended.




Do not leave wrench in chuck for any reason.



Adjustable
Chuck Guard

Lubricate as
recommended by
chuck manufacturer



Specifications

BARDONS & OLIVER No. 3 Ram Type UNIVERSAL TURRET LATHE

Swing over bedways	2"	Hexagon turret power feeds
Swing over carriage guides	15 1/2"	.005, .008, .012, .018, .029, .047 ¹
Swing over cross slide	13 3/4"	Cross slide power feeds
Bar capacity round	7 7/8"	.003, .005, .008, .012, .020, .032 ¹
Bar capacity hexagon	2"	Carriage power feeds
Bar capacity square	1 3/4"	.005, .008, .013, .019, .031, .050 ¹
Hole in collet chuck plunger	1 7/16"	OPTIONAL CARRIAGE THREAD
Chuck size medium duty steel body	2 1/16"	CHASING ATTACHMENT
Spindle nose	8"	Pitches available—4 to 28 T.P.I. ²
Spindle hole diameter	A1	Effective length—5"
Spindle speeds, number	2 3/8"	OPTIONAL CROSS SLIDE
Spindle speed range	24	TAPER ATTACHMENT
	59-1505	Maximum taper—3" per foot
	70-1820	Effective length—6"
Maximum distance end of spindle to		Motor horsepower—10/5
face of turret	7"	Approximate shipping weight with motor—
Bed width across ways	1 1/2"	no tooling—3400 lbs.
Width of bedways	10"	Additional shipping weight collet chuck
Hexagon turret effective travel at one setting	8 1/4"	and bar feed—1000 lbs.
Hexagon turret size across flats	1 1/2"	
Diameter of tool holes	2 7/8"	
Center of tool holes to top of slide	9"	
Cross slide cross travel	18 1/2"	
Carriage longitudinal travel		

¹Feeds may be halved with fine feed gears
²8 to 56 T.P.I. with fine feed gears

BARDONS & OLIVER, INC.

