LIFT TO A CONTRACTOR OF A CONT

This installation guide is for left-hand charge. If your grille has a right-hand charge, please adjust installation of enplates accordingly.



LEFT HAND CHARGE

RIGHT HAND CHARGE



PHONE: 1 · 800 · 663 · 4599 FAX: 1 · 800 · 205 · 6665

Please refer to drawing for proper orientation.





Supports and Endplate Installation	
Between Lift Ready Aluminum Angles	page 1
Between Steel Angles	page 5
Between Jamb	page 9
Between Lift Ready Telescopic Tubes	page 12
Between Steel Tubes	page 16
Curtain Installation	page 19
Warranty	page 26

SAFETY WARNING

- -Only trained door installation technicicians should install, reset or perform maintenance.
- -All electrical connections are to be performed by qualified individuals and must confrom to local codes.
- -Door is under spring tension and can cause serious injury or death. Please take proper safety measures when adjusting tension.
- -Dynamic Closures is not responsible for an improperly installed door assembly.



PHONE: 1.800.663.4599 FAX: 1.800.205.6665

MOUNTING OPTION BETWEEN LIFT READY ALUMINUM ANGLES

RECOMMENDED FASTENERS

TYPE OF CUNSTRUCTION TO WHICH FASTENER EMBEDS	TYPE OF FASTENERS TO USE	HOLE SIZE (DRILL DIA.)	TAP SIZE (IF REQ'D)	DEPTH OF HOLE
WOOD	Ø3/8" X 2" LAG BOLT	Ø3/16″		1-1/2" MAX
WOOD	Ø1/2" X 3" LAG BOLT	Ø 5/16″		2-1/2" MAX
	Ø3/8" X 2-1/8" WEDGE ANCH.	Ø3/8″ CARBIDE		1-5/8" MIN
CONCRETE	Ø1/2" X 2-3/4" WEDGE ANCH.	Ø1/2" CARBIDE		2-1/4" MIN
CONCRETE	Ø5/8" X 3-1/2" WEDGE ANCH.	Ø5/8″ CARBIDE		2-7/8" MIN
	Ø3/4" X 4-1/4" WEDGE ANCH.	Ø3/4″ CARBIDE		3-1/2" MIN
MASONRY	Ø5/8" X 2-1/4" SLEEVE ANCH. (Ø1/2" BOLT)	Ø 5/8″		2″ MIN
OR BRICK	Ø3/4" X 2-1/2" SLEEVE ANCH. (Ø5/8" BOLT)	Ø 3/4″		2″ MIN
	Ø3/8″ BOLT	Ø 5/16″	3/8″-16UNC	
STEEL	Ø1/2" BOLT	Ø27/64″	1/2"-13UNC	
	Ø5/8″ BOLT	Ø17/32″	5/8″-11UNC	
	Ø3/4″ BOLT	Ø21/32″	3/4″-10UNC	





LIFT READY ALUMINUM ANGLE INSTALLATION



The Width to back of guides distance and total height, can be found on the drawings.





NOTICE: Angles must be plumb and level with each other. If the angles are not plumb and levelled, the gate may not operate properly. This may cause one of the angles to NOT sit on the floor, if floor is not level.





Mark and drill holes and fasten angles to surface using appropriate fasteners (Not provided. See the Recommened Fatener chart on page 2).

LIFT READY * - INSTALLATION INSTRUCTIONS

3

PLEASE PROCEED TO PAGE 19 FOR CURTAIN INSTALLATION





Z INSTALLATION

GUIDE INSTALLATION



RH



RH

MOUNTING OPTION BETWEEN STEEL ANGLES

RECOMMENDED FASTENERS

TYPE OF CUNSTRUCTION TO WHICH FASTENER EMBEDS	TYPE OF FASTENERS TO USE	HOLE SIZE (DRILL DIA.)	TAP SIZE (IF REQ'D)	DEPTH OF HOLE
WOOD	Ø3/8" X 2" LAG BOLT	Ø3/16″		1-1/2" MAX
WOOD	Ø1/2" X 3" LAG BOLT	Ø 5/16″		2-1/2" MAX
	Ø3/8″ X 2-1/8″ WEDGE ANCH.	Ø3/8″ CARBIDE		1-5/8" MIN
CONCRETE	Ø1/2" X 2-3/4" WEDGE ANCH.	Ø1/2" CARBIDE		2-1/4" MIN
CONCRETE	Ø5/8" X 3-1/2" WEDGE ANCH.	Ø5/8" CARBIDE		2-7/8" MIN
	Ø3/4" X 4-1/4" WEDGE ANCH.	Ø3/4″ CARBIDE		3-1/2" MIN
MASONRY	Ø5/8" X 2-1/4" SLEEVE ANCH. (Ø1/2" BOLT)	Ø 5/8″		2″ MIN
OR BRICK	Ø3/4" X 2-1/2" SLEEVE ANCH. (Ø5/8" BOLT)	Ø 3/4″		2″ MIN
	Ø3/8″ BOLT	Ø 5/16″	3/8″-16UNC	
STEEL	Ø1/2″ BOLT	Ø27/64″	1/2"-13UNC	
	Ø5/8″ BOLT	Ø17/32″	5/8″-11UNC	
	Ø3/4″ BOLT	Ø21/32″	3/4"-10UNC	

Angles provided with 3/8" holes. Should a larger fastener be needed, drill out the hole as required.





STEEL ANGLE INSTALLATION



EINSTALLATION Locate center of the opening, then mark off the distance* from the center line to locate angle placement (*Distance will be half the width to back of guides + 1/4"). Mark location with plumb lines.



NOTICE: Angles must be plumb and level with each other. If the angles are not plumb and levelled, the gate may not operate properly. This may cause one of the angles to NOT sit on the floor, if floor is not level.







PLEASE PROCEED TO PAGE 19 FOR CURTAIN INSTALLATION







2





BRACKET PLATE INSTALLATION

page 8 OF 26

MOUNTING OPTION BETWEEN JAMB

RECOMMENDED FASTENERS

TABLE 1 GUIDES

TYPE OF CONSTRUCTION TO WHICH FASTNER EMBED	TYPE OF FASTENER TO USE	HOLE SIZE (DRILL DIAMETER)	TAP SIZE (IF REQUIRED)	DEPTH OF HOLE
WOOD	#10 X 2 " WOOD SCREW (PROVIDED)	Ø 1/8″		1-½" MAX
CONCRETE	#10 X 1-½ " WOOD SCREW WITH #10 PLASTIC SHIELD	Ø 1/4 " CARBIDE		1-½" MAX
STEEL	ؼ"BOLT	#7	¼"-20 UNC	d
HOLLOW METAL	%-20 SELF DRILLING AND TAPPING SCREW	Ø 13/64"		

TABLE 2BRACKETS

TYPE OF CONSTRUCTION TO WHICH FASTNER EMBED	TYPE OF FASTENER TO USE	HOLE SIZE (DRILL DIAMETER)	TAP SIZE (IF REQUIRED)	DEPTH OF HOLE
WOOD	ؽ x 3″ LAG BOLT	Ø5/16"		2- ½" MAX.
CONCRETE	Ø ½" X 2- ¾" WEDGE ANCH.	ؽ" CARBIDE		2- ¼" MIN.
	Ø ½" X 3" EXP. SHIELD W/ Ø ½" FHMS	Ø ¾" CARBIDE		3" MIN.
STEEL	Ø ½" BOLT	Ø 27/64″	1/2"-13UNC	
MASONRY OR BRICK	Ø ½" X 2- ¼" SLEEVE ANCH. (Ø 3/8" BOLT)	Ø ½"		2″ MIN.

PARTS LIST

Door Guides (x2) Documentation Guide Screw #10 (x20) LIFT READY^{**} - INSTALLATION INSTRUCTIONS



(x1)



(x1)

page 9 OF 26



GUIDE INSTALLATION





BRACKET PLATE INSTALLATION



NOTE: It is important to level bracket plates for door to function properly.



Install the Charge Clip now. (See page 21 for charge clip installation) For ease of barrel installation, tape clip near top of "T" slot. Remove tape after barrel is installed.



CENTER OF GUIDE

Place bracket against jamb on top of guide and align bracket holes with the center of the guide. Mark and drill holes.



NOTE: If installing a fascia,

install fascia mounting brackets at this point. To be installed on the inside of the bracket plates.

PLEASE PROCEED TO PAGE 19 FOR CURTAIN INSTALLATION



MOUNTING OPTION BETWEEN TELESCOPIC TUBES PARTS LIST



Idler Bracket (x1)



Floor base angle (x2)





Tube template (x2)







TELESCOPIC TUBE FLOOR BASE ANGLES







SECURING TELESCOPIC TUBES



Loosen bolts. Press bolts in to release channel.

WARNING: Do not remove bolts.



0

Extended channel to structure above. Secure using method appropriate to structure materials.

0	Tighten bolts to secure Telescopic Tubes
0	

RETURN TO STEP 2 FOR SECOND TUBE



BRACKET PLATE INSTALLATION

NOTE: Bracket for charge side has a — "T" slot on the side.













MOUNTING OPTION BETWEEN STEEL TUBES

PARTS LIST







Secure tube to angle using 1/4in.-20 machine screw.



Place steel tubes over floor base angles.



BRACKET PLATE INSTALLATION

Place bracket over predrilled holes and insert and tighten 4in. bolt (supplied). Repeat for other side.



PLEASE PROCEED TO PAGE 19 FOR CURTAIN INSTALLATION

CURTAIN INSTALLATION



REMOVE ALL CARDBOARD PACKING TUBES, LEAVING THE BOTTOM CENTER TUBE IN PLACE.







BARREL ASSEMBLY INSTALLATION











CHARGE CLIP INSTALLATION





LOWERING BOTTOM BAR









TOP STOP INSTALLATION







CHARGING STEPS









TO REMOVE CHARGE: Put pressure on charging arm to remove tension from charge clip. Hold charge clip up and allow charge wheel teeth to rotate counterclockwise. Drop charge clip back down to engage teeth.

CAUTION: When adding charge, make sure charge clip is fully in the down position to lock the charge sprocket.

CAUTION: A charged spring is under high tension. Always use caution around door components once charge is applied.





CHARGE INSPECTION

Pull/push bottom bar down to floor to test door. Door should operate smoothly. Add or remove charge if necessary.





PHONE: 1.800.663.4599 FAX: 1.800.205.6665

www.DynamicClosures.com



OPERATION INSPECTION







Dynamic Closures Corporation One Year Limited Warranty

The Manufacturer warrants to the Buyer that all materials sold to the Buyer pursuant hereto are free from defects in material and workmanship under normal use and service for a period of **one (1) year from the possession date on new construction, or the installation date on remodels**. Abuse, misuse, and failure due to improper installation are not covered under the Manufacturer's warranty. The Manufacturer's obligation under this warranty is limited to repairing or replacing any parts, found to its satisfaction upon examination, to be defective.

The Manufacturer shall not be responsible for labor or other charges not expressly authorized in writing by the Manufacturer.

Said warranty shall not apply to any: parts, which have been altered or repaired by any person not expressly authorized in writing by the Manufacturer for such purpose, or by negligence, accident, or criminal act. The aforesaid warranty is made expressly in lieu of all other warranties, expressed or implied, and in lieu of any other obligations or liabilities on the part of the Manufacturer. Accordingly, the Manufacturer does not assume any other liability or obligation in connection with the sale of the grille, including any liability for special, consequential, or incidental damage to any person or property resulting from the use or possession thereof.

All other warranties express or implied, including any implied warranty of merchantability, are hereby expressly excluded.



