Fault symptom

If your Landroid®L does not work correctly, follow the trouble shooting guide below. If the fault persists, contact your Dealer. Refer to the Owner's Manual for Landroid®L component information.

| Symptom | Cause | Action |
|--|--|--|
| Landroid [®] L turns on, but the Blade Disc does not move. | Landroid [®] L is searching for the Charging Base. | This is normal, the Landroid [®] L needs to recharge, the Blade Disc does not rotate while it is searching for the Charging Base automatically. |
| Landroid [®] L vibrates. | Blades may be damaged. Check condition of the Blade Disc. | Check the Blades, and replace them if damaged . Clean the debris or foreign objects on the blades and blade disc. |
| Grass is being cut unevenly. | Landroid [®] L does not work enough hours per day. | Add more hours to the mowing time. |
| | Mowing area is too big. | Try decreasing the size of the mowing area or adding more hours to the mowing time. |
| | Blades are dull. | Change all the Blades and screws in order to balance the Bade Disc. |
| | The cutting height is set to low for the length of the grass. | Raise the cutting height and then gradually lower. |
| | Grass or other object has wrapped around the blade disc. | Check the Blade Disc and remove the grass or other object. |
| | There is a build-up of grass in the Blade Disc or Motor Frame Box. | Make sure the Blade Disc rotates easily. If need be, you may take off the Blade Disc and then remove the debris. See How to Clean. |
| The LED light on the Charging Base does not turn on. | There is no power. | Check that the power cord is connected properly and that the power source is sufficient. |
| Green light flashing on charging base. | The Boundary Wire isn't connected. | Check that the Boundary Wire has been connected correctly or that it has not been broken off. |
| The charging time is far more than 2.5h. | Poor connection caused by debris on the Charging Strip. | Clean the Contact Strip of the Charging Base and the Charging Strip on the Landroid®L using a cloth. |
| The mower does not charge. | There is no power. | Check that the power cord is connected properly and that the power source is sufficient. |
| | The Boundary Wire isn't connected. | Check that the Boundary Wire has been connected correctly or that it has not been broken off. |
| | Does not operate correctly while manually charging. | Connect the charger base while the machine is off. Before the LED light of the charging base turns green from red, press ON/OFF Key and close the Keypad Window to start charging. |
| Landroid [®] L is starting to have shorter run-times between charges. | Something is clogged in the Blade Disc. | Take off the Blade Disc and clean it. The grass is too high and too thick. |
| | Landroid [®] L is shaking heavily. | Check the Blade Disc and Blade, remove the grass or other object. |
| | The battery may be exhausted or old. | Replace a new battery. |
| Landroid [®] L is not operating at the correct time. | The clock is not set to the correct time. | Set the clock. |
| | The times set of the Landroid [®] L to start and stop mowing are incorrect. | Change the time settings for the mower to start and stop. |
| Landroid [®] L wheels skid or wheels rip the grass up. | Landroid [®] L cover is stuck by branches and followers, which may result in skipping when it hits obstacles. | Make sure to clear up the branches or followers inside Landroid®L's cover, and surround the branches or followers as an island to avoid further damage. |
| | Rain or irrigation makes the grass wet. | Please mow the grass when the grass is dry. |
| The Landroid [®] L exits the boundary wire due to high speed when going down a hill | The Boundary Wire is placed on a slope steeper than 25% (15°). | Reposition the Boundary Wire away from slopes that are steeper than 25% (15°). Please refer installation manual for details. |