

Firmware Update Procedure


This document describes how to update the firmware of NX-1.

The firmware can be upgraded using the Web Browser Interface of NX-1.


* This document uses the screenshots captured from Windows 7. However, the procedure will be the same if you are using an OS other than Windows 7.

- 1 Enter the IP address that is configured on NX-1 in the address bar of the Web browser. Press the ENTER key.


Example) Enter 192.168.0.100 and press the ENTER key.




- 2 Your Web browser will run and the login menu for NX-1 will be displayed. Enter the password and click **Login**. (By factory default, no password is set to NX-1.)





- 3 When the Web page of NX-1 is displayed, click **Firmware Update** under **Maintenance**.



- 4 In the **Firmware Update** page, click **Browse...** and select the firmware file to be loaded to NX-1 (NX-1.bin file). Check that the file name is displayed in New firmware field and click **Update**.



- 5 The update confirmation message is displayed. Click **OK** to begin the firmware update. Please wait until the update is complete.



* Do not turn off NX-1 or close your Web browser while the firmware update is in process.

- 6 When the login menu is displayed, the firmware update is complete. In the bottom left of the Web page, check that the version information is changed.