




BRIDGERSTEEL
CREATE LASTING BEAUTY



Mechanical Lock

www.bridgersteel.com



BRIDGERSTEEL

CREATE LASTING BEAUTY


Table of Contents

General Notes

Handling and Storage	1
Tools and Equipment, Field Cutting Panels	2
Safety	3
Preparing to Install your New Roofing	4
Reroofing Existing Structures	5
Panel Installation	6
Fastener Installation	7
Panel Profiles	8-9
Panel Profile / Panel Laps	10
Flashing Profiles	11

Flashing Details

Vented Ridge Cap	12
Non-Vented Ridge Cap	13
Hip - Ridge	14
2 x 6 Top Cap	15
2 x 4 Top Cap	16
2 x 6 Gable	17
2 x 4 Gable	18
2 x 4 Eave	19
2 x 6 Eave	20
Style D Eave	21
Fascia Trim	22
F & J Style Trim / 1/2" J-Trim	23
Endwall	24
Sidewall	25
Snow Break	26
Inside Corner	27
Outside Corner	28
Base Trim	29
Transition Low - High	30
Transition High - Low	31
24" W-Valley	32
Prow Gable	33
Overall Dormer	34
Dormer Tie-Ins	35



BRIDGERSTEEL
CREATE LASTING BEAUTY

Congratulations on your Customized Metal Package from Bridger Steel! We hope we have helped you *Create Lasting Beauty*

When picking up or receiving your metal package check the parts you received against the invoice. If there are any discrepancies notify Bridger Steel Personnel right away.


Handling

Handle your panels and trim with care to avoid damage. Longer panels may need more than one pickup point when lifting on or off a trailer. Trim bundles can be heavy and awkward. Don't lift more than you can safely handle. Break open the bundle if needed.

Storage

Bridger Steel recommends you should have your structure built before ordering metal. With actual building measurements, your materials can then be ordered. Because of our quick turnaround time you will have the material in a matter of one to three days. The longer the metal package is stored at your work site, the more opportunity for damage to occur.

If for some reason you cannot install the metal right away, proper storage is a must. Store metal panels and other materials in a covered, dry, well ventilated area ensuring moisture and direct sunlight are kept away from panels. If stored outside, wrap a tarp loosely around the panel bundles so air can circulate freely to avoid moisture build-up. One end of the bundle should be elevated so any accumulated moisture can run off. Never store materials in direct contact with the ground. The trim package you receive has a protective plastic film on it. The film should be removed within 90 days.



Tools and Equipment


- Screw Gun
- Tin Snips
- Tape Measure
- Pop Rivet Tool
- Chalk Line
- Hemming Tool
- Locking Pliers
- Nibbler
- Circular Saw*

****When using a circular saw to cut metal panels, always cut from the back side of the metal panel to keep the metal shavings from marring the paint. Always wear hearing and eye protection when using saws to cut metal.***

Field Cutting panels

Tin snips or nibblers are recommended for cutting metal panels and trim. All cut metal shavings should be removed from the panel to prevent damage to the finish. One way to prevent shavings on the finish side of the panel is to cut from the primer side of the panel. Never cut panels on top of existing panels. Always wear gloves and eye protection when cutting metal panels. If using a circular saw always wear hearing protection! All installed products should be wiped free of any debris at the end of each workday.

CAUTION! Clean all metal shavings and particles off of roof to avoid unsightly rust stains.



Safety

Safety is always your first consideration when installing your metal package. Hazards exist on the ground as well as on the roof.


- Always be aware of where you are on the roof. Openings, edges, electrical lines and tripping hazards (cords and equipment) are a constant danger.
- Watch electrical lines when maneuvering panels.
- Never install metal roofing on windy or stormy days. The wind can get under the panel and force you off the roof. Once the panel is loose and airborne it can become a sharp projectile.
- Roofing can be very slick when dusty, wet, or covered with frost. Avoid being on the roof when these conditions are present.
- Never step on panels until they are in place and secured with fasteners. Then only step in the flat areas and not on the panel ribs.
- Wearing soft soled shoes will help with traction while preventing scratching the panels.
- Use fall protection where needed.
- Be aware of your coworker. Make sure they are not putting themselves in danger.
- If your building has an open purlin system make sure to walk on the purlin not in between the purlin this may result in injury.

Preparing to Install Your New Roofing


Bridger Steel quality light gauge material can be used for new or existing structures.

Prepping New Construction

1. If you need openings cut for venting through the ridge or plumbing vents or electrical conduits, now is the time to add them before panel installation.
2. It is very important to check for protruding nails and other objects which may puncture the underlayment and roofing panels. Be sure to clean all foreign materials from the roof.
3. Cover the deck with a moisture barrier such as a minimum 30 # pound felt or other approved underlayment. Begin at the eave and roll the underlayment horizontally (along the eave). Overlap the next strip at least 3 inches. (Place a hi-temp ice & water membrane underlayment in areas which snow, ice, and rain can accumulate, such as valleys and eaves. This will be applied to the roof before rolling the 30 # felt out).
4. Place an alignment line along the gable end where the first panel will be installed. This line must be parallel to the gable edge of the roof and square with the eave edge. Check the roof for squareness by making a 3 foot line across the eave. (See illustration) Completing the 3' x 4' x 5' triangle should place the 4' line parallel along the gable edge. The first panel will be placed along this line. Any out of square conditions up to 3" can be covered by the gable trim.



It is important to measure the roof from gable to gable. Proper placement of panels will allow the panel ribs on each side to be covered by the gable trim while creating a symmetrical appearance on the roof.



Reroofing Existing Structures

It's best if existing roofing such as shingles, cedar shakes be removed so there is a smooth flat substrate for installing metal roofing panels. Metal roofing should never be installed over an uneven surface.

Another good reason for stripping a roof is to look for any defects which need repair or replacement.


Never apply metal roofing over a damaged substrate.

(If you are going to strip the roof go back to new roof installation, see Page 4)

If you do decide to apply over existing roofing, inspect the roof for defects and repair so the new roofing has a flat surface to be applied to.


1. Secure or remove any warped roofing.
2. Make sure there are no protruding nails or other objects which may affect the new underlayment or roofing panels.
3. Remove all moss and other debris.
4. Remove all hip cap, ridge cap, and penetration flashing.
5. Cover the deck with a moisture barrier such as a minimum 30 # pound felt or other approved underlayment. Begin at the eave and roll the underlayment horizontally (along the eave). Overlap the next strip at least 3 inches. (Place a hi-temp ice & water membrane underlayment in areas which snow, ice, and rain can accumulate, such as valleys and eaves. This will be applied to the roof before rolling the 30 # felt out).
6. Place an alignment line along the gable end where the first panel will be installed. This line must be parallel to the gable edge of the roof and square with the eave edge. Check the roof for squareness by making a 3 foot line across the eave. (See illustration, Page 4) Completing the 3' x 4' x 5' triangle should place the 4' line parallel along the gable edge. The first panel will be placed along this line. Any out of square conditions up to 3" can be covered by the gable trim.

It is important to measure the roof from gable to gable. Proper placement of panels will allow the panel ribs on each side to be covered by the gable trim while creating a symmetrical appearance on the roof.



Panel Installation

Study the trim details in this manual before installing the panels. Pay close attention to Valleys, Eaves, and Transitions. Follow these basic guidelines



1. Install eave trim, valley trim prior to panel installation.
2. Always install your panels into the prevailing wind.
3. Align the edge of the first panel with the alignment line constructed along the gable end. Allow the panel to overhang the eave 1 to 2".


(If venting through the ridge make sure you hold the underlayment down 2" from the ridge. Also make sure your decking is 2" down from the top of the ridge on both sides. Doing this will allow for air circulation in the attic space.)

4. After the first panel is properly aligned, Fasten per the fasteners placement and spacing guide on page 7.

- a. (Lay down second and third panels, check the alignment, and be sure they are square.) You may have to stretch or shrink the panel by either pulling the top or bottom of the panel to make up the distance needed to be square. If you have over a 1/4" to make up it is best to stretch or shrink the panel over the next few panels.

FASTENERS		
CORRECT	TOO LOOSE	TOO TIGHT
EPDM MATERIAL IS COMPRESSED AND VISIBLE AT WASHER. FASTENER IS PROPERTY INSTALLED.	EPDM NOT AT VISIBLE JOINT. NOT ENOUGH COMPRESSION TO MAKE A SEAL.	FASTENER IS OVER-DRIVEN AND EPDM IS PROTRUDING BEYOND EDGE OF FASTENER.

5. After the panels are installed, you can install the rest of your trim and flashing. Start at the eave edges and work your way up. For example, place your gable trim starting at the bottom edge and work towards ridge. If pieces must be overlapped; a 2" minimum is recommended. Once the gable trim is installed, you may then install the ridge cap. Please see trim details on how each piece of trim is installed.




BRIDGERSTEEL

CREATE LASTING BEAUTY


Fastener Installation

Screw fasteners have been proven to have 2 to 3 times the holding power of nails. For maximum holding power, it is recommended that the minimum wood penetration be 1 inch. Utilizing pancake head screw fasteners have an excellent quality and are specifically designed for fastening clips to the metal roofing panels. For OSB and plywood 1/2" or less, use #14 x 1" wood screws.



All testing based on 24ga material


To prevent damage to panels and trim, install immediately or store in a cool dry area. Carbonized Steel, Galvanized Steel, Aluminized Steel, Galvalume and all alloys of Aluminum are susceptible to what is commonly referred to as "White" or "Black" rust and water stain. These are caused by electrolysis, which occurs when moisture exists between stacked sheets. Painted metal products are also susceptible to a change of or loss of paint gloss discoloration, delaminating, disintegrating, and other accelerated defects of the paint as a result of moisture between the panels sheets. Bridger Steel assumes no responsibility of liability for damage to our product which occurs in the possession of the consignee or which we deem to be improper handling and storage. If panels are to be cut or drilled be certain to wipe free any metal filings that may accumulate. Protective plastic film on the trim should be removed within 90 days. Failure to follow these instructions may void the warranty.



BRIDGERSTEEL


CREATE LASTING BEAUTY

Refer to 2" load chart on panel width




Panel Profile

All mechanical lock panels need to be double seamed or warranty will be voided




90° SEAM




180° SEAM

Seams

Please refer to Bridger Steel's clip chart on spacing and gauge of clips.



SLIDER CLIP




FIXED CLIP

Clips

All testing based on 24Ga material

PANEL PROFILE & LAPS

2" Mechanical Lock




BRIDGERSTEEL

CREATE LASTING BEAUTY


Flashings

FLASHINGS


1a) VENTED RIDGE CAP




1b) NON VENTED RIDGE CAP




2) HIP RIDGE




3a) 2x6 TOP CAP




3b) 2x4 TOP CAP




4a) 2x4 GABLE




4b) 2x6 GABLE




5a) 2x6 EAVE




5b) 2x4 EAVE




5c) STYLE D EAVE




9) ENDWALL




10a) SIDEWALL




20a) TRANSITION HIGH LOW




20b) TRANSITION LOW HIGH




14) INSIDE CORNER




15) OUTSIDE CORNER




8a) F & J TRIM




18) 2\" J TRIM




13) Z METAL




23) Z TRIM




6) FASCIA




11) SNOW BREAK




19) F TRIM FOR SOFFIT



22) OFFSET CLEAT




8b) 1/2\" J TRIM




12) DOOR CAP




16) BASE DRIP




17) 24\" W-VALLEY




22) OFFSET CLEAT




8b) 1/2\" J TRIM



21a) OPEN PROWN GABLE




2\" Mechanical Lock



BRIDGERSTEEL


CREATE LASTING BEAUTY




2" Mechanical Lock - Wood Deck Vented Ridge Cap

NOTES:

1. Make sure to leave a 2" gap from both sides of the ridge.
2. Install roof panels on both sides of the ridge, making sure not to cover up the 2" opening at the ridge.
3. Place vented closures on roof panel and fasten down both sides of the ridge on every major rib.




Vented Ridge Cap
10'-2" Pes.




BRIDGERSTEEL

CREATE LASTING BEAUTY



NOTES:


1. Install roof panels on both sides of ridge.
2. Cut Z closure to fit between seams.
3. Set Z closure in butyl tape sealant.
4. Fasten Z closure with (5) fasteners per panel.
5. Place ridge on Z closure and fasten 12" O.C.



Non-Vented Ridge Cap


10'-2" Pcs.

2" Mechanical Lock - Wood Deck Non-Vented Ridge Cap



BRIDGERSTEEL

CREATE LASTING BEAUTY




Hip/Ridge

2" Mechanical Lock - Wood Deck

NOTES:


1. Install roof panels on both sides of ridge.
2. Cut Z closure to fit between seams.
3. Set Z closure in butyl tape sealant.
4. Fasten Z closure with (5) fasteners per panel.
5. Place ridge on Z closure and fasten 12" O.C.

Provide Roof Pitch
12
x



Hip / Ridge

10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY

FASTENER, 12" O.C.

Z CLOSURE SET IN BUTYL TAPE SEALANT, (5) FASTENERS PER PANEL, CAULK VERTICAL SEAMS

BOX END OF PANEL


UNDERLAYMENT

TOP CAP

CONT. CLEAT, FASTEN 12" O.C.


SLIDING CLIP

12" Max.




NOTES:

1. Box end of panel.
2. Install roof panels.
3. Cut Z closure to fit between seams.
4. Set Z closure in butyl tape sealant.
5. Fasten Z closure with (5) fasteners per panel.
6. Place Top Cap on Z closure and fasten 12" O.C.




2 x 6 Top Cap

2" Mechanical Lock - Wood Deck



BRIDGERSTEEL

CREATE LASTING BEAUTY





2x4 Top Cap

2" Mechanical Lock - Wood Deck

NOTES:


1. Box end of panel.
2. Install roof panels.
2. Cut Z closure to fit between seams.
3. Set Z closure in butyl tape sealant.
4. Fasten Z closure with (5) fasteners per panel.
5. Place Top Cap on Z closure and fasten 12" O.C.





BRIDGERSTEEL

CREATE LASTING BEAUTY




2 x 4 Gable

2\" Mechanical Lock - Wood Deck


NOTES:

1. Run panels across roof deck cutting and field bending last panel to fit.
2. Install Z closure in continuous butyl tape along rake/gable edge on top of roof panel.
3. Install continuous cleat along fascia.
4. Install rake/gable trim hooking onto cleat.
5. Install rake/gable on Z closure fastening 12" o.c.




2x4 Gable

10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY




2 x 6 Gable

2" Mechanical Lock - Wood Deck


NOTES:

1. Run panels across roof deck cutting and field bending last panel to fit.
2. Install Z closure in continuous butyl tape along rake/gable edge on top of roof panel.
3. Install continuous cleat along fascia.
4. Install rake/gable trim hooking onto cleat.
5. Install rake/gable on Z closure fastening 12" o.c.



2x6 Gable


10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY



2 x 4 Eave



NOTES:

1. Install continuous cleat along fascia.
2. Install eave trim hooking onto drip edge.
3. Nail upper flange of eave flange to roof deck 12" o.c.
4. Apply offset cleat in continuous butyl tape sealant on eave flashing fastening through the sealant at 12" o.c.
5. Apply underlayment over top of nailing flange.
6. Notch upper roof panel 1" and form around offset cleat.


Provide Roof Pitch



2x4 Eave


10'-2" Pcs.

2" Mechanical Lock - Wood Deck



BRIDGERSTEEL

CREATE LASTING BEAUTY





2 x 6 Eave

2" Mechanical Lock - Wood Deck

NOTES:


1. Install continuous cleat along fascia.
2. Install eave trim hooking onto drip edge.
3. Nail upper flange of eave flange to roof deck 12" o.c.
4. Apply offset cleat in continuous butyl tape sealant on eave flashing fastening through the sealant at 12" o.c.
5. Apply underlayment over top of nailing flange.
6. Notch upper roof panel 1" and form around offset cleat.





BRIDGERSTEEL

CREATE LASTING BEAUTY




Style D Eave

2" Mechanical Lock - Wood Deck


NOTES:

1. Install continuous cleat along fascia.
2. Install eave trim hooking onto drip edge.
3. Nail upper flange of eave flange to roof deck 12" o.c.
4. Apply underlayment over top of nailing flange.
5. Notch upper roof panel 1" and form around style D eave.




Style D Eave

10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY




Fascia

2" Mechanical Lock - Wood Deck


NOTES:

1. Apply metal fascia over soffit and over fascia material.
2. Fasten metal fascia to fascia board every 12".




Fascia

10'-2" Pes.




BRIDGERSTEEL

CREATE LASTING BEAUTY




NOTES:

1. Place either F&J or 1/2" J Trim on wall of the building.
2. Make sure that the F&J or 1/2" J Trim is parallel with your fascia.
3. Once F&J or 1/2" J Trim is installed either install wall panels or soffit panel.




F & J Trim
10'-2" Pcs.




1/2" J Trim
10'-2" Pcs.

2" Mechanical Lock - Wood Deck F & J Trim / 1/2" J-Trim



BRIDGERSTEEL

CREATE LASTING BEAUTY




End wall

2" Mechanical Lock - Wood Deck


NOTES:

1. Box panel end.
2. Install roof panels.
3. Install Z closure on roof panels in continuous butyl tape sealant.
4. Place endwall on Z closure and fasten endwall trim every 12" o.c.
5. Fasten upper flange to wall every 12".




Endwall

10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY




Sidewall

2" Mechanical Lock - Wood Deck


NOTES:

1. Run panels across roof deck, cutting and field bending last panel to fit.
2. Install panel.
3. Install Z closure on roof panel in continuous butyl tape sealant.
4. Install Sidewall Flashing on top of Z closure.
5. Fasten sidewall to Z closure every 12" o.c.
6. Fasten upper sidewall flange to wall every 12" o.c.




Sidewall

10'-2" Pcs.




BRIDGERSTEEL

CREATE LASTING BEAUTY




NOTES:

1. Install all roof panels.
2. Snow retention runs in perpendicular direction of roof panels.
3. If building has an overhang, place snow retention over the exterior load-bearing wall.
4. If structure has no overhang, place snow retention approximately 2 ft. from eave.




S-5 ColorGard

2" Mechanical Lock - Wood Deck S-5 ColorGard



BRIDGERSTEEL

CREATE LASTING BEAUTY




Inside Corner

2" Mechanical Lock - Wood Deck


NOTES:

1. Install wall panels.
2. Install Z closure on top of panels in continuous butyl tape sealant.
3. Install corners on Z closures, always working from base of wall to roof. Fasten every 24" on both sides of corner.




Inside Corner

10'-2" Pcs.




BRIDGERSTEEL

CREATE LASTING BEAUTY



NOTES:


1. Install wall panels.
2. Install Z closure on top of panels in continuous butyl tape sealant.
3. Install corners on Z closures, always working from base of wall to roof. Fasten every 24" on both sides of corner.



Outside Corner


10'-2" Pcs.

2" Mechanical Lock - Wood Deck




BRIDGERSTEEL

CREATE LASTING BEAUTY



NOTES:


1. Apply Base Trim to bottom of wall to keep panels straight.
2. Base trim must be installed above ground and fastened every 12" o.c. on nailing flange.



Base Trim
10'-2" Pcs.


Base Trim

2" Mechanical Lock - Wood Deck



BRIDGERSTEEL


CREATE LASTING BEAUTY



2" Mechanical Lock - Wood Deck Transition Low-High


NOTES:

1. Install lower roof panels.
2. Install Z closures to lower roof panels.
3. Install Low High Transition over Z closure, make sure the transition covers closures. Fasten 12" o.c.
4. Fasten upper leg of transition every 12".
5. Install offset cleat on upper leg of transition.
6. Notch upper roof panel 1" and form around offset cleat.




Transition Low High

10'-2" Pcs.




BRIDGERSTEEL

CREATE LASTING BEAUTY



NOTES:


1. Install lower roof panels.
2. Install Z closures to lower roof panels.
3. Install High Low Transition over Z closure, make sure the transition covers closures. Fasten 12" o.c.
4. Fasten upper leg of transition every 12".
5. Install offset cleat on upper leg of transition.
6. Notch upper roof panel 1" and form around offset cleat.



Transition High Low


10'-2" Pcs.

2" Mechanical Lock - Wood Deck Transition High-Low



BRIDGERSTEEL

CREATE LASTING BEAUTY




24" W-Valley

2" Mechanical Lock - Wood Deck


NOTES:

1. Install underlayment in bottom of the valley.
2. Lay valley panel down and fasten 2" from the outside edge every 12" o.c.
3. Apply second layer of underlayment over outer edge of valley, approximately 3" down on both sides of the valley.
4. Install offset cleats on both sides of valley.
5. Notch panels 1" and form around offset cleat.




24" W-Valley

10'-2" Pcs.



BRIDGERSTEEL

CREATE LASTING BEAUTY




ProW Gable

2" Mechanical Lock - Wood Deck


NOTES:

1. Install underlayment over edge of prow gable.
2. Lay prow gable trim down and fasten 2" from the outside edge every 12" o.c.
3. Apply universal closure under panel leaving panel 1" from flashing closure.
4. Install offset cleat.
5. Notch panels 1" and form around offset cleat.




Open Prow Gable

10'-2" Pcs.



BRIDGERSTEEL


CREATE LASTING BEAUTY



Overall Dormer

Overall Dormer


2" Mechanical Lock - Wood Deck



BRIDGERSTEEL


CREATE LASTING BEAUTY

Ridge Tie-In



- UNDERLAYMENT
- VALLEY PAN
- FASTENER
- UPTURN RIDGE CONT. UP SLOPE
- BUTYL TAPE SEALANT
- UNIVERSAL CLOSURE SET IN BUTYL TAPE SEALANT
- FASTENER, 12" O.C.
- 2" MECHANICAL LOCK PANEL


Valley Tie-In



- VALLEY PAN
- FASTENER, 12" O.C.
- UNDERLAYMENT
- UNIVERSAL CLOSURE SET IN BUTYL TAPE SEALANT
- BUTYL TAPE SEALANT
- FASTENERS AS PER HEAD LAP CONDITIONS


Dormer Tie-In

2" Mechanical Lock - Wood Deck



BRIDGERSTEEL

CREATE LASTING BEAUTY



Dormer Tie-In