



NOTE: USE TAPERED ROOF INSULATION (EDGE STRIPS) TO CREATE DRAIN SUMP. IF TOTAL INSULATION THICKNESS IS LESS THAN OR EQUAL TO 1 1/2 IN., TAPER 12 IN. FROM THE DRAIN CENTER. IF TOTAL INSULATION THICKNESS IS GREATER THAN 1 1/2 IN., TAPER 18 IN. FROM DRAIN CENTER.



GENERAL REFERENCE:  
 "FTR GS 01/21"  
 APPLICABLE SYSTEMS:  
 "FTR MA 01/21"  
 "FTR AD 01/21"  
 "FTR BA 01/21"

TYPICAL DRAIN FLASHING  
 FLEECEBACK OR REINFORCED MEMBRANE

REVISES DETAIL  
 ALL PREVIOUS

ISSUE DATE  
 02-23-21

DRAWING NUMBER  
 FTR-DD3