



FLEX-A-MAT INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flex-a-mat®
 Address: 11006 Reading Road, Suite 301
 Cincinnati, Ohio 45242
 Telephone: 513-772-6689
 Fax: 513-772-6690
 Contact: Matt Motz
 Website: Matt@Flexamat.com
 www.Flexamat.com

CONSTRUCTION NOTES:

1. GRADE A UNIFORM SUBGRADE. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS WITH NO SHARP OR ABRUPT BREAKS IN THE GRADE. FLEX-A-MAT BLOCKS HAVE A 2" RISE; GRADE SO THAT THE TOP OF THE MAT WILL TRANSITION INTO THE LANDSCAPING.
2. INSTALL RECYCLEX TRM OR EQUIVALENT. TRM SHALL EXTEND THE ENTIRE WIDTH OF THE PROPOSED FLEX-A-MAT AREA.
3. INSTALL FLEX-A-MAT ROLLS. ROLL WIDTHS ARE 5.5', 8', 10', 12', & 16'. MATS SHALL BE INSTALLED SO THAT THE FLEX-A-MAT EXTENDS 3'-0" ABOVE THE ANTICIPATED HIGH WATER ELEVATION AND 3'-0" BELOW ANTICIPATED LOW WATER ELEVATION.
4. SPREAD SHREDDED TOPSOIL OVER MAT. SWEEP SOIL BETWEEN BLOCKS AND USE SOIL TO TRANSITION FROM MAT AND INTO LANDSCAPE
5. SEED THE AREA WITH SITE SPECIFIC SEED MIX. NATIVE GRASSES AS WELL AS OTHER LITTORALS WILL GROW WITHIN MAT.
6. ABOUT THE NEXT SECTION OF MAT TO THE PREVIOUS SECTION. A CONCRETE SAW MAY BE NECESSARY TO CUT MAT TO FIT TIGHTLY TO ADJACENT SECTION OF MAT.

**FLEX-A-MAT®
 SHORELINE ARMORING DETAIL
 NTS**

