

SCREEN

Gazebo Kits Wood Screen Instructions www.alansfactoryoutlet.com

INSTALLATION

INSTRUCTIONS

(WOOD)



This Is Step #1.
Attach Fastening Strip On Post
And Fasten With 2" Screws. This
Should Be Done After Rails Are
Attached To Posts And Before
Roof Is Started. Note Location
Of Top Aluminum Closure on Fas-
tening Strip. Screen Panel Will
Slide Up Behind This Piece After
Gazebo Is Assembled.



Attach Aluminum Closure Pc To
Top 2x4 As Shown In Photo. Use
3 - Roof Nails To Attach.
Approx. 1 7/8" From Outside Of 2x4
This Step Should Be Done Before
Installing Roof Rafters.

Gazebo Kits Wood Screen Instructions www.alansfactoryoutlet.com

Fasten Corner Block To Corner Rafter And To Jack Rafter Fasten With 2" Screw. Position On Top Of Post And Flush With Top Of Rafter. Make Sure Block Does Not Pertrude Above Rafter.



Fasten Screen Board To Block With 2" Screw On Each End Of Screen Board.



Photo Of Installed Screen Boards.



Photo Of Screen Boards
& Blocks At Jack Rafter.



View Of Upper Roof
Screens.
(Victorian Model)



OUTSIDE VIEW OF DOOR.

Attach Door Frame To Top Rail Section With 3- 2" Screws. Fasten Bottom Of Jamb To Inside Of Step With 2 - 3" Screws On Each Side. After Door Is Secured Install Short Rail Sections And Attach With 2" Screws.



INSIDE VIEW OF DOOR.

Line Inside Of Door Jamb And Bottom Of Top Rail With Lath Provided. Keep Flush With Door Opening And Fasten With 2" Screws. Then Install Screen Panels Around Door And Turn Clips To Secure. Use Extended Clips For Around Door.

