

# A-Frame Shed Kit Assembly Instructions

- Step #1 Remove all material from inside of building.
- Step #2 Remove all screws starting at wall #4.
- Step #3 Remove each wall panel when all screws are removed.
- Step #4 Place floor on final site and level both ways.
- Step #5 Reattach walls starting with # 1. Nail corners and all bottom 2x4's.
- Step #6 Nail rafters 16" on center at markings on top of wall # 1 & #3. Keep rafter notch against wall.
- Step #7 Install 4' plywood with 16" on center markings at peak. Start with 4'x8' piece.
- Step #8 Install felt paper starting at bottom of roof with 2" overlap on each row of felt paper.
- Step #9 Install drip edge around perimeter of roof.
- Step #10 Install shingles as per instructions on shingle wrapper.
- Step #11 Install corner trim pieces.
- Step #12 Use touch up paint on all scuffs and nail heads.

Congratulations you just finished building your shed. Enjoy.

If you have family or friends that are in need of a storage building please remember us at Alan's Factory Outlet, Luray VA.

[www.alansfactoryoutlet.com](http://www.alansfactoryoutlet.com)

(540) 743-1272