

## Rope on Black Handle Instructions for TP 6870, 6830, 6850

To insert rope from the handle opening to the desire length:



Pull rope against handle until rope can go inside of handle as shown on this picture:





Note: We recommend adding a knot at end of rope after the handle is installed to prevent handle form getting misplaced





