



**TOWN & COUNTRY PLASTICS**

*Customized For Precision*

**10B Timber Lane, Marlboro, NJ 07746 • (732) 780-5300 • FAX: (732) 294-0001 • [www.tandcplastics.com](http://www.tandcplastics.com)**

## Recommended Excavation, Backfilling, and Finishing for Interior or Exterior Below Grade XL Series Interceptors

- A. Install the interceptor(s) as close as practical to the fixtures being served.
- B. The excavation must be a minimum of 12" greater on all sides of the tank.
- C. The depth of the excavation must be greater than 6" on the bottom of the interceptor.
- D. Fill the interceptor with water prior to backfilling in order to prevent the interceptor from floating.
- E. Fully install the double wall corrugated pipe and lid prior to backfilling.
- F. Concrete or finishing material requirements is to be determined by the specifying engineer.
- G. Encase the interceptor in well-packed  $\frac{3}{4}$ " rock, or sand.
- H. To prevent float out; the Anchor kit is recommended for installations in high water table conditions. This is to be determined by the specifying engineer.