

# MODEL NUMBER:

# AA1400 SERIES CEILING MOUNT

Document Number: PD196-381R1

# **CMT COVER INSTALLATION**

Page 1 of 1

# ARM COVER INSTALLATION

## Safety steps:

- 1) Always wear safety glasses/goggles to prevent injury from debris.
- 2) Follow the installation/removal instructions for your existing products.

### **TOOL LIST:**

- 1) P1 or P2. Phillips screw driver
- 2) Safety glasses/goggles

#### NOTE:

- 1) Attach arm to Ceiling Mount Support and mount TV to arm before beginning cover installation.
- Arm Safety Brake Pin must be removed from arm nose to install the new Nose Arm Cover.
- DO NOT DISCARD SAFETY BRAKE PIN. Keep the safety pin for future service of the arm and/or TV. Locate the plastic Retainer Clip attached to the Arm's safety brake pin. Attach the safety brake pin/clip to the coax cable inside the nose as shown below.

## STEP 1.

Securely snap the Elbow Covers around the elbow joint. Hook over the top edges of the elbow plates then snap the lower hooks along the bottom edges.

When the halves are properly installed there should only be a thin seam visible where the halves meet.

Attach the left and right Nose covers to the nose, using (4) PD209-004 screws, hand tighten.

When the halves are properly installed there should

only be a thin seam visible where the halves meet.

## STEP 3.

Rotate the TV and move the arm through its range of travel to check for any interference issues.

## **PARTS LIST for KIT:**

- 1) (2) PD216-103 Elbow Covers
- 2) (1) PD216-057L Left Nose Cover
- 3) (1) PD216-057R Right Nose Cover
- 4) (4) PD209-004 Painted Cover Screw



