

1. Locate a wall stud near an AC wall and RF outlet.
2. Position the mounting bracket over the wall stud with the top of the bracket no less than 13" below the ceiling. Mark three mounting holes on the wall.
3. Attach the bracket to the wall with 1/4x20 hardware (not supplied).
4. Place the TV Tray over the Pivot hole and attach with a Hex Head Cap Screw, flat washers and Locking Nut as shown. Make certain to use the Plastic Washer between the mounting bracket and TV Tray.
5. Mount the 13" TV (not shown) on the Tray with the TV's mounting studs positioned through the tray holes. Tighten nut and washer on each bolt.

