

	MODEL NUMBER: <b>PD216-007</b>	Document Number: PD196-226R3
	Cover Kits for 1000 Series CMT Arms	Page 1 of 1

**Safety steps:**

- 1) Always wear safety glasses/goggles to prevent injury from debris.
- 2) Follow the installation/removal instructions for your existing products.

**Tool List:**

- 1) P1 or P2, phillips screw driver
- 2) Pliers
- 3) Safety glasses/goggles

**Note:**

- 1) Attach arm to wall bracket and mount TV to arm before beginning cover installation.
- 2) Arm Safety Brake Pin must be removed from arm nose to install the new Nose Arm Cover.
- 3) **DO NOT DISCARD SAFETY BRAKE PIN. Store the safety pin under one of the extra clamps in the nose of the arm for future service of the arm and/or TV.**

**Step 1.**

Snap the (2) PD216-001 End Caps into the ends of the arm section as pictured.

**Step 2.**

Securely snap the Elbow Covers PD216-003 around the elbow joint. Hook over the top edges of the elbow plates then snap the lower hooks along the bottom edges.

When the halves are properly installed there should only be a thin seam visible where the halves meet.

**Step 3.**

Attach the left and right Nose covers PD216-004R, PD216-004L to the nose using (4) PD209-004 screws as pictured. Tighten the (4) PD209-004 screws to secure the nose covers.

Now install the PDIPPTL61950 Plastite screw into the nose covers to secure the "bell" around the top of the LCD TV housing.

When the halves are properly installed there should only be a thin seam visible where the halves meet.

**Step 4.**

Rotate the TV and move the arm thru its range of travel to check for any interference issues.

**PARTS LIST for KIT:**

- (2) PD216-001 End Caps
- (2) PD216-003 Elbow Covers
- (1) PD216-004L Left Nose Cover
- (1) PD216-004R Right Nose Cover
- (1) PDIPPTL61950 Plastite Screw
- (4) PD209-004 Painted Cover Screws

The TV is not shown for installation clarity.

