

PD216-076

PRODEURE FOR CEILING MOUNT ARM

STEP 1:

Assemble supplied spring pins into one of the Arm Cover halves. Pins should be installed into one cover side only.

- 5 pins in nose cover

STEP 2:

Securely hold nose cover and carefully, by hand, push the pin into one of the small holes located in the end of each mounting boss. The pin only needs to go in far enough to stay in place on its own. If using tools, don't press the pin more than halfway into the hole.

Repeat until the pins are installed in all of the bosses in one half of the nose cover pair.

STEP 3:

Place the nose cover half that has the installed pins on the arm in its proper position.

Sandwich the other half of the nose cover around the arm section by aligning the exposed pin ends with the open holes in the second cover half.

When the pins and holes are aligned, carefully squeeze the two halves together.

Then the halves are properly installed, there should only be a thin seam visible where the halves meet.

