

INSTALL FASTENERS AND CAP COVERS

1. Ground the Wall Casting using the PDI-192 Green Grounding Screw.
2. Place a customer supplied fastener thru a PDI-272 Cap Washer.
3. Insert the fastener thru the PDI-178CP Wall Casting and tighten.
4. Repeat for next three mounting holes.
5. Retighten all four mounting fasteners securely.
6. Snap a PDI-271 Plastic cap cover on each Cap Washer.

INSTALL COAX CONNECTION

1. Pull the coax through the wall bracket and install an "F" Connector.
2. Tighten the "F" Connector on the short side of the F-81 Barrel Connector.
3. Slide the PDI-205 Bushing over the F-81 and tighten the nut on the front.
4. Push the assembly back into the wall bracket. Make sure that the PDI-205 is lined up with the set screw, and tighten the set screw in place.

INSTALL ARM AND PILFER SCREW

1. Remove Pilfer Screw from wall bracket before installing arm.
 2. With Arm installed, reinstall Pilfer Screw and tighten. Check rotation of Arm Pin for binding before installing TV.
- NOTE: This feature is designed for use with matching arm basepin and wall bracket only. Misuse can cause failure or binding of basepin.

