

Scope:

To install the PD168-214 X-Box Mount to a PDI-179C-EXT wall bracket.

*This is only compatible with an **X-Box Slim** model.

Parts List:

1. PD181-764 Main Bracket
2. PD181-765 Secondary Bracket
3. PD219-135 #6 Spanner Bit
4. PD218-002 Ty-Wrap
5. PD209-088 6-32 x 1/4 Tamper – Resist Machine Screw Drilled Spanner

Tool List:

1. Safety glasses/goggles
 2. 7/16" Socket wrench
 3. Screwdriver with spanner bit
- *Spanner bit supplied

Safety Steps:

1. Always wear safety glasses/goggles to prevent injury from debris.
2. Follow the installation/removal instructions for existing products.

INSTALLATION PROCEDURE:

***If the 179C power supply is already installed, remove bottom (2) PDIG5HCS2520500 bolts to allow insert of X-Box mount.**

1. Insert PD181-764 Bracket and secure with PDIG5HCS2520500 bolt included with PDI-179C-EXT wall bracket.
2. Place X-Box (Not supplied with bracket) into PD181-764 paying attention to locating pins. (See side view)
3. Paying attention to locating pin, slide PD181-765, secondary bracket, over the X-Box assembly and attach with (4) PD209-084 screws to secure X-Box.
4. Place X-Box brick into mount and secure with ty-wrap. (See bottom view)

