

1. Remove mounting bracket from box and open to "V" shaped support, using care not to get pinched at hinged joint.
2. Locate mounting studs. Important – studs must be on 16 inch centers.
3. Position template to allow sufficient room to install tray/television assembly and mark mounting holes on center of wall studs (16 inch) centers.
4. Drill 4 holes for wall fasteners.
5. Attach mounting bracket to studs with suitable fasteners (not supplied).
6. Remove tray from box and locate Phillips head mounting screws.
7. Align tray to bottom of television and attach using supplied Phillips head screws. Don't over tighten.
8. Carefully lift tray/television assembly and slide mounting hole in tray over pin on mounting bracket, making sure assembly is completely seated before letting go.
9. Install hairpin in cross-hole in mounting pin to secure assembly.

