



1. Remove 7/16" Acorn nut from each stud.
2. Push handle onto studs. Finger grip towards rear.
3. Attach handle with 7/16" Acorn nuts. Tighten with wrench.