

The installation of nose cover clip kit, PD168-015, should be done using the following steps.

1. Lift nose cover to access the front tabs of the nose cover.
2. Position the clip as shown in pictures #1 and #2, with the curved part to the inside of the cover tab.



3. Press clip onto tab as shown in pictures #3 and #4. Make sure that the holes in the clip line up with the holes in the nose cover tab.



4. Repeat process for both sides.
5. Slightly bend each tab inward, approximately 1/32 of an inch, to allow for the added thickness of the two clips.
6. Lift nose cover upward and tilt/lower the cover until the clips are positioned in front of the nose, as shown in picture #5.



7. Next, slide the nose cover rearward until the holes in the nose are aligned with the holes in the clips and nose cover, as shown in picture #6.



8. Install (2) the 8-32 x 1/2 Phillips flat head machine screws thru the nose into the clips and gently tighten.
9. If the arm is equipped with arm covers, install them per the arm cover installation sheet.