

- 1: Find a container that will hold the amount of product you will be working with

- 2: Pour in equal parts by weight of Part A and B

- 3: Mix thoroughly until there is no White or Black streaks remaining and the product is completely Gray in color

- 4: Utilizing a putty knife, scraper or other paddle, apply product evenly over your marker and place in position

Notes:

FirmMarker should push out past the edges of the marker once firmly pressed down to ensure enough product was used for proper adhesion.

The chemical reaction that occurs while mixing will cause product to heat, use caution.

Pot life of this product once mixed is 7 – 10 minutes