



For the best results when painting new galvanized steel pipe with Stove Bright<sup>®</sup>, follow these surface preparation steps:

1. Clean and penetrate commercial sealant typically used over galvanized pipe by washing with 1 part vinegar to 1 part water. Let that dry; then rinse thoroughly with clean warm water. Dry with a clean cloth.
2. Lightly sand the surface with 220 grit sandpaper to create a profile. Wipe the surface with a clean cloth with a small amount of Acetone to lift the debris left by sanding.
3. Apply Paint within 4 hours of the cleaning and sanding process.

After preparing the pipe according to the instructions above, follow the application and heat set steps outline in the Stove Bright<sup>®</sup> User Guide.

Contact FORREST Technical Coatings with questions via phone at: 1-800-537-7201, or by e-mail: [info@forrestpaint.com](mailto:info@forrestpaint.com).