



NOTE: USE TAPERED ROOF INSULATION (EDGE STRIPS) TO CREATE DRAIN SUMP. IF TOTAL INSULATION THICKNESS IS LESS THAN OR EQUAL TO 1 1/2 IN., TAPER 12 IN. FROM THE DRAIN CENTER. IF TOTAL INSULATION THICKNESS IS GREATER THAN 1 1/2 IN., TAPER 18 IN. FROM DRAIN CENTER.



GENERAL REFERENCE:  
"FTR GS 01/21"

APPLICABLE SYSTEMS:  
"FTR MA 01/21"  
"FTR AD 01/21"  
"FTR BA 01/21"

TYPICAL DRAIN FLASHING

| REVISES DETAIL | ISSUE DATE | DRAWING NUMBER |
|----------------|------------|----------------|
| ALL PREVIOUS   | 02-23-21   | FTR-DD1        |