



INSTRUCTION

1. After the PowerMate unit is installed in the vehicle, place the Mat Assembly on the unit Base as shown. Clearance holes are provided in the Mat for the Base mounting bolts.
2. Insert the 3" long self-drilling screws through the Body Washers and into the Mat and Spacer Block.
3. Using an electric hand drill with a 3/8" socket driver, drill and thread the screws through the Mat into the floor of the vehicle.

LV-7 POWERMATE MAT INSTALLATION

POWERMATE® LV-7 MAT INSTALLATION

