



Also known as

- Sand
- Crusher dust
- Gap 7mm
- Sand blinding
- Blinding

QuickSet must be installed on a level surface that is within a +/- 5mm tolerance.

Preferred application is using a laser grader.

Please check the overall foundation height to confirm finished sand height, as this will include any base insulation. E.g. 305mm may change to be 330mm (25mm base insulation) or 355mm (50mm base insulation).

Check that finished sand height has taken into account the true overall foundation height which will include any base insulation. Ensure site cut is within a 50mm tolerance and compacted if hard fill is used.

Spread fines out with the use of a machine (or wheel barrow) to small even piles on the building footprint.

Using a large concrete rake and a laser level with a staff spread sand out to an even layer to a +/- tolerance of 5mm. Checking every 1/2 m² that the height has been achieved.

Fines should range from 20mm to a max of 50mm layer and should be loose pack only (do not compact). 500mm to 1000mm past the building line should also be sanded to the same +/- 5mm tolerance.

