



How to Make Ringtone for Yealink SIP-T2XP


How to Make Ringtone for Yealink SIP-T2XP Phones

1. You could install the tool of **Cooledit** to make the ringtone you like.


[Note]:

- a. The ringtone which you update must less than 100k in total;
- b. The parameter of ringtone is "Sample Rate: 8000 & Channels: Mono & Resolution: 16-bit";
- c. The ringtone format is "A/mu-Law Wave(*.wav)"


2. Open the ring file by Cooledit.




3. After choosing the ring, then press  key to listen to the ring.



4. Select the segment of ringtone you chosen and copy it to the new created file.
4a: select the segment of ringtone(**Ctrl + C**)




4b: Creat a new file via File→New.




4c: Paste it to the new created file(**Ctrl + V**).

[Note]: The ringtone format as picture:



5. Save the ringtone via **File→Save As..**
Note: please choose the save type as "A/mu-Law Wave(*.wav)".




6. Open your phone's **webpage**→**Phone**→**Preference**.
Note: the ringtone must be less than 100k in total.


A screenshot of the Yealink SIP-T2XP Phone Preference page. The page has a green header with the Yealink logo and a navigation bar with tabs: Status, Account, Network, Phone, Contacts, Upgrade, and Security. The 'Phone' tab is selected, and the 'Preference' sub-tab is active. The page contains various settings for the phone, including Language, Time Zone, NTP Server, Update Interval, Daylight Saving Time, Start/End Time, Manual Time, Inter Digit Time, Flash Hook Time, Backlight Brightness, Backlight Time, LCD Contrast, Keyboard Lock, Ring Type, and Upload Ringtone. The 'Ring Type' is set to 'Ring1.wav'. The 'Upload Ringtone' section has a text input field and a '浏览...' (Browse...) button. There are 'Upload', 'Cancel', 'Confirm', and 'Cancel' buttons at the bottom. A 'NOTE' section on the right provides instructions for Time Zone, NTP Server, Update Interval, Daylight Saving Time, Manual Time, and Ring Tone.

7. Choose the ringtone you saved.

A screenshot of the Yealink SIP-T2XP Phone Preference page, focusing on the 'Ring Type' and 'Upload Ringtone' sections. The 'Ring Type' is set to 'Ring1.wav'. The 'Upload Ringtone' section has a text input field containing 'd:\111.mp3' and a '浏览...' (Browse...) button. There are 'Upload' and 'Cancel' buttons below the input field. The 'NOTE' section on the right is partially visible, showing instructions for Ring Tone.



8. Choose the ringtone 121.wav as the default ringtone of incoming calls.



9. Press **confirm** to complete the settings.

