

Pre-Programmed Graphics and Animations**Graphics available**

Use the **MODE** and **SELECT** keys to select one of the following:

- “Welcome” — [SPC]8
- “Sale” — [SPC]9
- “News Flash” — [SPC]A
- “Happy 4th” — [SPC]B
- “Open” — [SPC]D
- “Closed” — [SPC]E
- “Thank You” — [SPC]S
- “No Smoking” — [SPC]U
- “Smile” — [SPC]Z

Animations available

Use the **MODE** and **SELECT** keys to select one of the following:

- American Flag animation — [SPC]T
- Don’t Drink and Drive animation — [SPC]V
- Fish animation — [SPC]W
- Fireworks animation — [SPC]X
- Christmas animation — [SPC]Y

Pre-Programmed Graphics and Animations**Graphics available**

Use the **MODE** and **SELECT** keys to select one of the following:

- “Welcome” — [SPC]8
- “Sale” — [SPC]9
- “News Flash” — [SPC]A
- “Happy 4th” — [SPC]B
- “Open” — [SPC]D
- “Closed” — [SPC]E
- “Thank You” — [SPC]S
- “No Smoking” — [SPC]U
- “Smile” — [SPC]Z

Animations available

Use the **MODE** and **SELECT** keys to select one of the following:

- American Flag animation — [SPC]T
- Don’t Drink and Drive animation — [SPC]V
- Fish animation — [SPC]W
- Fireworks animation — [SPC]X
- Christmas animation — [SPC]Y