

INTELLIGENT CHARGING SYSTEM USER GUIDE

Charging and managing multiple notebooks has never been this easy. This powerful, yet easy to use charging system gives teachers and IT coordinators full control of their cart. No more tripping of circuit breakers, multiple power cords for one cart, or uncharged devices. Best of all, it even improves the battery life of the devices!



Charge Button

When the "power on" icon is illuminated, press the "charge" button once to begin charging. Charging will automatically stop when all devices are completely charged. To start charging again, press the charge button once to clear the LED screen and press it a second time to be charging. You can also stop charging at any time during the charging process by pressing the "charge" button a second time.



Manage Mode

Pressing "manage" button once prepares the cart for remote management. The system will first evaluate and if necessary, charge the devices. Once that is complete, the network switch will be turned on. The button will light up when the cart is ready to begin remote management. Press the button a second time to stop manage mode.



Auxiliary Power

Controls power to any peripherals that are plugged into the AUX power strip in the back of the cart. The button will not work during charging. If the AUX devices must be operational during charging then the button must be pushed prior to beginning the charging process. Be aware that this may lengthen charge time.

1 2 3 4

Charging Quadrants

Indicates which section of the cart is active. The charging unit controls this automatically, ensuring that all devices inside are charged in the quickest, most efficient way possible. When all four lights are flashing green charging is complete.



Power On Icon

Indicates when the cart is connected to power and is ready.



RESET

Reset Button

JAR carts with the Intelligent Charging System are protected with their own circuit breaker. If the cart encounters misuse such as plugging in unsupported devices, the circuit will trip and the reset button will pop out. To reset the cart simply press it back in. Please first consult the manual and ensure that everything is plugged in properly and that only supported devices are connected before resetting.

