# Setup Instructions for Winegard CarryOut GM1518 Satellite Antenna<sup>††</sup> & DISH Receiver

Setup | Installation | Receiver Activation Software Version L551RGND-N

### Setup of Winegard CarryOut GM1518 Satellite Antenna<sup>††</sup> & DISH Receiver

#### Setup | Installation | Receiver Activation

Software Version L551RGND-N

## INSTRUCTIONS ESTIMATED SETUP TIME

Position the Winegard CarryOut satellite antenna and connect the cabling between the satellite antenna and receiver. **IMPORTANT: Ensure that your satellite antenna is connected to a power source, if applicable.** 

STEP #2

**STEP #1** 

Power up TV / ViP<sup>®</sup>211k Receiver / Winegard CarryOut satellite antenna.

#### STEP #3

Select 'Menu' from your remote. From the Main Menu page, select '611' on your remote control number pad.



**STEP #4** 

Select 'Check Switch' with your DISH remote.

dish	Point	Dish			
	Enter y	To calcula our ZIP Co	te Dish 500 P de and select	eak Angles, satellite 110 or 11	9
Zip Code	Dish Syster	m Transpo	nder Satellite		lodulator
55901				Ch	ock Switch
				C	Help
	Azimu	ith: 208	Elevation: 3	4 Skew: 111	
0	10 25	5 !	50 75	5 100	125
N	ot Locked ·	- Name Not	t Acquired!	Signal Streng	th: 0

#### **Step #5**

**20** MINUTES

#### Select 'Test' with your DISH remote.

dish Installation Summary	Tue, May 22	Installation Summary	Tue, May 22
Port: Satellite Input Satellite: X Trans: X Device: Status: Reception Verified Switch: None SuperDISH Alternate Details Test Done	Неір	Attention   Please wait while your switch installation   Currently doing test # 5 c   I supervise   I supervise   I supervise   Details	of 38

++ Also applicable for most automatic roof-mounted satellite antennas. Differences may apply.

#### STEP #6

#### Select 'Done' using your DISH remote.

		To c Enter your Z	alculate Dish	500 Peak a	Angles, Illite 110 or 11	9
Satellite Input	Zip Cod		Atte	ntion	3	78) or
Satellite: 119						lite
Trans: OK	5590					
Device:		Now scanning for available satellites				
Status: Reception Verified		Please wait.				
Switch: None	and the second second					
SuperDISH Alternate	0	10 25	50	75	100	125

NOTE: If you see an X in the place of the satellite information (110, 119, 129) at this step, reposition your satellite antenna and then select 'Test.'

#### **STEP #7**

Select 'Done' on your DISH remote, and then 'Cancel.' Do this three (3) times.



535 Popup: Acquiring Signal



STEP #9

Installation Wizard: Connect Receiver to Ethernet or Phone – Select 'Continue'



**NOTE:** Connecting Ethernet or Phone is not required; it will automatically sequence through if you choose not to connect.

STEP #10	10 MINUTES

Installation Wizard: Activate Receiver



First-Time Activation of DISH ViP®211k Receiver

To activate, call the applicable number listed below.

- New DISH Customers: 1.800.970.9623
- Existing DISH Customers: 1.888.854.9535