



208 S Spresser St PO Box 376
Taylorville, IL 62568
800-7DOMINO 800-736-6466
217-824-9441(T) 217-824- 3349(F)
email: info@dominoengineering.com

Garage Door Keypad Installation/Instructions

Installation:

1. **Outside:** Choose a convenient location to mount the keypad. Drill a ½” (or larger) hole from outside to inside the garage. Carefully, feed cable from keypad to inside of garage. Screw keypad to outside surface with 2 screws (included). **DO NOT OVERTIGHTEN.** The keypad is meant to “stand off” the surface so moisture can run behind the unit.
2. **Inside:**
 - a. Disconnect power to garage door opener.
 - b. Connect control box to push button terminals on opener with two low voltage (18-24 gauge) wires.
[OPTIONAL: If there is a nearby wall push button already wired to your garage opener, you can connect the control box to the terminals of this wall push button.]
 - b. Strip ¼” insulation from connecting wires, insert and screw wires into the two terminals marked “OPENER” in control box. There is no polarity on the connecting wires. Either wire in either terminal is ok.
 - c. Insert 3 “AA” alkaline batteries (included), observing polarity.
 - d. Snap keypad cable plug, with locking tab on bottom, into receptacle marked “KEYPAD” in control box.
 - e. Mount control box to wall with styrofoam over batteries. Styrofoam keeps batteries from vibrating out of position.
 - f. Reconnect power to garage door opener.

How to Code Keypad:

- Step 1. Slide switch to “program” or “on” – (switch is located on control box)
- Step 2. Press “ENTER”
- Step 3. Press your **code numbers** (you can use up to six digit in your code)
- Step 4. Press “ENTER”
- Step 5. Slide switch to “operate” or “off”

How to use Keypad: Press your code numbers and press “ENTER”

How to Erase old code: Simply set new code. The new code replaces old code.

For Other Questions, go to Frequency Asked Questions (FAQs).