

Thank you for choosing
mylifemyshop
in the spirit of welcoming you
we would like to offer ...

**50%
OFF**

Your next purchase!

Just enter this exclusive code

CHEF50

at checkout when you visit MyLifeMyShop.com

Safety & Warnings

To avoid damage to the Chef's Circle do not exceed the maximum weight capacity of 15 pounds. This scale is a precision measurement instrument store it in a safe, dry place and use it with caution and care to maintain and extend its life. Remove the battery if the scale is not to be used for an extended period of time. This product is not suitable for use by children. Do not operate with wet hands. This scale is made for domestic use only and may weigh only domestic quantities of food.



ONE-YEAR WARRANTY

This My Life My Shop product is warranted to be free of manufacturer's defects in materials or workmanship for one year from the date of purchase. Damage or wear resulting from an accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair are not covered under this warranty.

Should this product require warranty service (or replacement at our discretion) please contact client service to obtain a Return Merchandise Authorization number (RMA) and return instructions, proof of purchase is required. Products returned without a My Life My Shop generated RMA number will not be accepted and the sender will not receive a refund, replacement, or repaired product.

mylifemyshop.com

info@mylifemyshop.com

1.888.870.2132

There are no express warranties except as listed above. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

PLEASE DO NOT RETURN THIS PRODUCT TO THE RETAILER. CONTACT US DIRECTLY FOR WARRANTY SERVICE OR REPAIR. THANK YOU.

Chef's Circle
DIGITAL KITCHEN SCALE

Instruction Manual

mylifemyshop

Getting Started

Checking the Battery

Before using your **Chef's Circle** Digital Kitchen Scale you need to remove the battery insulation tab. This is a clear plastic tab inside the battery compartment on the bottom of the scale that keeps your scale from activating before it is opened.

Selecting Your Measurement Unit

To select your measurement unit first turn the **Chef's Circle** on by pressing the "On|Tare" button. Then press the "Unit" to cycle through your options. These options appear on the far right of the screen: grams, pounds, ounces and kilograms. When you have reached your selection, stop pressing the unit button.

The measurement unit has now been changed and the **Chef's Circle** will display measurements in this unit until you make a change.

While taking a measurement you can also press the "Unit" button to cycle through the measurement units and convert your reading.

Using Your Chef's Circle

Set the Chef's Circle to Zero

To set your **Chef's Circle** to zero, simply place it onto a hard flat surface and turn it on. The **Chef's Circle** will automatically balance itself. This process works the same way if you would like to zero out the weight of a bowl or other container. Place the bowl or plate on the scale then press the "On|Tare" button and it will automatically zero out the weight of the container.

Cleaning & Maintenance

Clean the **Chef's Circle** with a soft damp cloth and light dish soap. Do not submerge it in water, or use chemicals or abrasives to clean it.

As any good chef knows, the **Chef's Circle** should be cleaned after each measurement to ensure that you are not cross contaminating your ingredients. Be careful when measuring citrus and other acids that you do not get them on the underside of the scale.

Do not put the Chef's Circle in the dishwasher.

Taking a Measurement

Taking a Measurement

- To take a measurement place the Chef's Circle on a hard flat surface.
- Make certain that there is no weight pressing down on it, other than an item you have placed on it intentionally.
- Press the "On|Tare" button to activate and zero the scale.
- Place the item(s) you want to weigh on the scale's surface. Their weight will display in your selected unit of measure on the LCD screen.
- You may continue to weigh items one after the other, though you should verify that the Chef's Circle resets to zero after each item, and you should clean it prior to each item touching the surface of the scale.
- When finished you may either press the "On|Tare" button for 3 seconds to shut the scale off or let it shut itself off automatically.