ONE-YEAR WARRANTY

This Vanity Planet product is warranted to be free of manufacturer's defect in materials or workmanship for one year from the date of purchase. Damag or wear resulting from an accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair are not covered under this warrante

Should this product require warranty service (or replacement at our discretion) please contact client service to obtain a Return Merchandise Authorization number (RMA) and return instructions; proof of purchase is required. Products returned without a Vanity Planet generated RMA number will not be accepted and the sender will not receive a refund, replacement, or repaired product.

VANITYPLANET.COM INFO@VANITYPLANET.COM

There are no express warranties except as listed above. This warrant ives you specific legal rights and you may have other rights which va

Please do not return this product to the retailer.

SUBSCRIBE & SAVE PROGRAM

REPLACEMENT HEAD PROGRAM

To keep your Vanity Planet PureSpin spinning in top condition, dermatologists recommend replacing your brush head every two to three months. Our Subscribe & Save program will ensure that you receive the optimal cleansing and exfoliating results without a second thought.

New brushes are available at vanityplanet.com

Subscribe to our convenient refill program and save 25% on every refill order.

V

PURESPIN

cleansing & massaging electric facebrush

#VPBEAUTY | VANITYPLANET.COM

HEY THERE GOOD LOOKIN'

In this box, you'll find a top notch product waiting patiently for your attention. Let's be honest, you know an awesome buy when you see one, so thanks for choosing our goods to add to your stellar beauty routine.

The way we see it, we're here to help you enhance your already stunning looks. Why? Because we think confidence looks best on everyone.

XOXO VANITY PLANET

DON'T FORGET TO SHOW OFF YOUR GOODS BY USING THE #MYVP AND #VPBEAUTY HASHTAGS.

YOUR PURESPIL

The Vanity Planet PureSpin will leave your face feeling refreshed in no time. Ultra-soft bristles on the uniquely designed Cleansing Brush gently massage and cleanse the delicate skin on your face, while the advanced 360° rotary motion removes dirt, oil, and dead skin to reveal your skin's natural glow. Created with you in mind, the PureSpin is water resistant and equipped with a rubber-coated handle, so it's easy to hold at the sink or in the shower. The PureSpin has two speed settings and a LED Mode Indicated light. Choose between low speed for gentle cleansing, and a high speed for deep cleansing to enjoy the cleansing treatment that is right for you.

Designed for use by men and women, this powerful cleansing system is far more effective than simply using your hands to wash your face. This essentia tool will quickly become part of your daily skin care routine. In addition to the benefits of cleaning, the device's rotational scrubbing perfectly primes your skin's surface to absorb moisturizers and other facial care products. With regular use, it can help reduce the appearance of blemishes, blackheads, and breakouts. The PureSpin is powerful, yet gentle, giving your skin a clean and radiant look.

USING YOUR PURESPIN

- · Attach the Cleansing Brush to the body of the PureSpin.
- · Wet your face and the brush head with water.
- Apply facial cleanser to your skin or directly to the brush head.
- Push the on/off button to turn on the device. Press once for the lower speed or press twice for the higher speed.
- Gently move the brush head in small circular motions around the areas of your face that you are cleansing.
- Push the on/off button again when finished to turn off the PureSpin.

NOTE: Keep the brush head flush to your skin. Pressing too hard will impede the motion of the brush and reduce its effectiveness.



CLEANSING BRUSH

The Cleansing Brush is made of ultra-soft bristles that are specially designed for your tender and sensitive facial skin. For best results, always dampen your face and the brush prior to use.

CARING FOR YOUR PURESPIN

To keep your PureSpin in optimum condition, do not use abrasive cleaners or chemicals to clean any part of the unit. The handle is sealed and fully waterproof. However, you should never fully submerge any part of the Vanity Planet PureSpin under water.

CLEANING THE HANDLE:

- To remove any residue or buildup, clean the handle at least once a week by removing the brush head and washing the device thoroughly with soapy water.
- · Never attempt to open the brush handle for any reason.

CLEANING THE BRUSH HEADS:

- · Rinse brush heads thoroughly after every use.
- Dermatologists recommend replacing brush heads every three months with regular use.

INSERTING THE BATTERIES

For maximum run time, we recommend using alkaline batteries. Use one hand to hold the device and the other hand to hold the battery cover. Gently pull off the cover. Insert 2 AA batteries in alignment with the polarity symbols (+ / -) indicated on the unit. Then replace the battery cover and you're ready to cleanse.

IMPORTANT SAFEGUARDS & WARNINGS

If you are under a doctor's care for any skin condition or if you think you may have a skin condition, please consult your physician before using the Vanity Planet PureSpin. To ensure that you experience the full range of benefits from the Vanity Planet PureSpin we recommend the following:

- · Do not share brush heads with anyone.
- · Use with a gentle daily cleanser designed for the face.
- Do not use jagged exfoliating particles, such as shells, with the PureSpin.
- If you would like to use with an exfoliating product, use one that contains soft, rounded particles.
- Using your Vanity Planet PureSpin to remove makeup may stain the bristles of the brush head; if discoloration occurs, clean the brush head with soap and water.
- Change your brush heads every three months.