



FURNITURE USE AND CARE GUIDE

MAKING ADJUSTMENTS

Your Valet furniture is fully adjustable to fit your changing needs. Below are instructions for adjusting various components in your system. It is **important that you follow these instructions** to ensure the long-term integrity of your furniture.

Shelves:

Your shelves are fully **adjustable**, and can easily be moved. To adjust shelves in cabinets behind doors simply remove the 4 support pins and replace them at the desired height. A pair of pliers may be helpful in removing and replacing the support pins. To move adjustable shelves in open bookcases, slide out the shelf and then remove the support rails and replace them at the desired height.

Hinges:

Please see attached diagram for hinge adjustment instructions.

CLEANING

Wood:

Wiping with a clean dry cloth is best for normal maintenance. For heavy cleaning, standard wood furniture cleaning product can be used successfully without damaging your finish. Do not use solvents such as lacquer thinner or mineral spirits on wood. Immediately wipe off and dry any other liquids such as water or coffee that may come into contact with your wood finish.

Melamine:

A damp cloth with a general house hold cleaner such as 409 or glass cleaner will remove most spots. If you should get a tough spot (grease, glue, etc.) a small amount of nail polish remover, lacquer thinner or mineral spirits on a clean cloth should remove the stain. You should follow all instructions and safety precautions as listed on the container when using strong chemicals such as lacquer thinner or mineral spirits. Avoid using any abrasive cleaner.

High Pressure Laminate:

Many of our counter tops are made with high pressure laminate. The same cleaning instructions indicated for Melamine above will work on high pressure laminate surfaces.




WARRANTY

Limited Lifetime Warranty – Valet warrants to the original purchaser that the goods manufactured and installed by Valet shall be free, under normal use and service, from defects in material or workmanship for as long as you own your home. The warranty does not cover ordinary wear and tear, misuse, repairs, or modifications by unauthorized personnel, of the product. Any claims must be presented to Valet in writing, and Valet shall have a reasonable length of time to validate and remedy such defect by repair and/or replacement in accordance with this warranty.


(Full warranty listed at www.valetcustom.com – Products – Warranty)

Concealed Hinges


Duomatic - Salice




Adjustments



Horizontal
by screw adjustment
(5 mm of adjustment)



In-and-Out
by loosening the
hinge-arm mounting screw
or via cam adjustment
(3.3 mm of adjustment)



Vertical
via slots in the mounting
plate or cam adjustment
(4 mm of adjustment)

