ansul:

System Components

UL EX-4510 4-1-05 Page 1-8 REV. 1

Flexible Discharge Hose

The flexible discharge hose is used to connect the tank valve outlet to rigid distribution piping. On single tank systems, a check valve is not required. Three sizes of flexible discharge hoses are available: 1 in. (for 20, 50, and 90 lb. tank sizes), 2 in. (for 140, 280, 390, and 450 lb. tank sizes), and 3 in. (for 850 lb. tank sizes).


The 1 in. flexible hose or the adaptor, Part No. 570557, can be used to connect the valve outlet to rigid pipe.

The 2 in. flexible hose or the adaptor, Part No. 570558, can be used to connect the valve outlet to rigid pipe.

When using a 3 in. flexible discharge hose (without a manifold), three single tank swivel adaptors are available for connection from the valve outlet to the flexible discharge hose.

| Component | Material | Approvals |
|--|--|--|
| 1, 2, 3 in. Flexible Discharge Hose | Stainless Steel Tubing with Stainless Steel Braid Cover | UL Listed ULC Listed FM Approved |

| Shipping Assembly Part No. | Description |
|----------------------------------|---|
| 570539 | 1 in. Flexible Discharge Hose |
| 570538 | 2 in. Flexible Discharge Hose |
| 69990 | 3 in. Flexible Discharge Hose |
| 570557 | 1 in. Single Tank Swivel Adaptor |
| 570558 | 2 in. Single Tank Swivel Adaptor |
| 69470 | 3 in. Flared to 3 in. NPT Single Tank Swivel Adaptor |
| 69471 | 3 in. Flared to 3 in. Grooved Single Tank Swivel Adaptor |
| 570363 | 3 in. Flared to 3 in. BSPT Single Tank Swivel Adaptor |



3 IN. FLEXIBLE DISCHARGE HOSE

ANSUL and SAPPHIRE are trademarks of Ansul Incorporated or its affiliates.

Litho in U.S.A.