


1. Determine how many gallons of Holganix is needed for your fill.
2. Open Yellow Fill Valve to "FILL" position.
3. Reset GPI Meter by holding button down while on "TOTAL 1" setting until you "zero out" the meter(Figure A) .
4. Hold Momentary Switch(Figure B) on until desired gallons is reached on meter.
5. Turn yellow valve to "OFF" position - IMPORTANT!!!
6. See Inductor Bowl Instructions.



**YELLOW  
FILL VALVE**

**GPI METER**  
Figure A



**MOMENTARY  
SWITCH**  
Figure B

Any questions or concerns, please call Holganix at 866-563-2784 or email [SUPPORT@holganix.com](mailto:SUPPORT@holganix.com)