


Auto Reset Assembly



MULTI-PLOUGH ASSEMBLIES

Auto Reset Assembly

NO	PART NUMBER	DESCRIPTION
1	400411	Auto Reset Spring
2	400412	Overload Spring
3	400413	Spring Pins
4	400414	Spring Pin Split Pins
5	400435	Front Spring Anchor
6	400420	Rear Spring Anchor
7	400409	Bolt Set Screw
8	400410	Bolt Beam Pivot
9	400401	Beam Auto Reset
	400402	Beam High Clearance
10	400415	Octagonal Spacer
11	400404	Multi-Plough Furrow Assembly
12	103500	Mounted D/Bar Clevis Cat 2 - 4"
	103470	Semi Mounted D/Bar Cat 2 - 3"
	103475	Semi Mounted D/Bar Cat 2 - 4"
	103480	Semi Mounted D/Bar Cat 3 - 4"
	103485	Semi Mounted D/Bar Clevis Cat 2 - 4" (Not Shown)