

Meter Reading Directions

Taskalfa/Ecosys Models

Press the System Menu/Counter
Select Reports
Select Print Reports
Select Status Page
Select Yes/OK to print

Lexmark Models

Select Menu (Bottom right hand corner of touch screen)
Select Reports
Select Device Statistics

Muratec Models

Press the Utility/Counter key
Press User Settings
Press Print Settings
Press Print Reports
Press Statistics Page
Print, OK

Oki Models

Press the Counter button
Press Print out Total Counter
The status page will then print out

Sharp Models

Select - Setting
Select - System Setting
Print – OK