

Patient Cheat Sheet



Welcome to the medTAB Touchscreen Entertainment Experience!

Power button. TV-Games—Relaxation are built-in and do not need internet. The Internet-News-Social icons do access the Internet.



- Touch the green TV icon to watch TV
- Touch the TV screen for a touchcreen TV remote
- CH touch arrows up/down to change channel
- VOL touch +/- or use slider: Right+ or Left-
- CC touch for Closed Captions
- FAV touch to store up to 4 favorite TV channels
- SOURCE touch to change input sources
- INFO touch to see current channel info
- CH ENTRY touch for direct numeric CH keypad
- Use HOME button to exit



Internet

- Touch the blue Internet icon
- Opens a web browser
- Touch inside the search bar and a keyboard pops-up
- Type in search terms to visit the web
- Swipe up or down to scroll
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Games

- · Touch the red Games icon
- Touch to select a game
- Follow on-screen prompts or instructions
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Relax

- Touch the blue Relax icon
- Select a relaxation scene
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Touch the gray News icon

- Select an online news source
- Swipe up or down to scroll news

patient experience on-dema

- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Social

- Touch the yellow Social icon
- Select an online social app
- Login if necessary
- Swipe up or down to scroll feed
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit
- Clear Data if desired



- Press HOME anytime to return to Main Menu
- A floating icon you can move around the screen



- Press to erase personal internet data on-demand
- Cache data is automatically erased when TV powers off

Alternate Controls



- Left Arrow takes you back one screen
- Circle takes you back home to Main Menu
- Square shows all open Apps



Resident Cheat Sheet



Welcome to the medTAB Touchscreen Entertainment Experience!

Power button. TV-Games—Relaxation are built-in and do not need internet. The Internet-News-Social icons do access the Internet.



- Touch the green TV icon to watch TV
- Touch the TV screen for a touchcreen TV remote
- CH touch arrows up/down to change channel
- VOL touch +/- or use slider: Right+ or Left-
- CC touch for Closed Captions
- FAV touch to store up to 4 favorite TV channels
- SOURCE touch to change input sources
- INFO touch to see current channel info
- CH ENTRY touch for direct numeric CH keypad
- Use HOME button to exit



Internet

- Touch the blue Internet icon
- Opens a web browser
- Touch inside the search bar and a keyboard pops-up
- Type in search terms to visit the web
- Swipe up or down to scroll
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Games

- Touch the red Games icon
- Touch to select a game
- Follow on-screen prompts or instructions
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Relax

- Touch the blue Relax icon
- Select a relaxation scene
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



- · Touch the gray News icon
- Select an online news source
- Swipe up or down to scroll news

patient experience on-dema

- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit



Social

- Touch the yellow Social icon
- Select an online social app
- Login if necessary
- Swipe up or down to scroll feed
- Adjust volume using cabinet buttons or touchscreen slider
- Use HOME button to exit
- Clear Data if desired



- Press HOME anytime to return to Main Menu
- A floating icon you can move around the screen



- Press to erase personal internet data on-demand
- Cache data is automatically erased when TV powers off

Alternate Controls



- Left Arrow takes you back one screen
- Circle takes you back home to Main Menu
- Square shows all open Apps