 PDi Communication Systems, Inc. Better Solutions Are Within Reach®	MODEL NUMBER: PD251-002	Document Number: PD196-132R2
	Internal DVD Quick Start Guide	Page 1 of 5

Thank you for your purchase of the PD251-002 internal DVD player. Please read and carefully follow the directions in this Quick Start Guide. If you should have any questions please contact PDi technical support at 1-937-550-2852.



IMPORTANT: REMOVE AC POWER FROM TELEVISION BEFORE INSTALLING THE PD251-002 INTERNAL DVD PLAYER OR DAMAGE TO THE DVD PLAYER OR TV MAY RESULT!

Step 1: Remove the DVD player from the shipping box. The box will contain:

- 1- DVD module
- 1 – DVD-to-Television port cable
- 1 – set screw

Step 2: The PD251-002 may be mounted in one of three different orientations:

- Top Mount
- Side Mount
- Bottom Mount

Determine which orientation best suits your application needs.

Step 3: Remove the Power Input Cover Plate from the back of the TV.



Press tabs in to remove cover panel. When pressed in the lock will release and the cover panel will be able to swing out from the TV until the locking tabs disengage.

Step 4: Make sure that the power cable is not plugged into the TV receptacle!





Step 5: Remove the DVD access panel located on left side as you are facing the back of the Television.



Press tabs in to remove the DVD access panel. When pressed in the lock will release and the access panel will be able to swing out from the TV until the locking tabs disengage.

Step 6: Remove the module cover plate from the DVD access panel.



Remove these two screws

Step 7: First attach the DVD cable to the port on the TV (make sure to do this first before attaching to the DVD player). There are two ports on the TV. Connect the cable to the port that best fits the DVD player orientation as shown below. Ensure that the connections are tight by screwing the thumb screws into the jacks on the port.

- For Top Mounting connect the cable to the bottom port.
- For Side Mounting connect the cable to the top port.
- For Bottom Mounting connect the cable to the top port.



top mount



side & bottom mount

Step 9: Attach the DVD cable to the DVD player. Ensure a tight connection by tightening the thumb screws on the cable to the DVD player jack.



Step 10: Install the DVD player into the Television cabinet in one of the three desired orientations.



top mount



side mount



bottom mount

Step 11: Once mounted install the set screw to hold the DVD player to the TV chassis.



Set screw installs here

Step 12: Re-Install the DVD side access panel and ensure the DVD player is flush with the side panel.



Step 13: Plug the AC power cord in the the AC receptacle and re-install the Power Input Cover Plate.

Step 14: The DVD player will automatically be recognized by the TV control system upon applying power to the TV. Use the PD108-427 remote to control functions of the DVD player.



***** THIS COMPLETES THE PD251-002 QUICK START INSTALLATION GUIDE**