PDi	MODEL NUMBER: PD181-660	Document Number: PD196-177R3
Communication Systems, Inc Your Source for Healthcare and Wellness Infotainment™	Bolt Down TV Table Stand	Page 1 of 3

SCOPE:

TO ATTACH A 42ELED TV TO A PD181-660 TABLE STAND USING A PDI BRACKET KIT (PURCHASED SEPARATELY)

SAFETY STEPS:

- 1. ALWAYS WEAR SAFETY GLASSES/GOGGLES TO PREVENT INJURY FROM DEBRIS.
- 2. FOLLOW THE INSTALLATION/REMOVAL INSTRUCTIONS FOR YOUR EXISTING PRODUCTS.

TOOLS:


- 1. P1 OR P2 PHILLIPS SCREWDRIVER
- 2. 1/4" HEX BIT DRIVER
- 3. SAFETY GLASSES/GOGGLES


PROCEDURE:


- 1. SECURELY MOUNT PD181-620 STAND (#1) TO TABLE SURFACE USING 1/4" FASTENERS (CUSTOMER SUPPLIED).
- 2. ATTACH THE VERTICAL WALL MOUNT BRACKET FROM CHOSEN MOUNT KIT (#7) TO THE PD181-620 STAND (#1) USING THE PD181-619 NUT PLATE (#2), AND PDIBSHCS252050 BUTTON SOCKET HEAD CAP SCREWS (#3). THIS MOUNT HAS AN ADJUSTABLE MOUNTING HEIGHT FEATURE. DETERMINE THE PROPER MOUNTING HEIGHT AND SECURELY TIGHTEN THE TWO 1/4 -20 X 1/2 BUTTON SOCKET HEAD CAP SCREWS.
- 3. NEXT, MOUNT THE E42 TV (#8) USING PARTS SUPPLIED WITH CHOSEN MOUNTING KIT.
- 4. FINALLY, ATTACH PD181-618-S (#4) TO PD181-620 (#1) USING SIX PDIPPHMS103250 SCREWS (#5), THEN BOLT THE LEG TO THE TABLE USING 1/4"FASTENERS (CUSTOMER SUPPLIED).

PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
1	PD181-620	STAND	1
2	PD181-619	NUT PLATE	1
3	PDIBSHCS 2520 50	1/4 – 20 X 1/2 BUTTON SOCKET HEAD CAP SCREW	2
4	PD181-618-S	STIFFENER: FOR LARGE SCREEN TABLE MOUNT	1
5	PDIPPHMS103250	PHILLIPS PAN HEAD MACHINE SCREW 10-32 X ½	6









PDi	MODEL NUMBER: PD181-660	Document Number: PD196-177R3
Communication Systems, Inc Your Source for Healthcare and Wellness Infotainment™	Bolt Down TV Table Stand	Page 2 of 3

MOUNTING INSTRUCTIONS FOR LCD TABLE MOUNT WITH PAN OPTION:


- 1. SECURELY MOUNT PD181-620 STAND TO TABLE SURFACE USING THREE 1/4" FASTENERS (CUSTOMER SUPPLIED).
- 2. ATTACH PD168-004 (PAN OPTION KIT, PURCHASED SEPARATELY) TO PD181-620 USING THE (2) 1/4 -20 X 1/2 BUTTON SOCKET HEAD CAP SCREWS AND TWO 1/4" FLAT WASHERS AS PICTURED IN DETAILS "D" AND "E".
- 3. ATTACH VERTICAL WALL MOUNT BRACKET FROM PURCHASED MOUNTING KIT TO PD168-004 USING THE HARDWARE PROVIDED IN THE PAN OPTION KIT.
- 4. DETERMINE THE PROPER MOUNTING HEIGHT AND SECURELY TIGHTEN THE TWO 1/4 -20 X 1/2 BUTTON SOCKET HEAD CAP SCREWS.
- 5. NEXT, MOUNT THE E42 TV (#8) ACCORDING TO INSTRUCTIONS INCLUDED IN THE PURCHASED MOUNTING KIT.
- 6. FINALLY, ATTACH PD181-618-S (#4) TO PD181-620 STAND USING (6) PDIPPHMS103250 (10-32 X .5") SCREWS, THEN BOLT THE LEG TO THE TABLE USING 1/4" FASTENER (CUSTOMER SUPPLIED).




PD168-004 ASSEMBLY **DETAIL D**



DETAIL E







A, B, C VALUES

ELED TV	Α	В	С
42	20.7	23.2 to 25.0	0.2 to 2.0

