


# PDI-DVD-SH Healthcare Grade DVD Player

## DVD Control & Menu Navigation

### Instruction Supplement

Document Number: PD196-178R1.DOC

The PD108-432 handheld remote is normally used to control the DVD player. Additionally, the front keypad of the player also provides basic control.



The front control buttons serve dual purposes: the first is control of the disc during normal movie Playback, and the second when the DVD Disk Menu is active.

<b>FUNCTION</b>	<b>PLAYBACK MODE</b>	<b>DISC MENU / NAVIGATION MODE</b>
PLAY	Starts playback /pause	Confirms a menu selection (Enter Key Function)
PAUSE	Activates Root menu	Activates Root menu
FR	Fast Rewind	Moves cursor down the menu item list
FF	Fast Forward	Moves cursor right
EJECT	Eject Disc	Eject Disc
POWER	Turns Player On or Off	Turns Player On or Off

For additional assistance please contact PDI Communication Systems.

PDI Communication Systems, Inc.

40 Greenwood Lane

Springboro, Ohio 45066 USA

PH: 800-628-9870 FX: 937-743-5664 Web: <http://www.pdiarm.com>