

	MODEL NUMBER: <b>PD133-711 24" ELED TV Table Stand</b>	Document Number: <b>PD196-282R1</b>
	<b>Installation Instructions</b>	

**SCOPE:**

To install a PD133-711 table stand to a 24" ELED TV.

**PARTS LIST:**

1. PD133-711 table stand
2. (2) M4x10mm Phillips Cheese head machine screws

**TOOL LIST:**

1. Safety glasses/goggles
2. Drill and bit for screw.

**SAFETY STEPS:**

1. Always wear safety glasses/goggles to prevent injury from debris.
2. Follow the installation/removal instructions for your existing products.
3. Only place TV on stable flat surface when using the stand.

**PROCEDURE**

1. Remove table stand and screws from box and protective cover.
2. Lay TV face down on flat, stable surface



3. Place stem of stand into bottom of TV and using drill, secure with 2 supplied screws as shown.

