

	MODEL NUMBER: PD133-712, PD133-713, PD133-714	Document Number: PD196-284R1
	ELED Table Stand Installation Instructions	Page 1 of 2

SCOPE:

To install a PDi table stand to an ELED TV. (Your product may vary slightly in appearance from item shown)

PARTS LIST:

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	PD133-712 PD133-713 PD133-714	29" STAND FOR LED TV 32" STAND FOR LED TV 42" STAND FOR LED TV
2	4	M4 X 10MM	M4X10MM PHILLIPS HEAD MACHINE SCREWS
3	4	M4 X 12MM	M4 X 12MM SHEET METAL SCREWS

TOOL LIST:

1. Safety glasses/goggles
2. Drill and bit for screw.

SAFETY STEPS:

1. Always wear safety glasses/goggles to prevent injury from debris.
2. Follow the installation/removal instructions for your existing products.
3. Only place TV on stable flat surface when using the stand.

PROCEDURE


1. Remove table stand and screws from box and protective sleeve.
2. Remove protective cover from stand base.
3. Place stem of stand to the base, making sure that the side attaching to the TV is facing the deepest part of the stand.



4. Insert all 4 screws (M4 X 12mm) into bottom of plate to secure stem.
Tighten screws with drill until secure, being careful not to strip screws.



- Lay TV face down on flat, stable, non scratch surface. Do not lay TV on anything smaller than the bezel of the TV.
- Insert stem of stand into back of TV making sure 2 tabs (shown) are secure in their proper place.



- Secure with (4) M4 x 10 machine screws as shown.

