	MODEL NUMBER: PD181-785 VESA ADAPTER PLATE	Document Number: PD196-298R2
	Installation Instructions	Page 1 of 2

Scope:

To install a PD181-785 VESA adapter plate to a P14 rear mount.

Tool List:

- Safety glasses/goggles
- Phillips Head Screwdriver

Safety Steps:

- Always wear safety glasses/goggles to prevent injury from debris.
- Follow the installation/removal instructions for your existing product.


Parts List:


PART	DESCRIPTION	QTY
PD181-785	VESA ADAPTER PLATE	1
PDI-753	STRAIN RELIEF	1
PDIPPHMSM4X710	PHILLIPS HEAD SCREW	4
PDIPPHMSM4X716	PHILLIPS HEAD SCREW	4

Procedure

Step 1:


Pass the coax cable booted end through center hole of the PD181-785 adapter plate. Then attach PD181-785 adapter plate to TV (with the two holes in the plate to the bottom of the TV) using (4) PDIPPHMSM4X716 screws.



	MODEL NUMBER: PD181-785 VESA ADAPTER PLATE	Document Number: PD196-298R2
	Installation Instructions	Page 2 of 2

Step 2:

Insert PDI-753 strain relief into adapter plate by squeezing around the coax close to the adapter plate and inserting into plate. The coax cable can be routed according to installation requirements of the selected mount.



Step 3:

Mount the TV to your chosen mount using the M4 screws that were supplied with the mount. If those screws are not long enough, use the (4) PDIPPHMSM4X710 screws for mounting the TV.