

SCOPE:

TO MOUNT A TV USING A PDI PD168-226 ARTICULATING WALL MOUNT KIT.

TOOL LIST


1. P1 OR P2, PHILLIPS SCREW DRIVER
2. SAFETY GLASSES/GOGGLES
3. LEVEL

SAFETY STEPS:


1. ALWAYS WEAR SAFETY GLASSES/GOGGLES TO PREVENT INJURY FROM DEBRIS.
2. FOLLOW THE INSTALLATION/REMOVAL INSTRUCTIONS FOR YOUR EXISTING PRODUCTS.

MOUNTING DISTANCE

16.6" MINIMUM FROM CLEVIS TO CEILING FOR 50" PLASTIC LED TV.


PROCEDURE TO MOUNT AN E50 LED TV:**STEP 1:**

ATTACH THE (4) PD181-825 MOUNTING BRACKETS (#1) TO THE BACK OF THE E50 LED TV USING FOUR PDIPPHMSM6X110 SCREWS (#3).



STEP 2:

ATTACH THE PD181-707 MOUNTING BRACKET (#2) TO THE PD181-825 MOUNTING PLATES (#1) USING FOUR PDIPPHMSM6X110 SCREWS (#4). THESE SCREWS ARE SUPPLIED WITH PD181-707 MOUNTING BRACKET KIT.



ITEM	PART NUMBER	DESCRIPTION	QTY
1	PD181-825	50" TV ADAPTER BRACKET	4
2	PD181-707	ARTICULATING WALL BRACKET	1
3	PDIPPHMSM6X110	M6 x 1.0 x 10mm PHILIPS HEAD SCREWS	4
4	PDIPPHMSM6X110	M6 x 1.0 x 10mm PHILIPS HEAD SCREW (SUPPLIED WITH PD181-707 KIT)	4