

Konica Minolta: Fax Report and Tray Pull

To Turn TX Result Report ON:

At the machine:

Utility → Administration Settings (Password: 1234567812345678) → Fax Settings → Report Settings → TX Result Report

Choose ON, and hit OK. Follow the prompts to exit back to the menu screen.

To Set the Finisher Tray for Fax Reports:

At the machine:

Utility → User Setting → System Setting → Paper Tray Setting → Print Lists

Choose which paper tray from which the TX Report should print, and hit OK. Follow the prompts to exit back to the menu screen.

